

**50-Port 10/100/1000Mbps with 4 Shared SFP
Managed Gigabit Switch**

WGSW-50040

Quick Installation Guide

Table of Contents

1. Package Content.....	3
2. Switch Management.....	4
3. Requirements.....	5
4. Terminal Setup.....	6
5. Logon on the Console.....	7
6. Configure IP Address.....	8
7. Telnet Management.....	10
8. Start Web Management.....	11
9. Save the Configuration.....	13
10. Login the Managed Switch.....	14
11. Customer Support.....	15

1. Package Content

Thank you for purchasing PLANET 50-Port 10/100/1000Mbps with 4 Shared SFP Managed Gigabit Switch, WGSW-50040. Terms of “**Managed Switch**” means the Switch mentioned titled in the cover page of this quick installation guide.

Open the box of the **Managed Switch** and carefully unpack it. The box should contain the following items:

- The Managed Switch x 1
- This Quick Installation Guide x 1
- User’s Manual CD x 1
- RJ-45-to-DB9 Console Cable x 1
- Power Cord x 1
- Rubber Feet x 4
- Two Rack-mounting Brackets with Attachment Screws x 1
- SFP Dust Caps x 4

If any item is found missing or damaged, please contact your local reseller for replacement.

2. Switch Management

To setup the Managed Switch, the user needs to configure the Managed Switch for network management. The Managed Switch provides two management options: **Out-of-Band Management** and **In-Band Management**.

■ Out-of-Band Management

Out-of-band management is the management through Console interface. **Generally, the user will use out-of-band management for the initial switch configuration**, or when in-band management is not available.

IMPORTANT!

The Managed Switch is shipped without IP address assigned by default. User must assign an IP address to the Managed Switch via the Console interface to be able to remote access the Managed Switch through Telnet or HTTP.

■ In-Band Management

In-band management refers to the management by login to the Managed Switch using Telnet, HTTP, or using SNMP management software to configure the Managed Switch. In-band management enables management of the Managed Switch for some devices attached to the Switch. Following procedures are required to enable In-band management:

1. Logon Console
2. Assign / Configure IP Address
3. Create a remote login account
4. Enable HTTP or Telnet server on the Managed Switch

In the case when in-band management fails due to Managed Switch configuration changes, out-of-band management can be used for configuring and managing the Managed Switch.

3. Requirements

The Managed Switch provide remote login interface for manage; the following equipments are necessary for further management.

- **Workstation** running Windows XP/2003/Vista/Windows 7, MAC OS X, Linux, Fedora, Ubuntu or other platform.
- **Serial Port Connect** (Terminal)
 - Above Workstation with COM Port (DB9) or USB-to-RS-232 converter.
 - Above Workstation has installed with terminal emulator, such as Hyper Terminal included in Windows XP/2003.
 - Serial cable: one end attach to the RS-232 serial port, the other end to the Console port of the Managed Switch.
- **Ethernet Port Connect**
 - Above Workstation with running OS compatible with TCP/IP protocols.
 - Above Workstation installed with Ethernet NIC (Network Card).
 - Network cables - Use standard network (UTP) cables with RJ-45 connectors.
 - Above Workstation has installed with WEB Browser and JAVA runtime environment Plug-in.



Note

It is recommended to use Internet Explore 7.0 or above to access the Managed Switch. If the Web interface of the Managed Switch is not accessible, please turn off the anti-virus software or firewall then try again.

4. Terminal Setup

To configure the system, connect a serial cable to a **COM** port on a PC or notebook computer and to serial (console) port of the Managed Switch. The console port of the Managed Switch is DCE already, so that you can connect the console port directly through PC without the need of Null Modem.




Figure 4-1 Managed Switch Console connection

A terminal program is required to make the software connection to the Managed Switch. Windows' **Hyper Terminal** program may be a good choice. The Hyper Terminal can be accessed from the **Start** menu.

1. Click **START** menu, then **Programs, Accessories** and then **Hyper Terminal**.
2. Type a name for opening Hyper Terminal, such as **"COM1_9600"**.
3. When the following screen appears, make sure that the COM port should be configured as:

- Baud : 9600
- Parity : None
- Data bits : 8
- Stop bits : 1
- Flow Control : None




Figure 4-2 Hyper Terminal COM port configuration


5. Logon on the Console

Once the terminal has connected to the device, power on the Managed Switch, the terminal will display that it is running testing procedures.

Then, the following message asks the login user name and password. The factory default user name and password as following and the login screen in Figure 5-1 appears.

Username: **admin**

Password: **admin**



```
COM1_9600 - HyperTerminal
File Edit View Call Transfer Help
[Icons]
UP
%Jan 01 00:00:20 2006 %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet1/
48, changed state to DOWN
%Jan 01 00:00:20 2006 %LINK-5-CHANGED: Interface Ethernet1/49, changed state to
UP
%Jan 01 00:00:20 2006 %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet1/
49, changed state to DOWN
%Jan 01 00:00:20 2006 %LINK-5-CHANGED: Interface Ethernet1/50, changed state to
UP
%Jan 01 00:00:20 2006 %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet1/
50, changed state to DOWN
%Jan 01 00:00:22 2006 %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet1/
48, changed state to UP
%Jan 01 00:00:22 2006 %DUPLEX-7-CHANGE: Interface Ethernet1/48, DUPLEX changed s
tate to FULL
%Jan 01 00:00:22 2006 %SPEED-8-CHANGE: Interface Ethernet1/48, SPEED changed sta
te to 1G

Username: admin
Password:
W6SW-50040>
```

Figure 5-1 Managed Switch Console Login screen

The user can now enter commands to manage the Switch. For a detailed description for the commands, please refer to the following chapters.



Note

1. For security reason, please change and memorize the new password after this first setup.
2. Only accept command in lowercase letter under console interface.


6. Configure IP Address

The IP address configuration commands for VLAN1 interface are listed below. Before in-band management, the Managed Switch must be configured with an IP address by out-of-band management (i.e. Console mode), the configuration commands are as follows (All switch configuration prompts are assumed to be "WGSW-50040" hereafter if not otherwise specified):

```
WGSW-50040> enable
WGSW-50040# config
WGSW-50040(config)# interface vlan 1
WGSW-50040(Config-if-Vlan1)# ip address 192.168.1.254 255.255.255.0
```

The previous command would apply the follow settings for the Managed Switch.

IPv4 Address: 192.168.1.254
Subnet Mask: 255.255.255.0




```
COM1_9600 - HyperTerminal
File Edit View Call Transfer Help
[Icons]
UP
%Jan 01 00:00:20 2006 %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet1/50, changed state to DOWN
%Jan 01 00:00:22 2006 %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet1/48, changed state to UP
%Jan 01 00:00:22 2006 %DUPLX-7-CHANGE: Interface Ethernet1/48, DUPLEX changed state to FULL
%Jan 01 00:00:22 2006 %SPEED-8-CHANGE: Interface Ethernet1/48, SPEED changed state to 1G
Password:
Username:
Password:
Username: admin
Password:
WGSW-50040>enable
WGSW-50040#config
WGSW-50040(Config-if-Vlan1)#interface vlan 1
WGSW-50040(Config-if-Vlan1)#ip address 192.168.1.254 255.255.255.0
WGSW-50040(Config-if-Vlan1)#
```

Figure 6-1 Configure IPv4 address screen

To check the current IP address or modify a new IP address for the Managed Switch, please use the procedures as follow:

■ Show the current IP address

1. On "WGSW-50040#" prompt, enter "show ip interface brief".
2. The screen displays the current IP address, Subnet Mask and Gateway. As show in Figure 6-2.



```
COM1_9600 - HyperTerminal
File Edit View Call Transfer Help
WGSW-50040(Config-if-Vlan1)#exit
WGSW-50040(config)#exit
WGSW-50040#show ip interface brief
Index      Interface      IP-Address      Status      Protocol
2002      Loopback       127.0.0.1       up          up
2003      Vlan1         192.168.1.254  up          up
WGSW-50040#_
```

Figure 6-2 Show IP information screen

If the IP is successfully configured, the Managed Switch will apply the new IP address setting immediately. You can access the Web interface of Managed Switch through the new IP address.



Note

If you do not familiar with console command or the related parameter, enter "**help**" anytime in console to get the help description.

7. Telnet Management

Login to the Telnet configuration interface. Valid login username and password are required; otherwise the Managed Switch will reject Telnet access. This is a method to protect the Managed Switch from unauthorized access. As a result, when Telnet is enabled for configuring and managing the Managed Switch, username and password for authorized Telnet users must be configured with the following command:

```
telnet-user <username> [password (0|7) <password>]
```

Assume an authorized user in the Managed Switch has a username of **"admin"**, and password of **"admin"**, the configuration procedure should like the following:

```
WGSW-50040> enable  
WGSW-50040# config  
WGSW-50040(config)# telnet-user admin password 0 admin
```

Enter valid login username and password in the Telnet configuration interface, Telnet user will be able to enter the Managed Switch's CLI configuration interface. The commands used in the Telnet CLI interface after login is the same as that in the Console interface.




Figure 7-1 Telnet Configuration Interface

8. Start Web Management

For configuring the IP address on the Managed Switch through out-of-band management, see the telnet management chapter.

To enable the Web configuration, users should type the CLI command IP http server in the global mode as below:

```
WGSW-50040> enable
WGSW-50040# config
WGSW-50040(config)# ip http server
```

The Managed Switch provides a built-in browser interface. You can manage it remotely by having a remote host with Web browser, such as Microsoft Internet Explorer, Mozilla Firefox, Google Chrome or Apple Safari.




Figure 8-1 IP Management diagram



Note

Please refer to Chapter 5 – CONFIGURE IP ADDRESS for the IPv4 IP address setting on the Managed Switch.

The following shows how to start up the **Web Management** of the Managed Switch, please note the Managed Switch is configured through an Ethernet connection, please make sure the manager PC must be set on the same **IP subnet address**.

For example, the IP address of the Managed Switch is configured with **192.168.1.254**, then the manager PC should be set at **192.168.1.x** (where x is a number between 1 and 253, except 254), and the default subnet mask is 255.255.255.0.

Login to the Web configuration interface. Valid login username and password are required; otherwise the Managed Switch will reject Telnet access. This is a method to protect the Managed Switch from unauthorized access. As a result, when Telnet is enabled for configuring and managing the Managed Switch, username and password for authorized Telnet users must be configured with the following command:

web-user <username> [password (0|7) <password>]

Assume an authorized user in the Managed Switch has a username of "admin", and password of "admin", the configuration procedure should like the following:

```
WGSW-50040> enable
WGSW-50040# config
WGSW-50040(config)# web-user admin password 0 admin
```

Enter valid login username and password in the web interface.

9. Save the Configuration

In Managed Switch, the running configuration file stores in the RAM. In the current version, the running configuration sequence running-config can be saved from the RAM to FLASH by **write** command or **copy running-config startup-config** command, so that the running configuration sequence becomes the start up configuration file, which is called configuration save.

```
WGSW-50040> enable
WGSW-50040# copy running-config startup-config
```




Figure 9-1 Copy running-config startup-config screen

10. Login the Managed Switch

1. Use Internet Explorer 7.0 or above Web browser, enter IP address **http://192.168.1.254** (that you have just set in console) to access the Web interface.
2. When the following dialog box appears, please enter the configured username **“admin”** and password **“admin”** (or the username / password you have changed via console). The login screen in Figure 10-1 appears.




Figure 10-1 Login screen

3. After entering the password, the main screen appears as Figure 10-2.




Figure 10-2 Web Main Screen of Managed Switch

4. The Switch Menu on the left of the Web page let you access all the commands and statistics the Switch provides.

Now, you can use the Web management interface to continue the Switch management or manage the Managed Switch by console interface. Please refer to the user manual for more.

11. Customer Support

Thank you for purchase PLANET products. You can browse our online FAQ resource at the PLANET Web site first to check if it could solve you issue. If you need more support information, please contact PLANET switch support team.

PLANET online FAQ :

<http://www.planet.com.tw/en/support/faq.php?type=1>

Switch support team mail address :

support_switch@planet.com.tw

Copyright © PLANET Technology Corp. 2010.

Contents subject to revision without prior notice.

PLANET is a registered trademark of PLANET Technology Corp. All other trademarks belong to their respective owners.

This page is intentionally left blank