PCI Express 10 Gigabit Ethernet Adapter

Quick Installation Guide

Version 2.2

Thank you for purchasing PLANET ENW-9801/ENW-9803 PCI Express 10 Gigabit Ethernet adapter. It supports x4 PCI Express interfaces. The 10 Gigabit Ethernet adapter provides a highly cost-effective solution to upgrading to the 10 Gigabit network with your existing Ethernet infrastructures.

Operation System Support:


- Windows Server 2008R2 64bits
- Windows Server 2012 64bits
- Windows Server 2016 64bits
- Windows 7 32/64bits
- Windows 8 32/64bits
- Windows 10 32/64bits
- Linux (2.6.x to 4.x)
- VMware® ESX 5.x

Package Contents

 1 x ENW-9801/ENW-9803 10Gigabit Ethernet Adapter (with long profile bracket)

- 1 -

- 1 x Quick Installation Guide
- 1 x User's Manual CD (including Quick Installation Guide and Driver)
- 1 x Low Profile Bracket



Hardware Installation


Step 1: Please turn off your PC.



- Step 2: Remove any metal decorations from your hands and wrists.
- Step 3: Remove the cover from your PC.
- **Step 4:** Locate an empty PCI Express slot and remove the corresponding back plate. Save the screw for use in Step 6.


Step 5: Carefully insert the 10 Gigabit Ethernet Adapter into the chosen slot and press firmly with proper push to ensure it is fully seated in the slot.

- 3 -



- **Step 6:** Secure the 10 Gigabit Ethernet Adapter with the screw you saved in Step 4.
- Step 7: Replace the PC cover.
- **Step 8:** Power on your PC and refer to the next section to install driver.

Installation on Windows 7




1. After installing the ENW-9801/ENW-9803 to your PC and booting it up, Windows 7 will detect it and you have to install driver.

	Action View Help
N P	
and the second se	NM-CV3L
	Computer
	Disk drives
	Display adapters
	DVD/CD-ROM drives
	IDE ATA/ATAPI controllers
Þ-@	Keyboards
	Mice and other pointing devices
Þ -	Monitors
⊳ - 9	Network adapters
a - [Other devices
	Ethernet Controller
Þ. 4	Ports (COM & LPT)
Þ	Processors
⊳-(Smart card readers
⊳-≋	Sound, video and game controllers
⊳ -1	System devices
⊳-1	Universal Serial Bus controllers
	-


2. Please move and right-click the mouse button for Ethernet Controller item and select "**Update Driver Software**".

File Action View Help					
	🖹 🙀 🕼				
A 🛁 ENM-CV3L					
▷ - I Computer					
Disk drives					
 Image: Second state of the second					
					IDE ATA/ATAPI controller
⊳ - Certa Keyboards					
Mice and other pointing e	devices				
Monitors					
Network adapters					
Other devices	a - 🗓 Other devices				
Ethernet Controller					
Ports (COM & LPT)	Update Driver Software				
Processors	Disable				
Smart card readers	Uninstall				
Sound, video and gam					
System devices	Scan for hardware changes				
🖕 🕛 Universal Serial Bus co					

- 6 -



 Please click "Browse" to specify the driver location to install. (Assume "E" is your CD-ROM drive. The driver can be found in E:\). Click "Next" to continue.
Let me pick from a list of device drivers on my computer This list will show installed driver software compatible with the device, and all driver software in the same category as the device.
Next Cancel
The driver is being installed.
(Update Driver Software - Ethernet Controller
Installing driver software
- 8 -



For more details, please refer to the manual found on the CD-ROM.

	es Drev Forder TextIldenses Bren Dere Unter TextIldenses Infer Dere Unter 120214 Dere Versen 44.464.131 Infer Dere Versen 44.464.131 Infer Dere Versen 44.464.131 Infer Dere Versen 44.464.131 Infer Dere Dere TextIldense Dere Versen 44.464.131 Infer Dere Dere
--	--



www.PLANET.com.tw

PLANET Technology Corp. 11F., No. 96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan 2010-A14100-003





Quick Installation Guide

Network Adapter ENW-9801 / ENW-9803

PCI Express 10G Ethernet Adapter



