

User's Manual

VIP-281SW

802.11n Wireless VolP Router



alitist 10 to The

2 Rinding TIPS 2 See a streng of 10 Series and 10

Copyright

Copyright (C) 2011 PLANET Technology Corp. All rights reserved.

The products and programs described in this User's Manual are licensed products of PLANET Technology, This User's Manual contains proprietary information protected by copyright, and this User's Manual and all accompanying hardware, software, and documentation are copyrighted.

No part of this User's Manual may be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form by any means by electronic or mechanical. Including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's personal use, and without the prior express written permission of PLANET Technology.

Disclaimer

PLANET Technology does not warrant that the hardware will work properly in all environments and applications, and makes no warranty and representation, either implied or expressed, with respect to the quality, performance, merchantability, or fitness for a particular purpose.

PLANET has made every effort to ensure that this User's Manual is accurate; PLANET disclaims liability for any inaccuracies or omissions that may have occurred.

Information in this User's Manual is subject to change without notice and does not represent a commitment on the part of PLANET. PLANET assumes no responsibility for any inaccuracies that may be contained in this User's Manual. PLANET makes no commitment to update or keep current the information in this User's Manual, and reserves the right to make improvements to this User's Manual and/or to the products described in this User's Manual, at any time without notice.

If you find information in this manual that is incorrect, misleading, or incomplete, we would appreciate your comments and suggestions.

CE mark Warning

The is a class B device, In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

WEEE Warning



To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Trademarks

The PLANET logo is a trademark of PLANET Technology. This documentation may refer to numerous hardware and software products by their trade names. In most, if not all cases, their respective companies claim these designations as trademarks or registered trademarks.

Revision

User's Manual for PLANET 802.11n Wireless VolP Router: Model: VIP-281SW Rev: 1.0 (2011, February)

Part No. EM-VIP-281SW_v1

Chapter 1 Introduction	6
Overview	6
Package Content	7
Physical Details	7
Physical Interface & Button	8
Chapter 2 Preparations & Installation	9
Physical Installation Requirement	9
Keypad commands	10
Chapter 3 Network Settings	13
Configuring and monitoring your Router from web browser	13
Overview on the web interface of Router	13
Manipulation of Router via web browser	13
Network Oprtation Mode	14
WAN Interface Setup	15
LAN Interface Setup	21
Chapter 4 Wireless Settings	23
Basic Settings	23
Advanced Settings	25
Security Setup	27
Access Control	30
WDS Settings	30
Site Survey	31
WPS Settings	31
Wireless Schedule	34
Chapter 5 Firewall Settings	35
Port Filtering	35
IP Filtering	35
MAC Filtering	36
Port Forwarding	37
URL Filtering	37
DMZ	38
QoS	38
Chapter 6 SIP Settings	
Phone 1 / Phone 2	39
Tone	49
Other	51
SIP QoS	52
Chapter 7 Management	53

	Status	53
	Statistics	53
	DDNS	54
	Time Zone Setting	55
	Denial-of-Service	55
	SNMP Management	56
	Log	57
	Upgrade Firmware	58
	Auto Config	58
	Save / Reload Settings	60
	Password Setup	61
Chapte	er 8 Utility	62
	Ping Watchdog Setup	62
	Ping Test	62
	Traceroute	63
	Reboot	63
	Logout	63
Ap	opendix A Voice communication samples	64
	Peer to peer (P2P) mode	64
	Case 2: (Peer-to-Peer mode) VIP-281SW Port 1 to Port 2 communications	65
	Case 3: SIP Proxy mode	66
	Case 4: Call Forward Feature	69
	Case 5: VIP-281SW register with IPX-1900 via WAN port	71
	Case 6: VIP-281SW register with UMG-2000 via WAN port	74
Ap	opendix B The method of featured voice operation guide	76
	Call Transfer	76
	3-Way Conference	76
	Call Waiting	76
	Switch the Default Proxy	76
	Auto Update firmware by manual (Keypad)	77
Ap	opendix C Frequently Asked Questions List	78
Ar	opendix D Router Specifications	79

Chapter 1 1 Introduction

Overview

Integrating the cutting edge of Internet Telephony and VoIP Router manufacturing experience, PLANET now introduces the latest member of PLANET Wireless VoIP Router family: the VIP-281SW.

The VIP-281SW provides not only high-quality voice communications and wired Internet sharing capabilities but also the Access Point (AP) function for flexible wireless communication. With advanced router and VoIP DSP processor technology, the VIP-281SW is able to make calls via SIP proxy voice communications plus the IP sharing and the QoS mechanism.

By applying the VIP-281SW, home users and companies are able to save installation cost and extend the VoIP network from their previous investments in telephones, conferences and speakerphones. The VIP-281SW is equipped with two telephony interfaces, so users may register to different SIP proxy servers and establish up to 2 concurrent VoIP calls for more flexibility in the voice communications. The VIP-281SW can also be the bridge between traditional analog telephones and IP network with an extremely affordable investment.

With built-in IEEE 802.11b/g/n wireless network capability, the VIP-281SW allows any computer and wireless enabled network client connect to it without additional cabling. The 802.11n wireless capability gives users the highest speed of wireless experience ever. With an 802.11n compatible wireless adapter installed in your PC, the files can be transferred at up to 300Mbps. The radio coverage is also doubled to offer the high speed wireless connection even in a wide space of your office or house.

To secure the wireless communication, the VIP-281SW supports most up-to-date encryption: WEP, WPA-PSK and WPA2-PSK. In addition, the VIP-281SW supports WPS configuration with PBC/PIN type for users to connect to a secured wireless network easily.

Product Features

- IEEE 802.11b/g/n wireless standard compliant
- Multi-mode: AP, AP-Client Mode
- Smart QoS mechanism to ensure the voice quality
- Auto-Provision feature for flexible, ease-of use system integration
- NAT Router, Port Forwarding, DMZ
- IP ToS (IP Precedence) / DiffServ
- Voice prompt for machine configurations
- Supports 64/128-bit WEP, WPA, WPA-PSK, WPA2, WPA2-PSK and 802.1x encryption

VoIP Features

- SIP 2.0 (RFC3261) compliant
- Up to 2 concurrent VoIP calls
- Voice codec support: G.711, G.729 AB, G.723, G.276, GSM and G.722

- T.38 FAX transmission over IP network (G.711 Fax pass-through)
- In-band and out-of-band DTMF Relay (RFC 2833)
- 3-Way conference calls
- Call Waiting / Forward / Transfer / Hold / Resume
- Caller ID Detection / Generation: DTMF, BELLCORE, ETSI, BT, NTT
- Voice processing: VAD, CNG, Dynamic Jitter Buffer, G.168 Line Echo Cancellation
- SNMP v1/v2 and Auto Provision management

Package Content

The contents of your product should contain the following items: 802.11n Wireless VoIP Router Power adapter Quick Installation Guide User's Manual CD RJ-11 cable x 2 RJ-45 cable x1 Antenna x2

Physical Details

The following figure illustrates the each panel of VIP-281SW



Front Panel of VIP-281SW



Rear Panel of VIP-281SW

Physical Interface & Button

Front Panel LED Indicators

LED	State	Descriptions	
D\W/D	ON	Router is power ON	
	Off	Router is power Off	
	ON	Router network connection established	
WAN	Flashing	Data traffic on cable network	
	Off	Waiting for network connection	
	ON	LAN is connected successfully	
LAN	Flashing	Data is transmitting	
	Off	Ethernet not connected to PC	
WPS	ON	The Wi-Fi Protected Setup function is starting.	
W1 3	Off	The Wi-Fi Protected Setup function is close	
WIAN	Flashing	Transmitting or receiving data through the Wireless LAN	
WEAN	Off	Wireless LAN is no function	
	ON	Telephone Set is On-Hook	
Phone	Flashing	Ring Indication	
	Off	Telephone Set is Off-Hook	
Pose	t Button	- Pressing 1 second to reboot machine.	
Rest	et Button	- Pressing 5 seconds to reset to the factory default setting	
		- Pressing 3 seconds to start the WPS function 2 minutes for client	
WPS	Button	connection.	
		- Pressing 10 seconds to enable or disable the wireless function.	

Rear Panel Indicators

1	WAN	RJ-45 connector for Internet access, connected directly to Switch/Hub through straight CAT-5 cable.
2	LAN	RJ-45 connector, to maintain the existing network structure, connected directly to the PC through straight CAT-5 cable
3	FXS	RJ-11 connector, connected directly to the analog phone.
4	12V DC	12V DC Power input outlet
5	Antenna	Used to connect the external antenna for accessing to 802.11b/g/n wireless network

V Note

- Machine LAN port default IP is <u>http://192.168.0.1</u>. Press RESET button on front panel over 5 seconds will reset the VoIP Router to factory default value. (Except speed dial and call forward settings)
- 2. Using the power supply that is not the one included in package will cause damage and void the warranty for this product.

Chapter 2 Preparations & Installation

Physical Installation Requirement

This chapter illustrates basic installation of Wireless VoIP Router ("Router" in the following term)

- Network cables. Use standard 10/100Base-TX network (UTP) cables with RJ-45 connectors.
- TCP/IP protocol must be installed on all PCs.

For Internet Access, an Internet Access account with an ISP, and either of a DSL or Cable modem

Administration Interface

PLANET Router provides GUI (Web based, Graphical User Interface) and utility for machine management and administration.

Web configuration access

You will connect to SIP Router via your web browser automatically. Router will prompt for logon username / password, please enter: *admin / admin* to continue machine administration.



Router will prompt for logon username/password, please enter: *admin / admin* to continue machine administration.

The default IP address of LAN port is **192.168.0.1**. (The WAN port is DHCP client mode.) You also could open your web browser, and insert *http://192.168.0.1* in the address bar of your web browser to logon Router web configuration page.

To start Router web configuration, you must have one of these web browsers installed on computer for management

• Microsoft Internet Explorer 6.00 or higher with Java support

Please locate your PC in the same network segment
(192.168.0.x) of Router. If you're not familiar with TCP/IP,
please refer to related chapter on user's manual CD or
consult your network administrator for proper network
configurations.

Keypad commands

The Router series phone adapters support telephone keypad configurations, please connect analog telephone set and refer to the following table for machine network configurations.

IVR Menu Choice Machine operation		Parameter(s)	Notes
#111# Set DHCP client		None	WAN port will change to DHCP Client
#112xxx*xxx* Setup Static IP Address		Use the * (star) key when entering a decimal point.	DHCP will be disabled and system will change to the Static IP type.
#113xxx*xxx*xxx* xxx#	Set Network Mask	Use the * (star) key when entering a decimal point.	Must set Static IP first.
#114xxx*xxx*xxx* xxx#	Set Gateway IP Address	Use the * (star) key when entering a decimal point.	Must set Static IP first.
#115xxx*xxx*xxx* xxx#	Set Primary DNS Server	Use the * (star) key when entering a decimal point.	Must set Static IP first.
#190#	Unlock	None	Must unlock the protect function before carry out the firmware update (#160#).
#195#	Save Network Settings	None	Must save network settings after set up network settings via keypad.

			The system will be reset to
#198#	Factory Reset	None	factory default value and
			reboot automatically.

Following keypad commands can be used to display the network settings enabled on Router via voice prompt.

IVR Menu Choice	Machine operation	Notes
#120#	Chock I AN port IP Addross	IVR will announce the current IP address of
#120#	Check LAN port if Address	the LAN port.
#106#	Chook WAN port ID Address	IVR will announce the current IP address of
#120#	Check wan port iP Address	the WAN port.
#101#	Check notwork connection Type	IVR will announce if DHCP in enabled or
#121#	Check helwork connection type	disabled. (WAN port)
#100#	Chack the Dhane Number	IVR will announce current enabled VoIP
#122#		number. (WAN port)
#100#	Chaole Notwork Moole	IVR will announce the current network mask
#123#	Check Network Mask	of the Router. (WAN port)
#4.0.4#	Chaok Catoway ID Address	IVR will announce the current gateway IP
#124#	Check Galeway IF Address	address of the Router. (WAN port)
#105#	Chook DNS Sonier Setting	IVR will announce the current setting in the
#125#	Check DNS Server Setting	DNS field. (WAN port)
#128#	Check Firmware Version	IVR will announce the version of the
#120#		firmware running on the Router.

Following keypad commands can be used to set up the main function .

IVR Menu Choice	Machine operation	Parameter(s)	Notes
#130+first priority codec	Set First Priority Codec	01: G.711 u-Law, 02: G.711 a-Law, 03: G.729, 04: G.723 6.3K, 05: G.723 5.3K, 06: G.726 16K, 07: G.726 24K, 08: G.726 32K, 09: G.726 40K, 10: GSM-FR, 11: G.722	You can set the codec you want to the first priority. For example: #13001# Set G.711 u-Law to the first priority codec
#133#	Set Speaker Voice Gain	00~31, 32: Mute	For example: #13305# Mic Voice: 5
#134#	Set Mic Voice Gain	00~31, 32: Mute	For example: #13410# Mic Voice: 10
#138#	Enable call waiting	None	Enable Call waiting

#139#	Disable call waiting	None	Disable Call waiting
#140+Forward type+Forward Phone Number#	Forward Settings	Forward Type: 1: Immediate Forward 2: Busy Forward 3: No answer Forward	For example: #1401101# Immediate Forward to 101
#141#	Disable Forward Settings	None	
#150#	Select Default Realm	0: Realm 1, 1: Realm 2	For example: #1501# Set Default Proxy to Realm 2
#160#	Update firmware	None	Update firmware Must unlock the protect function (#190#) before carry out the firmware update.



Configuring and monitoring your Router from web browser

The Router integrates a web-based graphical user interface that can cover most configurations and machine status monitoring. Via standard web browser, you can configure and check machine status from anywhere around the world.

Overview on the web interface of Router

With web graphical user interface, you may have:

- More comprehensive setting feels than traditional command line interface.
- Provides user input data fields, check boxes, and for changing machine configuration settings
- Displays machine running configuration

To start Router web configuration, you must have one of these web browsers installed on computer for management

• Microsoft Internet Explorer 6.00 or higher with Java support

Manipulation of Router via web browser

Log on Router via web browser

After TCP/IP configurations on your PC, you may now open your web browser, and input http://192.168.0.1 (Default LAN port IP address) to logon Router web configuration page.

Enter the **IP address** of the Router which by default is **192.168.0.1**

File	Edit	View	Favorites	Tools	Help
GB	ack -	0	- 🗶 🔊 🤄	🄉 🔎 s	Search
Addi	ess 🦉	http:	//192.16	8.0.1	

Phone Adapter will prompt for logon username/password: admin / admin

Connect to 192.168	.0.1 🛛 💽 🔀
	GP
The server 192.168.0, password. Warning: This server password be sent in ar without a secure conn	1 at VIP-281SW requires a username and is requesting that your username and a insecure manner (basic authentication ection).
User name:	2
Password:	
	Remember my password
	OK Cancel

Router login prompt screen

When users login the web page, users can see the general information like company...etc in this main page.

PLANET Retworking & Communication	/	802.11n Wireless Vol	P Router
 VIP-281SW: Network Wireless Firewall QoS SIP Settings 	System Informa This page illustrate the sys	ition	
Utility	Company:	PLANET Technology Corp.	
Reboot	Contact Address:	11F, No. 96, Min Chuan Road, Hsin Tien, Taipei, Taiwan, R.O.C	
	Tel:	886-2-22199518	
	Fax:	888-2-22199528	
	E-Mail:	support_voip@planet.com.tw	
	Web Site:	www.planet.com.tw	

VoIP Router main page

Network Oprtation Mode

You can setup different modes to WAN and LAN interface for NAT, Bridging and Wireless ISP function



Operation Mode

Reset

You can setup different modes to WAN and LAN interface for NAT and bridging function.

● NAT:	In this mode, the device is supposed to connect to internet via ADSL/Cable Modem. The NAT is enabled and your PC in LAN port share the same IP to ISP through WAN port. The connection type can be setup in WAN page by using PPPOE, DHCP client, PPTP client, static IP or L2TP.
O Bridge:	In this mode, all ethernet ports are bridged together and NAT function is disabled. All the LAN port related function and firewall are not supported.
O Wireless ISP:	In this mode, all ethernet ports are bridged together and the wireless client will connect to ISP access point. The NAT is enabled and PCs in ethernet ports share the same IP to ISP through wireless LAN. You must set the wireless to client mode first and connect to the ISP AP in Site-Survey page. The connection type can be setup in WAN page by using PPPOE, DHCP client, PPTP client, static IP or L2TP.

	In this mode, the device is supposed to connect to internet via
NAT	ADSL/Cable Modem. The NAT is enabled and your PC in LAN port
	shares the same IP to ISP through WAN port. The connection type
	can be setup in WAN page by using PPPOE, DHCP client, PPTP
	client, static IP or L2TP.
	In this mode, all Ethernet ports are bridged together and NAT function
Bridge	is disabled. All the LAN port related function and firewall are not
	supported.
Wireless ISP	In this mode, all Ethernet ports are bridged together and the wireless
	client will connect to ISP access point. The NAT is enabled and PCs in
	Ethernet ports share the same IP to ISP through wireless LAN. You
	must set the wireless to client mode first and connect to the ISP \ensuremath{AP} in
	Site-Survey page. The connection type can be setup in WAN page by
	using PPPOE, DHCP client, PPTP client, static IP or L2TP.

WAN Interface Setup

This page is used to configure the parameters for Internet network which connects to the WAN port of your Gateway. Here you may change the access method to static IP, DHCP, PPPoE, PPTP or L2TP by click the item value of WAN Access type.

Connection Type Description - Static IP

WAN Access Type:	Static IP
IP Address:	192.168.0.1
Subnet Mask:	255.255.255.0
Default Gateway:	192.168.0.254
MTU Size:	1412 (1400-1500 bytes)
DNS 1:	168.95.192.1
DNS 2:	168.95.1.1
DNS 3:	
Clone MAC Address:	0000000000
Enable uPNP	
Enable IGMP Proxy	
Enable Ping Access on WAN	
✓ Enable Web Server Access on WAN	
Enable PPTP pass through on VPN connection	
Enable L2TP pass through on VPN connection	

Apply Reset

Static IP	Set WAN interface as Static IP mode.
IP Address	WAN IP Address of the Router
	Default : 192.168.0.1
Subnet Mask	WAN mask of the Router
	Default : 255.255.255.0
Default Gateway	Gateway Address of the Router
	Default : 192.168.0.254
MTU Size	Set MTU (maximum transmission unit) size
	Default: 1412
DNS1/ 2/ 3	Set three alternatives Domain Name Server for WAN interface.
	Default : Null
Clone MAC Address	To clone the MAC by manual input.
	Default : 00000000000 (Null)
Enable UPnP	Check to enable UPnP function
	Default : Disable

Enable UPnP	Check to enable UPnP function
	Default : Disable
Enable ICMP Provu	Check to enable the IGMP Proxy function
	Default : Enable
Enable Bing Access on WAN	If accept ICMP response via WAN port
Enable Fing Access on WAN	Default : Enable
Enable IPSec pass through on	If accept be accessed to Web Management Interface via WAN
VPN connection	port
	Default : Enable
Enable PPTP pass through on	Check to enable PPTP pass through function
VPN connection	Default : Disable
Enable L2TP pass through on	Check to enable L2TP pass through function
VPN connection	Default : Disable

Connection Type Description – DHCP Client

WAN Access Type:	DHCP Client 💌	
Host Name:	VIP-281SW	
MTU Size:	1412 (1400-1492 bytes)	
Attain DNS Automa	itically	
○ Set DNS Manually		
DNS 1:	168.95.192.1	
DNS 2:	168.95.1.1	
DNS 3:		
Clone MAC Address:	0000000000	
Enable uPNP		
Enable IGMP Proxy		
Enable Ping Access on WAN		
Enable Web Server Access on WAN		
Enable PPTP pass through on VPN connection		
Enable L2TP pass through on VPN connection		

Apply Reset

DHCP Client	Set WAN interface as DHCP mode.
Attain DNS Automatically /	Select to attain DNS automatically from server or user wants to
Set DNS Manually	set DNS manually.
	Default : Set DNS Manually

Connection Type Description – PPPoE

WAN Access Type:	PPPoE	~
User Name:		
Password:		
Service Name:		
Connection Type:	Continuous	Connect Disconnect
Idle Time:	5	(1-1000 minutes)
MTU Size:	1412	(1360-1492 bytes)
Attain DNS Auton	natically	
Set DNS Manually		
DNS 1:	168.95.192.1	
DNS 2:	168.95.1.1	
DNS 3:		
Clone MAC Address:	Iress: 00000000000	
Enable uPNP		
Enable IGMP Proxy		
Enable Ping Access on WAN		
Enable Web Server Access on WAN		
Enable PPTP pass through on VPN connection		
Enable L2TP pass through on VPN connection		

Apply Reset

PPPoE	Set WAN interface as PPPoE mode.	
User Name	Set user name of PPPoE connection	
	Default : Null	
Password	Set password of PPPoE connection	
	Default : Null	
Service Name	Set Service Name of PPPoE for description	
	Default : Null	
Connection Type	Set PPPoE connection type to be Continuous/ Connect on Demand/	
	Manual. If user set type as Continuous, Router will keep trying to	
	connect to server when \ensuremath{PPOE} disconnect. If user set type as Connect	
	on Demand, please set following idle time, Router will check	
	connection after this time. If user set type as Manual, Router will only	
	connect or disconnect by press Connect or Disconnect manually.	
	Default : Continuous	
Idle Time	Set PPPoE connection idle time for Connect on Demand.	
	Default : 5	

After confirming the modification you've done, please click on the **Apply** button to apply settings effective and the Router will be reload page automatic by itsely, that you must to afresh enter the final modification IP address for logon web management.

Connection Type Description – PPTP/L2TP

WAN Access Type:	РРТР
Mode:	Oynamic IP
IP Address:	0.0.0.0
Subnet Mask:	0.0.0.0
Gateway:	0.0.0.0
Server IP Address:	
User Name:	
Password:	
Connection Type:	Continuous Connect Disconnect
Idle Time:	5 (1-1000 minutes)
MTU Size:	1412 (1400-1460 bytes)
Request MPPE Encryption Request MPPC Compression	

РРТР	Set LAN interface as PPTP/L2TP mode.	
Mode	Set IP type if Dynamic IP or Static IP at PPTP/L2TP connection.	
	Default : Dynamic IP	
IP Address	WAN IP Address of the Router at Static IP type.	
	Default : 0.0.0.0	
Subnet Mask	WAN Mask of the Router at Static IP type.	
	Default : 0.0.0.0	
Gateway	Gateway of the Router	
	Default : 0.0.0.0	
Server IP Address	Set PPTP/L2TP Server IP address.	
	Default : 0.0.0.0	
User Name	Set user name of PPTP/L2TP connection	
	Default : Null	
Password	Set password of PPTP/L2TP connection	
	Default : Null	
Server IP Address User Name Password	Set PPTP/L2TP Server IP address. Default : 0.0.0 Set user name of PPTP/L2TP connection Default : Null Set password of PPTP/L2TP connection Default : Null	

	Please be noticed that the Utility Tool is only designed
V Note	for the WAN environment setting. If the "Connect Type" is
	"PPPoE", the Utility Tool can NOT find the device.

LAN Interface Setup

This page is used to configure the parameters for local area network which connects to the LAN port of your Gateway. Here you may change the setting for IP address, subnet mask, DHCP, etc..

LAN Port Setup			
IP Address:	192.168.0.1		
Subnet Mask:	255.255.255.0		
DHCP Server:	Server 👻		
DHCP Client Range:	192.168.0.100 -		
brief chent Kunge.	192.168.0.200 Show Client		
Static DHCP:	Disabled V Set Static DHCP		
Domain Name:			
802.1d Spanning Tree:	Disabled 💌		
Clone MAC Address:	0000000000		
Port Bandwidth Manag	er		
Port	Egress(unit: kbps)	Ingress(unit: kbps)	
LAN Port 1	0	0	
LAN Port 2	0	0	
LAN Port 3	0	0	
LAN Port 4	0 0		
WAN Port	0 0		
Noto: Unlimit: 0. Egrado r	max: 1024 Ingrose max: /	1024	

Apply Reset

LAN IP Address of the Router
Default : 192.168.0.1
LAN mask of the Router
Default : 255.255.255.0
You can select Server or Disable. If you select Disable, the
DHCP service of LAN port is disabled.
Default : Server
The first and last IP address that DHCP server assigns.
Default: 192.168.0.100 - 192.168.0.200
It allows you reserve IP addresses, and assign the same IP
address to the network device with the specified MAC address
any time it requests an IP address
Default : Disable

Domain Name	Set three alternatives Domain Name Server for LAN interface.
	Default : Null
802.11d Spanning Tree	Spanning Tree Protocol. You can select Enable or Disable.
	Default : Disable
Port Bandwidth Manager	Show the egress and ingress total network traffic for each WAN
(WAN / LAN ports)	and LAN ports
	Default:0



Basic Settings

This page is used to configure the parameters for wireless LAN clients who may connect to your Access Point. Here you may change wireless encryption settings as well as wireless network parameters.

Wireless Basic Settings

This page is used to configure the parameters for wireless LAN clients which may connect to your Access Point. Here you may change wireless encryption settings as well as wireless network parameters.

Disable Wireless LAN Interface	
Band:	2.4 GHz (B+G+N) 💌
Mode:	AP V Multiple AP
Network Type:	Infrastructure 😪
SSID:	802.11bgn-SSID
Channel Width:	20MHz 💙
Control Sideband:	Upper 🗸
Channel Number:	6 🗸
Broadcast SSID:	Enabled 💌
WMM:	Enabled V
Data Rate:	Auto 💌
Associated Clients:	Show Active Clients
Enable Mac Clone (Single Ethernet Client)	
Enable Universal Repeater Mode (Acting as AP and client simultaneouly)	
SSID of Extended Interface:	

Apply Reset

Disable Wireless LAN	Enable or disable the wireless LAN	
Interface		
Band	There are 6 modes: 2.4GHz (B), 2.4GHz (G), 2.4GHz (N), 2.4GHz (B+G), 2.4GHz (G+N), and 2.4GHz (B+G+N) mode.	
	Default : 2.4GHz (B+G+N)	

Mode	 AP: The AP functions as a wireless hub to which wireless clients can connect. The clients must make sure that they are configured to match the AP's wireless settings. The AP must be connected to switch or other LAN segment patch cable. Client: In this mode the Router is used to access the Wireless
	Service Provider network by connecting wirelessly to the remote (Outdoor AP).
	 WDS: WDS operation as defined by the IEEE802.11 standard has been made available. Using WDS it is possible to wirelessly connect Access Points, and in doing so extend a wired infrastructure to locations where cabling is not possible or inefficient to implement. AP+WDS: It means the device can support WDS and AP Mode simultaneously.
	Default : AP mode
Network Type -	 Infrastructure: The wireless LAN serves as a wireless station (infrastructure). Connected to a PC or a small LAN (no more than 5 PCs), it allows the PC or small LAN able to access the wireless network via Access Point.
	- Ad hoc: The wireless LAN will use the Ad hoc mode to operate.
SSID	Wireless stations associating to the access point must have the same SSID. Enter a descriptive name for the wireless LAN.
	Default: 802.11bgn-SSID
Channel Width	There are 20MHz and 40MHz bandwidths for cohesion
	Default : 20MHz
Control Sideband	Specify if the extension channel should be in the Upper or Lower sideband
	Default : Upper (Unavailable)
Channel Number	Select the appropriate channel from the list provided to correspond
	with your network settings. Channels differ from country to country.
	Default : 6
Broadcast SSID	If you enable "Broadcast ESSID", every wireless station located within the coverage of this access point can discover this Router easily. If you are building a public wireless network, enabling this

WMM	The short of Wi-Fi Multi-Media, it will enhance the data transfer performance of multimedia contents when they're being transferred over wireless network. Default : Enable (Unavailable)
Data Rate	The Data Rate is the rate of data transmission for 802.11b/g/n clients. The Router will use the highest possible selected transmission rate to transmit the data packets.
	Default : Auto
Associated Clients	To show the MAC address, transmission, reception packet counters and encrypted status for each associated wireless client.
Enable Mac Clone	When set at Client mode, it provides wireless LAN to connect to a MAC address.
	Default : Disable
Enable Universal Repeater Mode	Universal Repeater is a technology used to extend wireless coverage.
	Default : Disable
SSID of Extended Interface	Click on "Enable Universal Repeater Mode"; In the "SSID of Extended Interface", enter the SSID of the wireless router that you want to extend. Default : Null

Advanced Settings

These settings are only for more technically advanced users who have a sufficient knowledge about wireless LAN. These settings should not be changed unless you know what effect the changes will have on your Access Point.

Wireless Advanced Settings

These settings are only for more technically advanced users who have a sufficient knowledge about wireless LAN. These settings should not be changed unless you know what effect the changes will have on your Access Point.

2346 (256-2346)
2347 (0-2347)
100 (20-1024 ms)
● Long Preamble
Inabled Object Disabled
Enabled Obisabled
Inabled Object Disabled
Enabled O Disabled
C Enabled

Apply Reset

Fragment Threshold	"Fragment Threshold" specifies the maximum size of packet during
	the fragmentation of data to be transmitted. If you set this value too
	low, it will result in bad performance.
	Default: 2346
RTS Threshold	When the packet size is smaller the RTS threshold, the access point
	will not use the RTS/CTS mechanism to send this packet.
	Default: 2347
Beacon Interval	The interval of time that this access point broadcast a beacon.
	Beacon is used to synchronize the wireless network.
	Default: 100
Preamble Type	Preamble type defines the length of CRC block in the frames during
	the wireless communication. "Short Preamble" is suitable for high
	traffic wireless network. "Long Preamble" can provide more reliable
	communication.
	Default : Long Preamble

IAPP	Inter-Access Point Protocol is a recommendation that describes an
	optional extension to IEEE 802.11 that provides wireless
	access-point communications among multivendor systems.
	Default : Enable
Protection	It is recommended to enable the protection mechanism. This
	mechanism can decrease the rate of data collision between 802.11b
	and 802.11g wireless stations. When the protection mode is enabled,
	the throughput of the AP will be a little lower due to many of frame
	traffic should be transmitted.
	Default : Enable
Aggregation	It is a function where the values of multiple rows are grouped
	together.
	Default : Enable
Short GI	It is used to set the time that the receiver waits for RF reflections to
	settle out before sampling data.
	Default : Enable
WLAN Partition	This feature also called WLAN isolation or Block Relay. If this feature
	is disabled, then there is no barrier between communications among
	wireless stations connecting to the Access Point, i.e the Router. If
	this is enabled, wireless stations of the selected band are not allowed
	to exchange data through the Access Point. The default value is set
	to 'Disabled'.
	Default : Disable
RF Output Power	Users can adjust the output power to 100%, 75% 50% 35% and
	15%.
	Default: 100%

Security Setup

This page allows you setup the wireless security. Turn on WEP or WPA by using Encryption Keys could prevent any unauthorized access to your wireless network.

Wireless Security Setup

This page allows you setup the wireless security. Turn on WEP or WPA by using Encryption Keys could prevent any unauthorized access to your wireless network.

Select	ect SSID: Root AP - 802.1		1bgn-SSID V Apply Reset
	Encryption:		Disable 💌
	802.1x	Authentication:	

Select SSID	If assigned multiple AP feature, you could choose the SSID that want to
	setup encryption function.
Encryption	Select the data privacy algorithm you want. Enabling the security can
	protect your data while it is transferred from one station to another.
	Default : Disable
802.1x Authentication	Check Box was used to switch the function of the 802.1X. When the
	802.1X function is enabled, the Wireless user must authenticate to this
	router first to use the Network service.
	Default : Uncheck

- WEP

When you select the 128 or 64 bit WEP key security, please select one WEP key to be used and input 26 or 10 hexadecimal (0, 1, 2...8, 9, A, B...F) digits.

Select	SSID: Root AP - 802.	11bgn-SSID V Apply Reset
	Encryption:	WEP
	802.1x Authentication	
	Authentication:	○ Open System ○ Shared Key ④ Auto
	Key Length:	64-bit 💌
	Key Format:	ASCII (5 characters) 💌
	Encryption Key:	****

- WPA

When select the WPA function, the Wireless user must **authenticate** to this router first to use the Network service. RADIUS Server IP address or the 802.1X server's domain-name.

If you select HEX, you have to fill in 64 hexadecimal (0, 1, 2...8, 9, A, B...F) digits

If ASCII, the length of pre-share key is from 8 to 63.

Key value shared by the RADIUS server and this router. This key value is consistent with the key value in the

RADIUS server.

Select	SSID: Root AP - 802.11b	gn-SSID 🖌 Apply Reset
	Encryption:	PA 🔽
	Authentication Mode:	○ Enterprise (RADIUS)
	WPA Cipher Suite:	
	Pre-Shared Key Format:	Passphrase
	Pre-Shared Key:	

- WPA2

When select the WPA function, the Wireless user must **authenticate** to this router first to use the Network service. RADIUS Server IP address or the 802.1X server's domain-name.

If you select HEX, you have to fill in 64 hexadecimal (0, 1, 2...8, 9, A, B...F) digits

If ASCII, the length of Pre-share key is from 8 to 63.

Key value shared by the RADIUS server and this router. This key value is consistent with the key value in the RADIUS server.

Select	SSID: Root AP - 802.11b	gn-SSID 🖌 Apply Reset
	Encryption: W	PA2 👻
	Authentication Mode:	○ Enterprise (RADIUS) ● Personal (Pre-Shared Key)
	WPA2 Cipher Suite:	
	Pre-Shared Key Format:	Passphrase
	Pre-Shared Key:	

- WPA-Mixed

When select the WPA-Mixed function, the Wireless user must **authenticate** to this router first to use the Network service. RADIUS Server

The router will detect automatically which Security type (WPA-PSK version 1 or 2) the client uses to encrypt. IP address or the 802.1X server's domain-name.

If you select HEX, you have to fill in 64 hexadecimal (0, 1, 2...8, 9, A, B...F) digits

If ASCII, the length of Pre-share key is from 8 to 63.

Key value shared by the RADIUS server and this router. This key value is consistent with the key value in the RADIUS server.

Select	SSID:	Root AP - 802.11b	gn-SSID 🖌 Apply Reset
	Епстур	tion:	/PA-Mixed 🔽
	Authen	tication Mode:	○ Enterprise (RADIUS)
	WPA C	ipher Suite:	
	WPA2	Cipher Suite:	
	Pre-Sh	ared Key Format:	Passphrase
	Pre-Sh	ared Key:	

Access Control

If you choose 'Allowed Listed', only those clients whose wireless MAC addresses are in the access control list will be able to connect to your Access Point. When 'Deny Listed' is selected, these wireless clients on the list will not be able to connect the Access Point.

Wireless Access Control

If you choose 'Allowed Listed', only those clients whose wireless MAC addresses are in the access control list will be able to connect to your Access Point. When 'Deny Listed' is selected, these wireless clients on the list will not be able to connect the Access Point.

Wireless Access Control Mode:	Disable	~
MAC Address:		
Comment:		
Current Access Control List	y Keset	
MAC Address	Comment	Select
	Comment	Jereet

WDS Settings

Wireless Distribution System uses wireless media to communicate with other APs, like the Ethernet does. To do this, you must set these APs in the same channel and set MAC address of other APs which you want to communicate with in the table and then enable the WDS.

WDS Settings

Wireless Distribution System uses wireless media to communicate with other APs, like the Ethernet does. To do this, you must set these APs in the same channel and set MAC address of other APs which you want to communicate with in the table and then enable the WDS.

🔲 Enable W	DS			
MAC Address:				
Data Rate:	Auto 🗸			
Comment:				
Apply	Reset	Set Security	Show Statistics	
Current WDS A	AP List:			
MAC Ac	ldress	Tx Rate (Mbps)	Comment	Select
	Delete S	elected Delete	All Reset	

Site Survey

This page provides tool to scan the wireless network. If any Access Point or IBSS is found, you could choose to connect it manually when client mode is enabled.

Wireless Site Survey

This page provides tool to sca could choose to connect it ma	n the wireless netw anually when client	ork. If any A mode is ena	Access P abled.	oint or IBS	S is found,
SSID	BSSID	Channel	Туре	Encrypt	Signal
	Refresh	Connect			

WPS Settings

Wi-Fi Protected Setup (WPS) is the simplest way to build connection between wireless network clients and this wireless router. You don't have to select encryption mode and input a long encryption pass phrase every time when you need to setup a wireless client, you only have to press a button on wireless client and router, and the WPS will do the rest for you.

This wireless router supports two types of WPS: Push-Button Configuration (PBC), and PIN code. If you want to use PBC, you have to push a specific button on the wireless client to start WPS mode, and switch this wireless router to WPS mode too. You can push RET/WPS button of this wireless router, or click 'Start PBC' button in the web configuration interface to do this. If you want to use PIN code, you can see the setup as below.

Wi-Fi Protected Setup

This page allows you to change the setting for WPS (Wi-Fi Protected Setup). Using this feature could let your wireless client automically syncronize its setting and connect to the Access Point in a minute without any hassle.

✓ Disable WPS	
WPS Status:	Configured OunConfigured Reset to UnConfigured
Self-PIN Number:	
Push Button Configuration:	Start PBC
	Apply Reset
Client PIN Number:	Start PIN

Disable WPS	Check this box to disable WPS function, uncheck it to enable WPS.
WPS Status	If the wireless security (encryption) function of this wireless router is
	properly set, you'll see 'Configured' message here. If wireless
	security function has not been set, you'll see 'unConfigured'.
Self-PIN Number	This is the WPS PIN code of this wireless router. This code is useful
	when router sets as Enrollee, you need to fill this number into the
	web page of the other device.
Push Button	Click 'Start PBC' to start Push-Button style WPS setup procedure.
Configuration	This wireless router will wait for WPS requests from wireless clients
	for 2 minutes. The 'WLAN' LED on the wireless router will be steady
	on when this wireless router is waiting for incoming WPS request.
Client PIN Number	Please input the PIN code of the other device you wish to connect,
	and click 'Start PIN' button. The 'WLAN' led on the wireless router will
	be steady on when this wireless router is waiting for incoming \ensuremath{WPS}
	request. (Please see the detail as below.)

- PBC setup step:

- 1. Ensure you have set the security setting on Router (as Registrar).
- 2. Click the WPS button on Router (or the "Start PBC" button on the web interface of Router) and the other device (supports PBC function) in 2 minutes.
- 3. Router (Registrar) would send SSID and security key to the other device (Enrollee) through tunnel to connect.

4. If you see the wireless client in the list, WPS-PBC setting is successful.



- PIN (as register) setup step:

- 1. Select Config Mode: "Registrar" on Router.
- 2. Fill the PIN code of the other device (as Enrollee that support WPS-PIN setting) into the "configure via Client Pincode" of Router.
- 3. Click the PIN buttons on Router and the other device in 2 minutes.
- 4. If you see the wireless client in the list, WPS-PIN setting is successful.



- PIN (as Enrollee) setup step:

- 1. Select Config Mode: "Enrollee" on Router.
- 2. Fill the PIN code of Router into the other device (as Registrar).
- 3. Click the PIN buttons on Router and the other device in 2 minutes.
- 4. If you see the wireless client in the list, WPS-PIN setting is successful.

** As the figure as above, just change two roles.

Wireless Schedule

This page allows you setup the wireless schedule rule. Please do not forget to configure system time before enable this feature.

Wireless Schedule

This page allows you setup the wireless schedule rule. Please do not forget to configure system time before enable this feature.

Enabl	e Wireless Schedule
Days :	Everyday Sun Mon Tue Wed Thu Fri Sat
Time :	○ 24 Hours ● From 00 ♥ : 00 ♥ To 00 ♥ : 00 ♥
	Apply Reset

Chapter 5 5 Firewall Settings

Port Filtering

Entries in this table are used to restrict certain types of data packets from your local network to Internet through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

Port Filtering

Entries in this table are used to restrict certain types of data packets from your local network to Internet through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

Enable Port F	iltering	
Port Range:		
Protocol:	Both	
Comment:		
	Apply Reset	
Current Filter Tab	le	
Port Range	Protocol Comment	Select
ſ	Delete Selected Delete All Reset	

IP Filtering

Entries in this table are used to restrict certain types of data packets from your local network to Internet through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

IP Filtering

Entries in this table are used to restrict certain types of data packets from your local network to Internet through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

Loal IP Address: Protocol:			
Protocol:	R		
		oth \vee	
Comment:			
C			

MAC Filtering

You can filter Internet access for local clients based on MAC Address. The MAC address filter enables you to allow or restrict specified nodes from communicating with other nodes.

MAC Filtering

Entries in this table are used to restrict certain types of data packets from your local network to Internet through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

Enable MAC Filtering		
MAC Address:		
Comment:		
Apply Reset		
MAC Address	Comment	Select
Delete Selected	Delete All Reset	
Port Forwarding

The Port Forwarding allows you to re-direct a particular range of service port numbers (from the Internet/WAN Ports) to a particular LAN IP address. It helps you to host some servers behind the firewall.

Port Forwarding					
Entries in this table allow you to automatically redirect common network services to a specific machine behind the NAT firewall. These settings are only necessary if you wish to host some sor of server like a web server or mail server on the private local network behind your Gateway's NAT firewall.					cific me sort s NAT
					1
Enable Port For	rwarding				
IP Address:					
Protocol:	Both	~			
Port Range:		-			
Comment:					
Apply Reset					
Current Port Forwar	ding Table				
Local IP Address	Protocol	Port Range	Comment	Select	
	Delete Selected	Delete All	Reset		

URL Filtering

URL Filtering

URL filter is used to deny LAN port users from accessing the internet. Block those URLs which contain keywords listed below.

	5	
URL filter is used t contain keywords I	o deny LAN port users from accessing th listed below.	e internet. Block those URLs which
Enable URL	. Filtering	
URL Address:		
	Apply Reset	
Current Filter Ta	able	
	URL Address	Select
	Delete Selected Delete All	Reset

DMZ

A Demilitarized Zone is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains devices accessible to Internet traffic, such as Web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.

DMZ

A Demilitarized Zone is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains devices accessible to Internet traffic, such as Web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.

Enable DMZ	
DMZ Host IP Address:	
	Apply Reset

QoS

Entries in this table improve your online gaming experience by ensuring that your game traffic is prioritized over other network traffic, such as FTP or Web.

QoS

Entries in this table improve your online gaming experience by ensuring that your game traffic is prioritized over other network traffic, such as FTP or Web.

Enable QoS					
Automatic Uplink Spe	ed				
Manual Uplink Speed (Kbj	os):	0			
Address Type:		●IP ○N	IAC		
Local IP Address:					
Port:			-	(1 ~ 6553	5)
Protocol:		TCP	1		
MAC Address:					
Mode:		Guaranteed minimum bandwidth			
Bandwidth (Kbps):					
Comment:					
Apply Reset					
Current QoS Rules Table					
Application Selected Po	ort	Protocol	Priority	Comment	Select

Delete All

Reset

Delete Selected



Phone 1 / Phone 2

This page is used to configure the parameters for SIP registration information. Here you also could setup the other functions like Call Forward, Voice Codec, Speed Dial and others.

After finish all the settings, press the Apply button to activate the new settings, or press the button to cancel the changes.

- Default Proxy

	Default Proxy			
	Select Default Pro	ху	Realm 1 🐱	
				_
Select Default	ault Proxy Each Phone port has support register two different Proxy		roxy	
	Servers. When select one of Proxy as default, Router will		r will use	
		this account for making outgoing call. And Router could receiv		uld receive
	incoming calls through both Proxys.			
	Default : Realm1			

- Realm 1 / Realm 2

Realm 1	
Display Name	
Line Number	
Register Name	
Register Password	
Ргоху	Enable
Proxy Server	
Proxy Port	5060
Domain Server	
SIP Expire Time	60
Outbound Proxy	Enable
Outbound Proxy Server	
Outbound Proxy Port	5060
Nortel SoftSwitch	Enable
Register Status	Not Registered

Display Name	Set Router Phone display name for caller ID information.
	Default : Null
Line Number	Set registering Phone number.
	Default : Null
Register Name	If Proxy server needs registration authentication please input
	Login ID here.
	Default : Null
Register Password	If Proxy server needs registration authentication please input password here.
	Default : Null
Proxy	Check to enable Proxy mode.
	Default : Disable
Proxy Server	If user enable Proxy mode, please input Proxy address.
	Default : Null
Proxy Port	If user enable Proxy mode, please input Proxy port.
	Default : 5060
Domain Server	Set SIP domain name for SIP signaling.
	Default : Null
SIP Expire Time	Set expire time of registration. Router will keep re-registering to
	proxy server before expire timed out.
	Default: 60 (sec)
Outbound Proxy	Check to enable Outbound Proxy mode.
	Default : Disable
Outbound Proxy Server	If user enables Outbound Proxy, please input Outbound Proxy
	address.
	Default : Null
Outbound Proxy Port	If user enables Outbound Proxy, please input Outbound Proxy
	port.
	Default : 5060
Nortel SoftSwitch	Enable this option for better compatibility capability with the
Desister Status	
Register Status	Here will display SIP account register status.

- Call Forward

Call Forward	
All Forward	⊙ Off ○ VoIP
All Fwd No.	
Busy Forward	⊙ Off ○ VoIP
Busy Number	
No Answer Forward to	⊙ Off ◯ VoIP
No Answer Number	
No Answer Time (sec)	0

All Forward	This is unconditional forward setting. All incoming call will be
	forwarded to specified number. Check to enable immediate
	forward function.
	Default : Off
All Fwd No.	Enter the assigned number for Immediate forward.
	Default : Null
Busy Forward	Check to enable Busy Forward function. When phone is busy,
	incoming call will be forwarded to assigned number.
	Default : Off
Busy Number	Enter the assigned number for busy forward.
	Default : Null
No Answer Forward to	Default : Null Check to enable no answer forward function. When phone is not
No Answer Forward to	Default : Null Check to enable no answer forward function. When phone is not answered for a period of time, incoming call will be forwarded to
No Answer Forward to	Default : Null Check to enable no answer forward function. When phone is not answered for a period of time, incoming call will be forwarded to assigned number.
No Answer Forward to	Default : NullCheck to enable no answer forward function. When phone is not answered for a period of time, incoming call will be forwarded to assigned number.Default : Off
No Answer Forward to No Answer Number	Default : NullCheck to enable no answer forward function. When phone is not answered for a period of time, incoming call will be forwarded to assigned number.Default : OffEnter assigned number for no answer forward.
No Answer Forward to No Answer Number	Default : NullCheck to enable no answer forward function. When phone is not answered for a period of time, incoming call will be forwarded to assigned number.Default : OffEnter assigned number for no answer forward.Default : Null
No Answer Forward to No Answer Number No Answer Time (sec)	Default : NullCheck to enable no answer forward function. When phone is not answered for a period of time, incoming call will be forwarded to assigned number.Default : OffEnter assigned number for no answer forward.Default : NullSet no answer time. Once phone is not picked up after this time,
No Answer Forward to No Answer Number No Answer Time (sec)	Default : NullCheck to enable no answer forward function. When phone is not answered for a period of time, incoming call will be forwarded to assigned number.Default : OffEnter assigned number for no answer forward.Default : NullSet no answer time. Once phone is not picked up after this time, incoming call be will forwarded to assigned number.

- Abbreviated Dial (Phonebook)

Abbreviated Dial			
Abbreviated Name	Phone Number		

Abbreviated Name	Abbreviated Dial (Phonebook) access code. Input this number
	and followed by # can dial out assigned phone number.
Phone Number	Set phone number for Router to make speed dial.

- Dial Plan

Dial Plan		
Replace prefix code	◯ On ⊙ Off	
Relace rule		
Dial Plan		
Auto Prefix		
Prefix Unset Plan		

Replace prefix code	Select to enable (On) or disable (Off) prefix replace function.			
	Default : Off			
Relace rule	Set prefix replace rule. Once user dial number matched prefix,			
	Router will replace the number with assigned number. Available			
	parameters are " 0~9 ", " # ", " * ", " + ", " x ". Symbol " + " means " or " , " x "			
	could be numbers 0~9 . For example, if user set Replace rule as			
	002+009->005, which means if user dial 002 87654321 or 009			
	87654321, these number will be dial out as 005 87654321.			
	Default : Null			
Dial Plan	User can set how many digits or which number for Router to dial out			
	immediately. Available parameters are "0~9", "#", "*", "+", "x".			
	Symbol "+" means " or " , " x " could be numbers " 0~9" . For example,			
	user can set Dial Plan as "911+xxxxxxx+*xx, which means if user			
	dial 911, 87654321, or *11, these number will be dial out immediately			
	dial 911 , 87654321 , or *11 , these number will be dial out immediately without waiting for dial time or pressing # sign.			

Auto Prefix	If user set Auto Prefix number, all number dialed out will be added
	with this prefix number. Available parameters are " U~9 ", "#", "^".For
	example, user set Auto Prefix as 02, number 87654321 will be dial
	out as 02 87654321.
	Default : Null
Prefix Unset Plan	User can set special access code to disable Auto Prefix function in
	single call. Available parameters are "0~9", "#", "*", "+", "x". Symbol
	"+" means "or" , "x" could be numbers "0~9". For example, if user set
	Prefix Unset Plan as *1+xxxxxxxx x. When dialed number as *1
	87654321 or 10 digits of number, for this call will not be added with
	Auto Prefix number.
	Default : Null

- Speed Dial

Speed Di	al		
Position	Name	Phone Number	Select
0			
1			
2			
3			
4			
5			
6			
7			
8			
9			
	Remove Sele	ected Remove All	

Position	Speed Dial access code. Press this speed dial number and			
	followed by # can dial out assigned phone number.			
Name	Name of this speed dial.			
Phone Number	Set phone number for Router to make speed dial.			
Select	User can delete selected speed dial data.			

- SIP Advanced

SIP Advanced				
SIP Port	5060			
Media Port	9000			
DMTF Relay	RFC2833 💌			
RFC2833 Payload Type	101			
SIP INFO Duration (ms)	250			
Call Waiting	Enable			
Call Waiting Caller ID	Enable			
Reject Direct IP Call	Enable			

SIP Port	Set local SIP listening port.		
	Default : 5060		
Media Port	Set RTP port for sending voice data.		
	Default : 9000		
DMTF Relay	Select DTMF Relay to be In band, RFC 2833, or SIP INFO.		
	Default : Inband		
RFC2833 Payload Type	If user select DTMF as RFC 2833 type, here can modify RFC		
	2833 payload type.		
	Default: 96		
SIP INFO Duration (ms)	If user select DTMF as SIP INFO type, here can modify SIP		
	INFO duration. Router will send out DTMF as this duration.		
	Default: 250		
Call Waiting	Check to enable Call Waiting function.		
	Default : Enable		
Call Waiting Caller ID	Check to enable call waiting caller ID function. If this function is		
	enabled, caller ID will display when having waiting call. Please		
	note that your phone set should also support such function.		
	Default : Disable		
Reject Direct IP Call	Check to enable Reject Direct IP Call. If this function is enabled,		
	Router will to reject the incoming peer to peer call.		
	Default : Disable		

- NAT Traversal

NAT Traversal	
Stun	Enable
Stun Server	
Stun Port	3478

Stun	Check to enable STUN function.
	Default : Disable
Stun Server Addr	Default : Disable If user enables STUN function, please input STUN Server address. Default : Null rver Port If user enables STUN function, please input STUN Server
	Default : Null
Stun Server Port	If user enables STUN function, please input STUN Server port.
	Default: 3478

- Codec

Codec										
Туро	Precedence									
Type	1	2	3	4	5	6	7	8	9	10
G711-ulaw										
G711-alaw										
G729										
G723										
G726-16k										
G726-24k										
G726-32k							✓			
G726-40k										
GSM-FR									~	
G722										~
Option	G726 Packing Order					Right 🗸				
Opuon	G72	G723 Bit Rate					6.3k 💌			

Precedence	Set codec priority sequence.		
Rate	Set G.723.1 codec with 5.3 or 6.3k mode.		

- T.38 (FAX)

T.38(FAX)				
T.38	Enable			
T.38 Port	9008			
Fax Modem Detection Mode	AUTO 💌			

T.38

Check to enable T.38 function.

Default : Disable

T.	3	8	Ρ	0	r	t
----	---	---	---	---	---	---

Set T.38 port for FAX.

Default : 9008

- DSP - Digital Singnal Process Options

DSP		
	Min delay (ms):	40 🐱
Jitter Buffer Control	Max delay (ms):	130 🕶
	Optimization factor:	7 🗸
Vad	Enable	
	Enable	
Speaker ACC	require level:	1 ~
Speaker AGC	Max gain up: dB	6 ~
	Max gain down: dB	-6 🗸
	Enable	
MICACC	require level:	1 ~
MIC ACC	Max gain up: dB	6 ~
	Max gain down: dB	-6 🗸
Caller ID Mode	DTMF	
FSK Date & Time Sync	Enable	
Reverse Polarity before Caller ID	Enable	
Short Ring before Caller ID	Enable	
Dual Tone before Caller ID	Enable	
Caller ID Prior First Ring	Enable	
Caller ID DTMF Start Digit	DTMF_A	
Caller ID DTMF End Digit	DTMF_C 🗸	
Caller ID Soft FSK Gen	Enable	Hardware caller id only support si3215/3210 slic
Flash Time Setting (ms) [Space:10, Min:30, Max:2000]	100 < Flash Time < 300	
Speaker Voice Gain (dB) [- 32~31],Mute:-32	0	
Mic Voice Gain (dB) [- 32~31],Mute:-32	0	

Vad	Check to enable VAD (Voice Activity Detection) function.
	Default : Disable
Caller ID Mode	Select caller ID mode as FSK (Bellcore), FSK (ETSI), FSK (BT),
	FSK (NTT), or DTMF from Phone to send out.
	Default : DTMF
FSK Date & Time Sync	Check to send FSK Date and Time to caller ID display device.
	Default : Disable
Reverse Polarity before Caller	Check to send reverse polarity before caller ID.
ID	Default : Disable
Short Ring before Caller ID	Check to send short ring before caller ID.
	Default : Disable
Dual Tone before Caller ID	Check to send dual tone before caller ID.
	Default : Disable
Caller ID Prior First Ring	Check to send caller ID before first ring.
	Default : Enable
Caller ID DTMF Start Digit	Set caller ID DTMF start digit.
	Default : DTMF_A
Caller ID DTMF End Digit	Set caller ID DTMF end digit.
	Default : DTMF_C
Flash Time Setting (ms)	Set Minimum and Maximum Flash time.
[Space:10, Min:30, Max:2000]	Default : 200 ~ 500
Speaker Voice Gain (dB)	Set Speaker voice volume.
[-32~31], Mute:-32	Default: 0
Mic Voice Gain (dB) [-32~31],	Set microphone voice gain volume.
Mute:-32	Default: 0

- Hot Line

Hot Line	
Use Hot Line	Enable
Hot Line Number	

Use Hot Line	Hot Line Number
	Default : Disable
Hot Line Number	Set the destination number for Hot Line function.
	Default : Null

- DND (Don't Disturb)

DND (Don't Disturb)		
DND Mode	◯ Always ◯ Enable ⓒ Disable	
From	00 : 00 (hh:mm)	
То	00 : 00 (hh:mm)	

DND Mode	You can select 3 mode of DND. The call will be always rejected if
	Always is selected. The call will be rejected by below Time
	setting (From and To) if Enable is selected. The call will be
	accepted if Disable is selected.
	Default : Disable
From	Set the start time for DND with Enable mode.
	Default : 00:00
То	Set the end time for DND with Enable mode.
	Default : 00:00

- Alarm

Alarm	
Enable	
Time	0 : 0 (hh:mm)

Enable	If set up as Enable, the telephone will ringed up at the specific
	time.
	Default : Disable
Time	It can set up the system prompt time with 24 hours.
	Default : 0:0

Tone

This page is used to configure the Tone Parameters country, or setup the custom tone parameters.

- Select Country

Select Country	
Country	TAIWAN
	Apply

 Country
 User can select country to specify tone parameters (Dial Tone,

 Ring Tone, Busy Tone, and Waiting Tone). If user wants to set
 tone manually, please select CUSTOMER. After selecting

 CUSTOMER, user can assign Custom 1 to 8 for each tone.
 Default : TAIWAN

- Select Country

Select Custom Tone	
Custom Tone	Custom1 💌
Selec	ct Custom tone number to set Tone Parame
Defau	ult : Custom1
	Custom Tone Select Select Select Defa

- Tone Parameters

Tone Paramete	rs	
ToneCycle	CONTINUOUS 🗸	
ToneNum	0 (1~3)	
Freq1	0 (Hz)	
Freq2	0 (Hz)	
Freq3	0 (Hz)	
	Freq3 is supported when SUCC tone type	
Gain1	0 (- dBm)(63~0)	
Gain2	0 (- dBm)(63~0)	
CadNum	0 (1~4)	
CadOn0	0 (msec)	
CadOn1	0 (msec)	
CadOn2	0 (msec)	
CadOn3	0 (msec)	
CadOff0	0 (msec)	
CadOff1	0 (msec)	
CadOff2	0 (msec)	
CadOff3	0 (msec)	
Apply Reset		

Default: 0	
Freq2 Set second set of tone frequency in Hz. This frequency i	S
optional.	
Default: 0	
Gain1Set volume level of Freq1 in dB (-7~-10). Please set this	
parameter under zero and suggested to set between –7	to –10.
Default: 0	
Gain2Set volume level of Freq2 in dB (-7~-10). Please set this	
parameter under zero and suggested to set between -7	to –10.
Default: 0	
CanOn Set cadence time for tone to play in ms. For example	e, if set
CanOn as 100, the tone will be played for 100ms.	
Default: 0	

CanOff	Set cadence time for tone not to play in ms. For example, if set
	CanOff as 100, the tone will stop playing for 100ms.
	Default: 0

Other

This page is used to configure the function key and other parameters.

- Function Key

Function Key	
Must be * + 0~9	
Call Transfer	*1 (default: *1)

Set call transfer function key.

Default: *1

- Dial Option

	Dial Option			
	Auto Dial T	ime	5 (3~9 sec, 0 is disable)	
	Dial-out by Hash Key		Disabled	
Auto Dial Time Set Auto dial time. When user finish input number after		ne. When user finish input number after this time,		
		Router will dial of	but immediately.	
If the call is en not need to wa		If the call is ended by "#", the call will be send immediately and you do		
		not need to wait	for the Auto Dial time.	
		Default: 5		
Dial-out by Hash Key If the "#" symbol is used for other service purpose		I is used for other service purpose, it could disable this		
		option. So that	the dialing number could include the "#" symbol and	
		send to destination side.		
		Default : Enable	9	

- Off-Hook Alarm

Off-Hook Alarm	
Off-Hook Alarm Time	30 (10~60 sec, 0 is disable)

	Default: 30
	time, from phone sett will hear alarm.
Off-Hook Alarm Time	Set off-hook alarm time. If phone set has been off-hook, after this

- FXS Pulse Dial Detection

If your telephone set is pulse type, you can enable this option and define the interdigit pause duration parameters for operation priority.

FXS Pulse Dial Detection	
Option	O Enable O Enable
Interdigit Pause Duration	450 (msec)

SIP QoS

This page is used to configure the parameters for SIP QoS. You can define the DSCP code here for SIP and RTP. Higher DSCP, higher priority. When DSCP is defined, a DSCP will be added in SIP and RTP packets, and the priority of voice should be higher than data.

SIP QoS

This page is used to configure the parameters for SIP QoS.

DSCP Flag	
SIP DSCP	EF (DSCP 0x2e)
RTP DSCP	EF (DSCP 0x2e)

VLAN Tags for Voice and Data	
Use VLAN Tags	Enable
Voice: VLAN ID	1 (1~4090)
Voice: User Priority	7 (0~7)
Voice: CFI	0 (0~1)
Data: VLAN ID	2 (1~4090)
Data: User Priority	0 (0~7)
Data: CFI	0 (0~1)

Apply

Reset



Status

In this page can show the current status and some basic settings of the Router.

Status

This page shows the current status and some basic settings of the device.

System	
Uptime	0 Days 00:39:13
Firmware Version	v1.0b110214
Build Time	Tue Feb 15 14:08:36 CST 2011
WAN Configuration	
Attain IP Protocol	DHCP Client
IP Address	10.1.1.197
Subnet Mask	255.255.255.0
Default Gateway	10.1.1.254
MAC Address	00:30:4f:00:00:01
LAN Link Status	Link Up
LAN Configuration	
Attain IP Protocol	Fixed IP
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
DHCP Server	Enabled
MAC Address	00:30:4f.00:00:02
Wireless Configuration	
Mode	AP
Band	2.4 GHz (B+G+N)
SSID	802.11bgn-SSID
Channel Number	6
Encryption	Disabled
BSSID	00:30:4f:00:00:03
Associated Clients	0
VolP	
Version	1.2.3
Flash Version	2.46
Auto Config Version	0
Firmware Upgrade Version	110214

Statistics

This page shows the packet counters for transmission and reception regarding to Ethernet networks.

Statistics

This page shows the packet counters for transmission and reception regarding to Ethernet networks.

Ethernet WAN		
Sent Packets	539	
Received Packets	10808	
Ethernet LAN		
Sent Packets	1104	
Received Packets	0	

DDNS

Dynamic DNS is a service, which provides you with a valid, unchanging, internet domain name (an URL) to go with that (possibly ever-changing) IP-address. Before setting this page, you should click below link to DynDNS or TZO to apply an account for DDNS.

Dynamic DNS Setting

Dynamic DNS is a service, that provides you with a valid, unchanging, internet domain name (an URL) to go with that (possibly everchanging) IP-address.

Enable DDNS

Service Provider :	DynDNS 🔽
Domain Name :	
User Name/Email:	
Password/Key:	
Note: For TZO, you can ha in <u>control panel</u> For DynDNS, you cau	ve a 30 days free trial <u>here</u> or manage your TZO account n create your DynDNS account <u>here</u>

Apply Change Reset

Enable DDNS	Check to enable DDNS function. User may register to DDNS
	server for DDNS function.
Service Provider	Select which server provider to implement DDNS function. For
	now we provide two servers: DynDNS and TZO.
Domain Name	Input the applied domain name for Router.
User Name/Email	Input user name for DDNS server login.
Password/Key	Input password for DDNS server login.

Time Zone Setting

You can maintain the system time by synchronizing with a public time server over the Internet.

Time Zone Setting

Current Time :	Yr 2000 Mon 1 Day 1 Hr 0 Mn 24	
Current rime .	Sec 25	
Time Zone Select :	(GMT-08:00)Pacific Time (US & Canada); Tijuana	
Enable NTP client update		
Automatically Adjust Daylight Saving		
NTP server :	(Manual IP Setting)	
	Apply Change Reset Refresh	
rent Time	nput current time manually.	
e Zone Select	Select local time zone according to location.	
ble NTP client	Check to enable NTP update. Once this function is enabled,	
ate F	Router will automatically update current time from NTP server.	
server l	Jser may select prefer NTP sever or input address of NTP	

You can maintain the system time by synchronizing with a public time server over the Internet.

Denial-of-Service

A "denial-of-service" (DoS) attack is characterized by an explicit attempt by hackers to prevent legitimate users of a service from using that service.

Denial of Service

A "denial-of-service" (DoS) attack is characterized by an explicit attempt by hackers to prevent legitimate users of a service from using that service.

vvnole System Flood: SYN	0	Dealecta/Second
		Packets/Second
Whole System Flood: FIN	0	Packets/Second
Whole System Flood: UDP	0	Packets/Second
Whole System Flood: ICMP	0	Packets/Second
Per-Source IP Flood: SYN	0	Packets/Second
Per-Source IP Flood: FIN	0	Packets/Second
Per-Source IP Flood: UDP	0	Packets/Second
Per-Source IP Flood: ICMP	0	Packets/Second
TCP/UDP PortScan	Low	Sensitivity
ICMP Smurf		
IP Land		
IP Spoof		
IP TearDrop		
PingOfDeath		
TCP Scan		
TCP SynWithData		
UDP Bomb		
UDP Bomb		
UDP Bomb UDP EchoChargen Select AL	L Clea	ir ALL
UDP Bomb UDP EchoChargen Select AL	L Clea	IT ALL
UDP Bomb UDP EchoChargen Select AL	L Clea	Block time (sec)
UDP Bomb UDP EchoChargen Select AL	L Clea	IF ALL Block time (sec)
UDP Bomb UDP EchoChargen Select AL Enable Source IP Blocking	L Clea	Block time (sec)
UDP Bomb UDP EchoChargen Select AL Enable Source IP Blocking	L Clea	Block time (sec)

SNMP Management

This page is used to configure the parameters for SNMP. SNMP is a widely used protocol for monitoring the health and welfare of network equipment (eg. routers), computer equipment and even devices like UPSs.

SNMP Management

This page is used to configure the parameters for SNMP. SNMP is a widely used protocol for monitoring the health and welfare of network equipment (eg. routers), computer equipment and even devices like UPSs.

SNMP Setup		
SNMP Agent	Disable 🛩	
SNMP Read Community	public	
SNMP Write Community	private	
System Option		
System Name	VIP-281SW	
System Location	PLANET	
Contact	support_voip@planet.com.tw	
Description	VIP-281SW	
SNMP Trap Receiver Configuration		
SNMP Trap	Disable 💌	
SNMP Trap Destination	192.168.0.99	

Apply

Log

This page can be used to set remote log server and show the system log.

System Log

This page can be used to set remote log server and show the system log.

Enable Log		
system all	wireless	DoS
Enable Remote Log	Log Server IP Address:	
	Apply	



Enable Log	Check to enable log function.
System all/Dos	Select which log you want to check. Related information will
	be shown at below.

Upgrade Firmware

This page allows you upgrade the Router firmware to new version. Please note, do not power off the device during the upload because it may crash the system.

Upgrade Firmware

	This page allows yo not power off the dev	u upgrade the Gateway firmware to new version. Please note, do vice during the upload because it may crash the system.
	Select File:	Browse
		Upload Reset
Select File		Browse and select file you want to upgrade and press Upload
		to perform upgrade.
		Please wait till on screen shows related information after
		upgrade finished.

Auto Config

This page is used to configure Auto Config and Auto Update.

- Auto Config

Router supports HTTP, TFTP and FTP auto configuration function in total.

Auto Config		
Mode	⊙ Disable ○ HTTP ○ TFTP ○ FTP	
HTTP Server Address		
HTTP Server Port	80	
TFTP Server Address		
FTP Server Address		
FTP Username		
FTP Password		
File Path		
Expire Time	0 days	
Auto Config Version	0	
Apply	/ Changes Reset	

- Auto Firmware Update

The Router can update new firmware file automatically by the Auto Firmware Update function.

Auto Firmware Update	
Mode	⊙ Off ○ TFTP ○ FTP ○ HTTP
TFTP Server Address	
HTTP Server Address	
HTTP Server Port	80
FTP Server Address	
FTP Username	
FTP Password	
FTP Path	Exp. auto
Check new firmware	● Power On ○ Scheduling ○ Both
Scheduling Day	14 (1~ 30 days)
Scheduling Time	AM 00:00~05:59 🗸
Auto Update	O Automatic Notify Only
File Prefix	ATA2S
Next Update Time	Off
Firmware Version	110214
Apply Reset	

Mode	There are TFTP / FTP and HTTP three ways to provide the auto
	upgrade function.
TFTP Server Address	Input the TFTP Server address, and it could input the IP or
	Domain Name form.
HTTP Server Address	Input the HTTP Server address, and it could input the IP or
	Domain Name form.
HTTP File Path	Set up the file path.
FTP Server Address	Input the FTP Server address, and it could input the IP or
	Domain Name form.
FTP Username	The login username.
FTP Password	The login password
FTP Path	Set up the file path.

Check new firmware	The Router will according to the below ways to check the new
	firmware.
	- Power On: The machine will check the new firmware
	when power on and following the scheduling date and
	time.
	- Scheduling: The machine will follow the scheduling date
	and time to check the new firmware.
Scheduling Day	The Router will check the new firmware every the interval time.
	The range is 1~30 days.
Scheduling Time	The Router will check the new firmware between the time range
	by random.
Automatic Update	There are Notify only and Automatic ways to update.
	- Notify only: If there are new firmware, the Router will
	send the "Be Be Be" sounds when pick up the handset to
	prompt there are new firmware.
	- Automatic: The Router will carry firmware update out
	automatically.
File Prefix	It will check the information of model name.
Next update time	It will show the next check date and time.
Firmware Version	The current firmware version, the Router is use this value to
	decide if there is newer firmware version fo upgrading.

Save / Reload Settings

This page allows you save current settings to a file or reload the settings from the file which was saved previously. Besides, you could reset the current configuration to factory default.

Save/Reload Settings

This page allows you save current settings to a file or reload the settings from the file which was saved previously. Besides, you could reset the current configuration to factory default.

Save Settings to File:	Save
Load Settings from File:	Browse Upload
Reset Settings to Default:	Reset

Save Settings to File	Save current settings to a file.
Load Settings from File	Browse a file and upload to reload settings.
Reset Settings to Default	Press Reset will clean all current configurations and return to default values.

Password Setup

This page is used to set the account to access the web server of Router. Empty user name and password will disable the protection.

Password Setup

This page is used to set the account to access the web server of Gateway. Empty user name and password will disable the protection.

User Name:	
New Password:	
Confirmed Password:	
<u> </u>	Apply Reset

User Name	Enter user name.
New Password	Input password for this user.
Confirmed Password	Confirm password again.



Ping Watchdog Setup

This page is used to configure the parameters for Ping Watchdog which pings to IP address every time interval. System will reboot when failing to ping the IP address 3 times.

Ping Watchdog Setup

This page is used to configure the parameters for Ping Watchdog which pings to IP address every time interval. System will reboot when failing to ping the IP address 3 times.

Enable Ping Watchdog				
IP Address:				
Ping Count:	3	times (1~100)		
Time Interval:	5	minutes (1~15)		

Apply	Re

Ping Test

This page is used to configure the parameters for Ping Test which pings to IP address or Domain Name.

Reset

Ping Test

This page is used to configure the parameters for Ping Test which pings to IP address or Domain Name.





Refresh

Traceroute

This page is used to configure the parameters for Traceroute which traces to IP address or Domain Name.

Traceroute

This page is used to configure the parameters for Traceroute which traces to $\ensuremath{\mathsf{IP}}$ address or Domain Name.

IP Address:	Test	Clear Message	



Reboot

Press Reboot to reboot system. Please wait for a few minutes and reload web page again.

System Reboot

Press Reboot to reboot system.Please wait for a few time and reload web page again.

Reboot

Logout

This page is used to logout.

Logout

This page is used to logout.

Do you want to logout ?

Apply

Appendix A Voice communication samples

There are several ways to make calls to desired destination in Router. In this section, we'll lead you step by step to establish your first voice communication via keypad and web browsers operations.

Peer to peer (P2P) mode

Assuming there are two routers in the network, the WAN port IP address are 192.168.0.1 and 192.168.0.2



Test the scenario:

- 1. To Phone A: Other Phone dials "192*168*0*1#".
- 2. To Phone B: Other Phone dials "192*168*0*1**5062#".
- 3. To Phone C: Other Phone dials "192*168*0*2#".
- 4. To Phone D: Other Phone dials "192*168*0*2**5062#".

 If the IP address of the remote calling party is known, you may directly make calls by preset number via its IP address and end with "#".

(i) Hint

- If the VoIP Router is installed behind a NAT/firewall/ IP sharing device, please make sure the NAT device support SIP applications before making calls.
- The voice communication need to go through via WAN port of router, so it needs to make sure the WAN port connector is properly for communication.

Case 2: (Peer-to-Peer mode) VIP-281SW Port 1 to Port 2 communications

Supposing one VIP-281SW connects to two telephones, just pick up phone 1 and dial

'192*168*0*1**5062', phone 2 will ring.

Analog telephone sets are connected to the phone (RJ-11) ports of VIP-281SW respectively



Test the scenario:

(i) Hint

- 1. Pick up the telephone set on Phone 1, and you should be able to hear the dial-tone
- 2. Press the keypad: **192*168*0*1**5062#** shall be able to connect to the Phone 2
- 3. Then the telephone set in Phone 2 should ring.
- 4. The Phone 2 also could dial "**192*****168*****0*****1**#" (without ****5062**) to Phone 1 to establish the voice communication.
 - If the IP address of the remote calling party is known, you may directly make calls via its IP address and end with "#".
 - If the router are installed behind a NAT/firewall/IP sharing device for Peer-to-Peer VoIP application, please make sure the NAT device support SIP applications, and suitable settings should be applied to the NAT device to enable the SIP communications before making calls
 - [VIP-281SW] in PLANET Router series products, to connect to remote Router, press the keypad in the following sequence to connect to the remote VIP-281SW port 2: [Remote Router IP address]**5062, for example:

192*168*0*2**5062

Case 3: SIP Proxy mode

In this example, there are two Routers register to UMG-2000 via wireless connection. The telephone set could dial the extension number to each other.



STEP 1:

Log in UMG-2000 and create four testing accounts: **5001 ~ 5004** (password same as number) for Router-A and Router-B. To enable the Wireless AP Service on UMG-2000 for wireless connection between Router-A and Router-B.

💫 Overview	🔏 Settings	Clients	Ø Block List			
Wireless Network Setting	js					
Access Point (AP)	• Enable	O Disable		Wireless Mode	802.11b/g/n	~
Hide SSID	O Enable	() Disable		Authentication Type	Open System	*
Network Name (SSID)	UMG_WIFI			Data Encryption	None	*
Wireless Region	Asia	~				
Channel	6	~				

STEP 2:

Please log in Router-A via web browser, access to "Wireless Basic Settings" page to switch to **Client** mode, and fill in the SSID of UMG-2000 (UMG_WIFI). In the setting page, please insert the account/password information obtained from your service provider (in this sample, we're using PLANET UMG-2000 as the IP PBX server for SIP account, call authentications), and then the sample configuration screen is shown below:

Disable Wireless LAN Interface				
Band:	2.4 GHz (B+G+N) 💙			
Mode:	Client V Multiple AP			
Network Type:	Infrastructure 👻			
SSID:	UMG_WIFI			
Channel Width:	20MHz ~			
Control Sideband:	Upper 🗸			
Channel Number:	6 😽			
Broadcast SSID:	Enabled 💌			
WMM:	Enabled V			
Data Rate:	Auto 🗸			
Associated Clients:	Show Active Clients			
Enable Mac Clone (Single Ethernet Client)				
Enable Universal Repeater Mode (Acting as AP and client simultaneouly)				
SSID of Extended Interface:				

It also could access to "Wireless Site Survey" menu to survey the wireless access connection and connect to UMG-2000.

Wireless Site Survey

This page provides tool to scan the wireless network. If any Access Point or IBSS is found, you could choose to connect it manually when client mode is enabled.

SSID	BSSID	Channel	Туре	Encrypt	Signal	Select
UMG_WIFI	00:30:4f:0e:3d:81	6 (B+G+N)	AP	no	56	۲
	Refresh	Connect				

STEP 3:

To assign the LAN port network parameters as 172.16.0.1 (IP Address) / 255.255.0.0 (Subnet Mask).

LAN Port Setup	
IP Address:	172.16.0.1
Subnet Mask:	255.255.0.0
DHCP Server:	Disabled V
DHCP Client Range:	192.168.0.100 - 192.168.0.200 Show Client
Static DHCP:	Disabled V Set Static DHCP
Domain Name:	
802.1d Spanning Tree:	Disabled V
Clone MAC Address:	0000000000

STEP 4:

Please log in Router-A via web browser, find to the **SIP** item. In the setting page, please insert the account/password information obtained from your service provider (in this sample, we're using PLANET UMG-2000 as the IP PBX server for SIP account, call authentications), and then the sample configuration screen is shown below:

Realm 1	
Display Name	5001
Line Number	5001
Register Name	5001
Register Password	••••
Ргоху	✓ Enable
Proxy Server	172.16.0.50
Proxy Port	5060
Domain Server	
SIP Expire Time	60
Outbound Proxy	Enable
Outbound Proxy Server	
Outbound Proxy Port	5060
Nortel SoftSwitch	Enable
Register Status	Registered

STEP 5:

Repeat the same configuration steps on Router-B, and check the machine registration status, make sure the registrations are completed.

STEP 6:

To verify the VoIP communication, please pick up the telephone. Dial the destination number to make call between SIP clients. For example, FXS 1 of Router-A (with number 5001) with keypad number 5003 to the FXS 1 of Router-B, or reversely makes calls from SIP client (Router-B) to the number 5001 (FXS 1 of Router-A).

Case 4: Call Forward Feature

In the following samples, we'll introduce the Call Forward Feature applications.

In this example, both Routers register to UMG-2000 and FXS 2 of Router_A had set Call Forward function to FXS1 of Router_B.



Machine configuration on the Router:

Please log in Router_A via web browser, browse to the **Phone 2** menu and select the **Call Forward** config menu. In the setting page, please enable the **All Forward** function and fill in the number of FXS 1 of Router_B (5003) in **All Fwd No.** field, then the sample configuration screen is shown below:

Phone 2 Settings

This page is used to configure the parameters for SIP registration information. Here you also could setup the other functions like Call Forward, Voice Codec, Speed Dial and others.

Service Domain Call Forward	Dial Plan Advanced Cod	ec DSP Others
Call Forward		
All Forward	Off ⊙ VoIP	
All Fwd No.	5003	
Busy Forward	⊙ Off O VoIP	
Busy Number		
No Answer Forward to	⊙ Off ◯ VoIP	
No Answer Number		
No Answer Time (sec)	0	

Test the scenario:

- 1. FXS 1 of Router_A (ext.5001) pick up the telephone
- 2. Dial the number 5002 (FXS 2 of Router _A),
- Because FXS 2 of Router _A had set up All Forward function to the number 5003(FXS 1 of Router _B)
- 4. The number **5003** (FXS 1 of Router_B) will ring up then it pick up the telephone and communication with the number 5001

Case 5: VIP-281SW register with IPX-1900 via WAN port

In this example, the VIP-281SW registered with IPX-1900 via WAN port, and has VoIP communications with VIP-360PT.



STEP 1:

Log in IPX-1900 and create three testing accounts: $101 \sim 103$ (password same as number) for VIP-281SW and VIP-360PT.

Jser Extensions Setting			
Add New User Extensions	Add Batch		
Extensions List Extension	sion Max is 300 Password	Caller Id	Action
101	101		
101	101	101	Advance Delete
102	101	101	Advance Delete

STEP 2:

Please log in VIP-281SW via web browser, access to "WAN Interface Setup" page to setup the WAN port network parameters for connect with IPX-1900.

WAN Interface Setup

This page is used to configure the parameters for Internet network which connects to the WAN port of your Gateway. Here you may change the access method to static IP, DHCP, PPPoE, PPTP or L2TP by click the item value of WAN Access type.

WAN Access Type:	Static IP 💌
IP Address:	172.16.0.10
Subnet Mask:	255.255.0.0
Default Gateway:	172.16.0.1
MTU Size:	1412 (1400-1500 bytes)
DNS 1:	168.95.192.1
DNS 2:	168.95.1.1
DNS 3:	

STEP 3:

Please access to the **SIP** item. In the setting page, please insert the account/password information obtained from your service provider (in this sample, we're using PLANET IPX-1900 as the IP PBX server for SIP account, call authentications), and then the sample configuration screen is shown below:

Realm 1		
Display Name	101	
Line Number	101	
Register Name	101	
Register Password	•••	
Ргоху	✓ Enable	
Proxy Server	172.16.0.1	
Proxy Port	5060	
Domain Server		
SIP Expire Time	60	
Outbound Proxy	Enable	
Outbound Proxy Server		
Outbound Proxy Port	5060	
Nortel SoftSwitch	Enable	
Register Status	Registered	

STEP 5:

Please log in VIP-360PT and access to "VOIP" page. According to the SIP account information to fill in the correspondence fields for registering with IPX-1900.
BASIC	
VOIP	
PHONE	
MAINTENANO	ΞE
SECURITY	
LOGOUT	

VOIP				
SIP IAX2	SIP IAX2 STUN DIAL PEER			
SIP Line Select	t			
SIP 1 💌		Load		
Basic Setting				
Register Status	Registered		Display Name	103
Server Name	103		Proxy Server Address	
Server Address	172.16.0.1		Proxy Server Port	
Server Port	5060		Proxy Username	
Account Name	103		Proxy Password	
Password	•••		Domain Realm	
Phone Number	103		Enable Register	
APPLY				
Advanced Set				

STEP 6:

To verify the VoIP communication, please pick up the telephone. Dial the destination number to make call between SIP clients. For example, FXS 1 of VIP-281SW with keypad number 103 to the VIP-360PT. Or reversely makes calls from VIP-360PT SIP client to the number 101 (FXS 1 of VIP-281SW).

Case 6: VIP-281SW register with UMG-2000 via WAN port

In this example, the Router-A and Router-B (VIP-281SW) registered with UMG-2000 via WAN port, and has VoIP communications with VIP-360PT that registered with LAN port of UMG-2000.



STEP 1:

Log in UMG-2000 and create three testing accounts: **5001** ~ **5005** (password same as number) for Router-A, Router-B and VIP-360PT.

STEP 2:

Please log in VIP-281SW via web browser, access to "WAN Interface Setup" page to setup the WAN port network parameters for connect with UMG-2000.

WAN Access Type:	Static IP 🗸
IP Address:	192.168.0.10
Subnet Mask:	255.255.255.0
Default Gateway:	192.168.0.254
MTU Size:	1412 (1400-1500 bytes)
DNS 1:	168.95.192.1
DNS 2:	168.95.1.1
DNS 3:	

STEP 3:

Please access to the SIP item. In the setting page, please insert the account/password information

obtained from your service provider (in this sample, we're using PLANET UMG-2000 as the IP PBX server for SIP account, call authentications), and then the sample configuration screen is shown below:

Realm 1	
Display Name	5001
Line Number	5001
Register Name	5001
Register Password	••••
Ргоху	Enable
Proxy Server	192.168.0.1
Proxy Port	5060
Domain Server	
SIP Expire Time	60
Outbound Proxy	Enable
Outbound Proxy Server	
Outbound Proxy Port	5060
Nortel SoftSwitch	Enable
Register Status	Registered

STEP 5:

Please log in VIP-360PT and access to "VOIP" page. According to the SIP account information to fill in the correspondence fields for registering with UMG-2000.

SIP IAX2 STUN DIAL PEER				
SIP Line Select				
SIP 1 ¥		Load		
Basic Setting				
Register Status	Registered		Display Name	5005
Server Name	5005		Proxy Server Address	
Server Address	192.168.1.1		Proxy Server Port	
Server Port	5060		Proxy Username	
Account Name	5005		Proxy Password	
Password	••••		Domain Realm	
Phone Number	5005		Enable Register	
APPLY				

STEP 6:

To verify the VoIP communication, please pick up the telephone. Dial the destination number to make call between SIP clients. For example, FXS 1 of Router-A with keypad number **5005** to the VIP-360PT. Or reversely makes calls from VIP-360PT SIP client to the number **5001** (FXS 1 of Router-A).

Appendix B The method of featured voice operation guide

In this section, we'll introduce the features method of operation, and lead you step by step to establish these features.

Call Transfer

A. Blind Transfer

- 1. B call to A and they are in the process of conversation.
- 2. A carry the transfer function out (Press *1 button) to hold the conversation with B.
- 3. A will hear the dial tone then input the number of C (Follow by the "#" key).
- 4. C will ring up then A hang up the handset.
- 5. C picks up the handset and conversation with B.

B. Attendant Transfer

- 1. B call to A and they are in the process of conversation.
- 2. A carry the transfer function out (Press *1 button) to hold the conversation with B.
- 3. A will hear the dial tone then input the number of C (Follow by the "#" key).
- 4. C will ring up.
- 5. C picks up the handset and conversation with A.
- 6. A hang up and C conversation with B.

3-Way Conference

- 1. A and B are in the process of conversation.
- 2. A want to invite C to join their conversation.
- 3. A press "**Flash**" button on telephone to hold the conversation with B at first and hear the dial tone, then input the number of C (Follow by the "**#**" key).
- 4. C will ring up and pick up the handset to conversation with A.
- 5. A press "Flash" button again, and they will entry the 3-Way conference mode.

Call Waiting

- 1. A and B are in the process of conversation.
- 2. C call to A and A will hear the prompt sounds.
- 3. A press "Flash" button to hold the conversation with B, and switch to conversation with C.

Switch the Default Proxy

Router can register to two different SIP Proxies at the same time. It can receive any one of different SIP accounts incoming call, and it can switch to any one SIP accounts for making calls through

input the switch code.

Realm switch code: #1500#: Realm 1

#1501#: Realm 2

For example: The default is Realm 1, input the **#1501#** from keypad and hang up the telephone set. It will switch to Realm 2 can make the SIP calls via Realm 2.

Auto Update firmware by manual (Keypad)

If pick up the handset of Router, it will hear the "DoDoDo" prompt. If want to carry out the upgrade action, please input"#190#" to unlock the device at first. Then input"#160#" to upgrade the new firmware.

Appendix C Frequently Asked Questions List

If your SIP Router is not functioning properly, you can refer to this chapter first for sample troubleshooting before contacting your dealer. This can save your time and effort but if the symptoms persist, please consult your dealer.

Q1: I forget my Router login username and / or password

A1:

1.) Restore Router to its factory default settings by pressing the "Reset" button which is at the side panel of the device for 5 seconds or more.

Q2: Non of the LEDs are on when I turn on the SIP Router

A2:

- 1.) Check if power cord is connected properly.
- 2.) Check if there is proper AC power coming from the power outlet.
- Q3: Why can't I dial my friend's SIP number?

A3:

- 1.) Check SIP Server Domain Name/IP address. Make sure you have the right Name or IP address.
- 2.) Check the web browser and access the configuration menu. Make sure that the SIP Server Domain Name/IP Address is correct.
- 3.) Check the register status under SIP Account Settings in the configuration menu (from web browser). If your status is "Not Registered, it means you do not have a SIP account. Contact your SIP service provider to get an account.

Q4: How to know the machine IP address?

A4:

- 1.) To pick up the telephone set, and key in #120#.
- 2.) Machine will prompt the current LAN port IP address.

Appendix D Router Specifications

Product	802.11n Wireless VoIP Router	
Model	VIP-281SW	
Hardware		
WLAN Standards	IEEE 802.11 b/g/n	
Wireless Frequency Range	2.4GHz ~ 2.4835 GHz	
Wireless Mode	AP, Client, WDS and AP+WDS mode	
Security	64/128 bit WEP data encryption, WPA, WPA-PSK, WPA2, WPA2-PSK,	
	WPA/WPA2 mix mode, 802.1x encryption and WPS PBC	
Operating Frequencies / Channel	USA/Canada: 2.412 GHz – 2.426 GHz (11 channels) Europe: 2.412 GHz – 2.472 GHz (13 channels) Japan: 2.412 GHz – 2.477 GHz (14 channels)	
Wireless Data Rate	IEEE 802.11b: CCK (11Mbps,5.5Mbps), DQPSK (2Mbps), DBPSK (1Mbps) IEEE 802.11g: OFDM (54Mbps, 48Mbps, 36Mbps, 24Mbps, 18Mbps, 12Mbps, 9Mbps, 6Mbps) IEEE 802.11n: 14/29/43/58/87/116/130/144Mps in 20MHz, 30/60/90/120/180/240/270/300Mbps in 40MHz	
Transmit Power	802.11b: 17dBm, 802.11g: 15dBm, 802.11n: 13dBm	
Receiver Sensitivity	802.11b: -86dBm @11M, 802.11g: -72dBm @54M 802.11n (20MHz): -68dBm, 802.11n (40MHz): -66dBm	
Antenna	2 x 2dBi Detachable Antenna	
WDS	WDS repeater support	
WAN	1 x 10/100 Base-TX RJ-45 port	
LAN	4 x 10/100 Base-TX RJ-45 port	
FXS (for telephone set connection)	2 x RJ-11 connection	
Protocols and Standard		
Standard	SIP 2.0 (RFC3261), SDP (RFC 2327), Symmetric RTP, STUN (RFC 3489), , ENUM (RFC 2916), RTP Payload for DTMF Digits (RFC2833), Outbound Proxy Support, UPnP (UPnPTM)	
Voice codec	G.711(A-law /µ-law), G.729 AB, G.723 (6.3 Kbps / 5.3Kbps), G.276 (16,24,32,40 Kbps), GSM and G.722	
Fax support*	T.38 (G.711 Fax pass-through)	
Voice Standard	VAD (Voice Activity Detection) CNG (Comfort Noise Generation) G.168: LEC (Line Echo Canceller) Dynamic Jitter Buffer In-band and out-of-band DTMF Relay (RFC 2833) Caller ID Detection/Generation: DTMF, BELLCORE, ETSI, BT, NTT	
Protocols	SIP 2.0 (RFC-3261), TCP/IP, UDP/RTP/RTCP, HTTP, ICMP, ARP, DNS, DHCP, NTP/SNTP, PPP, PPPoE	
Internet features	NAT router, DHCP server, Static routing, Virtual server, Virtual DMZ, Smart QoS, IP ToS (IP Precedance) / DiffServ	
Security	Built-in NAT Firewall MAC / IP / Port Filtering URL Filtering Port Forwarding, DMZ Password protection for system management	
Network and Configuration		
Access Mode	Static IP, PPPoE, DHCP	
Configuration & Management	Web-Based Graphical User Interface Remote management over the IP Network	
	vveb-Based firmware upgrade Backup and Restore Configuration file	

	SNMP v1/v2, Auto-Provision, Keypad on telephone set
Dimension (W x D x H)	186 x 143 x 35 mm
Operating Environment	0~50 Degree C, 5~90% humidity
Power Requirement	12V DC
EMC/EMI	CE, FCC Part 15 Class B