

User's Manual

ADSL 2/2+ Router with USB port

ADE-3410



Copyright

Copyright© 2011 by PLANET Technology Corp. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of PLANET.

PLANET makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not this company, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, this company reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

All brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio technician for help.

FCC Caution

To assure continued compliance (example-use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the Following two conditions: (1) This device may not cause harmful interference, and (2) this Device must accept any interference received, including interference that may cause undesired operation.

Federal Communication Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20 cm (8 inches) during normal operation.

R&TTE Compliance Statement

This equipment complies with all the requirements of DIRECTIVE 1999/5/EC OF THE EUROPEAN PARLIAMENT AND THE COUNCIL OF 9 March 1999 on radio equipment and telecommunication terminal Equipment and the mutual recognition of their conformity (R&TTE)

The R&TTE Directive repeals and replaces in the directive 98/13/EEC (Telecommunications Terminal Equipment and Satellite Earth Station Equipment) As of April 8, 2000.

WEEE Regulation



To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Safety

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacture must therefore be allowed at all times to ensure the safe use of the equipment.

Revision

User's Manual for Wired ADSL 2/2+ Router with USB Port

Model: ADE-3410v5

Rev: 1.0 (June. 2011)

Part No. EM-ADE3410v5

Table of Contents

1. INTRODUCTION	7
1.1 Feature	7
1.2 Package Contents	9
1.3 Physical Details	9
2. INSTALLATION	12
2.1 System Requirement.....	12
2.2 Hardware Installation	12
2.3 Configuring the Network Properties.....	13
3. WEB CONFIGURATION MANAGEMENT.....	17
3.1 Access the Router	17
3.2 Wizard.....	18
3.3 Status	24
3.3.1System.....	24
3.3.2 LAN	24
3.3.3 WAN.....	25
3.3.4 Port Mapping	25
3.3.5 Statistics	25
3.3.6 ARP Table	26
3.4 Network	27
3.4.1 LAN.....	27
3.4.2 WAN.....	32
3.5 Service.....	35
3.5.1 DNS.....	35
3.5.2 Firewall	37
3.5.3 UPNP	41
3.5.4 IGMP Proxy	41
3.5.5 TR-069	41
3.5.6 ACL.....	42
3.6 Advance	44
3.6.1 Bridge Setting.....	44
3.6.2 Routing.....	45

3.6.3 Port Mapping	47
3.6.4 QoS	47
3.6.5 SNMP	50
3.6.6 Others	51
3.7 Admin	51
3.7.1 Commit/Reboot	51
3.7.2 Upgrade	51
3.7.3 System Log	51
3.7.4 Password	52
3.7.5 Time Zone	52
3.8 Diagnostic	53
3.8.1 Ping	53
3.8.2 Ping6	53
3.8.3 ATM Loopback	53
3.8.4 ADSL	54
3.8.5 Diagnostic Test	54
APPENDIX A: GLOSSARY	55

1. Introduction

The PLANET Wired ADSL 2/2+ Router, the ADE-3410, provides office and residential users the ideal solution for sharing a High-Speed ADSL 2/2+ broadband Internet connection on the 10/100Mbps Fast Ethernet Interface. It can support downstream transmission rates up to 24Mbps and upstream transmission rates up to 3.5Mbps. The product supports PPPoA (RFC 2364 - PPP over ATM Adaptation Layer 5), PPP over Ethernet (RFC 2516), and RFC 1483 encapsulation over ATM (MER, bridged or routed) to establish a connection with ISP.

Via the user-friendly management interface, the ADE-3410 can be managed by workstations running standard web browsers. Furthermore, the device provides DHCP server, NAT, Virtual Server, DMZ, access control, IP filter, VPN Pass-Through, and UPnP capability.

The device also serves as an Internet firewall, protecting your network from being accessed by outside users. It provides the natural firewall function (Network Address Translation, NAT). All incoming and outgoing IPs are monitored and filtered by this product. In addition, it can be configured to block internal users from accessing to the Internet.

1.1 Feature

Internet Access Features

- ♦ **Shared Internet Access**

All users on the LAN can access the Internet through the ADE-3410 using only a single external IP Address. The local (invalid) IP Addresses are hidden from external sources. This process is called NAT (Network Address Translation).

- ♦ **Built-in ADSL 2/2+ Modem**

The device provides ADSL 2/2+ modem, and supports all common ADSL connections.

- ♦ **PPPoE, PPPoA, Direct Connection Support**

Various WAN connections are supported by ADE-3410.

- ♦ **Auto-detection of Internet Connection Method**

In most situations, the device can test your ADSL and Internet connection to determine the connection method used by your ISP.

- ♦ **Fixed or Dynamic IP Address**

On the Internet (WAN port) connection, the device supports both Dynamic IP Address (IP Address is allocated on connection) and Fixed IP Address.

Advanced Internet Functions

- ♦ **Virtual Servers**

This feature allows Internet users to access Internet servers on your LAN. The required setup is quick and easy.

- ♦ **DMZ Support**

The device can translate public IP addresses to private IP address to allow unrestricted 2-way communication with Servers or individual users on the Internet. This provides the most flexibility to run programs, which could be incompatible in NAT environment.

- ♦ **Firewall**

Supports simple firewall with NAT technology and provides option for blocking access from Internet, like Web, FTP, Telnet, SNMP, and ICMP. It also supports MAC and IP filtering.

- ♦ **Universal Plug and Play (UPnP)**

UPnP allows automatic discovery and configuration of the Broadband Router. UPnP is supported by Windows ME, XP, or later.

- ♦ **VPN Pass through Support**

PCs with VPN (Virtual Private Networking) software are transparently supported - no configuration is required.

- ♦ **RIP1/2 Routing**

It supports RIPv1/2 routing protocol for routing capability.

- ♦ **Simple Network Management Protocol (SNMP)**

It is an easy way to remotely manage the router via SNMP.

LAN Features

- ♦ **Dual-Port**

The ADE-3410 incorporates on one Ethernet port and one USB port, made to easily create or extend your LAN.

- ♦ **DHCP Server Support**


Dynamic **H**ost **C**onfiguration **P**rotocol provides a dynamic IP address to PCs and other devices upon request. The device can act as a DHCP Server for devices on your local LAN.

1.2 Package Contents

- ADE-3410 Unit x 1
- Power Adapter x 1
- Quick Installation Guide x 1
- User's Manual CD x 1
- RJ-11 cable x 2
- RJ-45 cable x 1
- USB cable x 1
- Splitter x 1

1.3 Physical Details


Front Panel of ADE-3410



Front Panel LED definition

LED	State	Description
PWR	ON	When the router is powered on and in ready state
	Red	The devise is being turned on and booting
	OFF	When the router is powered off
Link	ON	Successful connection between ADSL modem and telecom's network
	Flashing	Modem is trying to establish a connection to telecom's network
Data	Flashing	Data is transferred between Router and Internet
LAN	ON	Link
	Flashing	TX or RX activity

Rear Panel of ADE-3410



Rear Panel Port and Button Definition

Connector	Description
POWER Button	The power button is for turn on or turns off the router
Power	Power connector with 5V DC, 1A
Reset	The reset button can restore the default settings of device. To restore factory defaults, keep the device powered on and push a paper clip into the hole. Press down the button over 5 seconds and then release
Ethernet	Router is successfully connected to a device through the Ethernet port. If the LED is flashing, the Router is actively sending or receiving data over that port
USB	Connect the supplied USB cable to this port when connecting to the PC
Line	The RJ-11 connector allows data communication between the modem and the ADSL network through a twisted-pair phone wire

2. Installation

This chapter offers information about installing your router. If you are not familiar with the hardware or software parameters presented here, please consult your service provider for the values needed.

2.1 System Requirement

1. Personal computer (PC)
2. Pentium III 266 MHz processor or higher
3. 128 MB RAM minimum
4. 20 MB of free disk space minimum
5. RJ45 Ethernet Port

2.2 Hardware Installation

Please connect the device to you computer as follow:

- If connecting to the splitter, connect the “Line” splitter to wall jack using one telephone cable
- Use another telephone cable to connect “MODEM” port of the splitter and “LINE” port of the modem. The “Phone” port of the splitter can be use to connect the telephone by a telephone cable.
- Use Ethernet cable to connect “LAN” port of the modem and “LAN” port of your computer.

Connect ADE-3410 to the PC's USB port as follow:

- Connect the USB cable to USB port of ADE-3410. The cable has two different connectors.
- Connect the other end of the USB cable to PC's USB port.




Figure1 ADE-3410 connection diagram


If do not need to connect to the splitter,

- Connect the modem to wall jack with a telephone cable.
- Use Ethernet cable to connect “LAN” port of the modem and network adaptor of your computer.


2.3 Configuring the Network Properties

Configuring PC in Windows XP


1. Go to **Start / Control Panel (in Classic View)**. In the Control Panel, double-click on **Network Connections**
2. Double-click **Local Area Connection**.




3. In the **Local Area Connection Status** window, click **Properties**.



4. Select **Internet Protocol (TCP/IP)** and click **Properties**.




5. Select the **Obtain an IP address automatically** and the **Obtain DNS server address automatically** radio buttons.
6. Click **OK** to finish the configuration.




Configuring PC in Windows 2000

1. Go to **Start / Settings / Control Panel**. In the Control Panel, double-click on **Network and Dial-up Connections**.
2. Double-click **Local Area Connection**.




3. In the **Local Area Connection Status** window click **Properties**.
4. Select **Internet Protocol (TCP/IP)** and click **Properties**.
5. Select the **Obtain an IP address automatically** and the **Obtain DNS server address automatically** radio buttons.
6. Click **OK** to finish the configuration.




Configuring PC in Windows 98/Me

1. Go to **Start / Settings / Control Panel**. In the Control Panel, double-click on **Network** and choose the **Configuration** tab.
2. Select **TCP/IP → NE2000 Compatible**, or the name of your Network Interface Card (NIC) in your PC.



3. Select the **Obtain an IP address automatically** radio button.
4. Then select the **DNS Configuration** tab.
5. Select the **Disable DNS** radio button and click **OK** to finish the configuration.



3. Web Configuration Management

This chapter describes how to configure the router by using the Web-based configuration utility.

3.1 Access the Router

The following is the detailed description of accessing the router for the first time.

Step 1: Open the Internet Explorer (IE) browser and enter <http://192.168.1.1>.

Step 2: In the **Login** page that is displayed, enter the username and password.

- The username and password of the super user are **admin** and **admin**.
- The username and password of the common user are **user** and **user**.



If you log in as a super user, the page shown in the following figure appears. You can check, configure and modify all the settings.




Figure 1

If you log in as a common user, you can check the status of the router, but can not configure the most of the settings.



Note:

In the Web configuration page, you can click **Apply Changes** to save the settings temporarily. If you want to save the settings of this page permanently, clicks save of **Attention** that appears at the button of the Web page after the configuration.

3.2 Wizard

The **Wizard** page guides fast and accurate configuration of the Internet connection and other important parameters. The following sections describe these various configuration parameters. Whether you configure these parameters or use the default ones, click **NEXT** to enable your Internet connection.

When subscribing to a broadband service, you should be aware of the method by which you are connected to the Internet. Your physical WAN device can be either PPP, ADSL, or both. The technical information about the properties of your Internet connection is provided by your Internet Service Provider (ISP). For example, your ISP should inform you whether you are connected to the Internet using a static or dynamic IP address, and the protocol that you use to communicate on the Internet.

In the navigation bar, click **Wizard**. The page shown in the following figure appears.

The screenshot shows the Planet ADSL 2/2+ Router web interface. The top navigation bar includes links for Wizard, Status, Network, Service, Advance, Admin, and Diagnostic. The main content area is titled "Wizard" and contains instructions for configuring the device. It lists four steps: Step 1: Web Account Setup, Step 2: Time Zone Setup, Step 3: WAN Interface Setup, and Step 4: Configuration Saving. The current step is "Step 1: Web Account Setup", which prompts the user to set a new account for accessing the Web server. It includes input fields for "User Name" (with a dropdown menu showing "admin"), "New Password", and "Confirmed Password". A "Next" button is located at the bottom right of the form.

The following table describes the parameters of this page:

Field	Description
User Name	Choose the user name for accessing the router. You can choose admin or user
New Password	Enter the password to which you want to change the old password. The password can not contain space key, %, ", ? or &
Confirmed Password	Enter the new password again

After finishing the configuration, click **NEXT**. The page shown in the following figure appears. In this page, you can configure the system time and Network Time Protocol (NTP) server.

The screenshot shows the Planet ADSL 2/2+ Router web interface, specifically the "Step 2: Time Zone Setup" page. The navigation bar is the same as in the previous screenshot. The main content area is titled "Step 2: Time Zone Setup" and prompts the user to set up the system time and the Network Time Protocol (NTP) server. It includes a section for "NTP Configuration" with options for "State" (Disable or Enable), "Server IP" (220.130.158.52), "Interval" (Every 1 hours), "Time Zone" (GMT, Gambia, Liberia, Morocco, England), and "GMT time" (Thu Jan 1 22:8:7 1970). "Back" and "Next" buttons are located at the bottom of the form.

The following table describes the parameters of this page:

Field	Description
State	You can disable or enable NTP function. You have to enable it if you want to configure the parameters of this page
Server IP	Enter the IP address of the specified time server manually
Interval	Set the interval that the router obtains the time from the time server. That is, the interval that the router verifies the time with the server
Time Zone	Choose the time zone in which area you are from the drop down list
GMT time	It displays the Greenwich Mean Time (GMT)

After finishing the configuration, click **NEXT**. The page shown in the following figure appears.

PLANET Networking & Communication **ADSL 2/2+ Router**

Wizard Status Network Service Advance Admin Diagnostic

Wizard

Step 3: WAN Interface Setup
Set up the channel mode of WAN interface.

PVC Setting: VPI: (0-255) VCI: (32-65535)

Encapsulation: ☒ LLC/SNAP ☐ VC-Mux

Channel Mode: ☐ 1483 Bridged
☐ 1483 MER
☒ PPPoE
☐ PPPoA
☐ 1483 Routed

PPP Settings: User Name: Password:

Default Route: ☒ Enable ☐ Disable

DNS Settings: ☒ Obtain DNS Automatically
☐ Use the following DNS server address:
Primary DNS Server:
Secondary DNS Server:

There are five channel modes, the following describes them respectively.

1483 Bridged

In the **Setup WAN Interface** page, enter the correct PVC, set the channel mode to **1483 Bridged**.

PLANET Networking & Communication **ADSL 2/2+ Router**

Wizard Status Network Service Advance Admin Diagnostic

Wizard

Step 3: WAN Interface Setup
Set up the channel mode of WAN interface.

PVC Setting: VPI: (0-255) VCI: (32-65535)

Encapsulation: ☒ LLC/SNAP ☐ VC-Mux

Channel Mode: ☒ 1483 Bridged
☐ 1483 MER
☐ PPPoE
☐ PPPoA
☐ 1483 Routed

Click **NEXT**, and the page shown in the following figure appears.

If you want to modify the configuration, click **BACK** to return to the previous page. If you ensure the configuration is correct, click **FINISH** to take the configuration effect.

1483 MER

In the **Setup WAN Interface** page, enter the correct PVC, set the channel mode to **1483 MER**.

The following table describes the parameters of this page:

Field	Description
PVC Settings	<ul style="list-style-type: none"> ● VPI: Virtual Path Identifier (VPI) is the virtual path between two points in an ATM network, ranging from 0 to 255 ● VCI: Virtual Channel Identifier (VCI) is the virtual channel between two points in an ATM network, ranging from 32 to 65535 (0 to 31 is reserved for local management of ATM traffic)
Encapsulation	Select the method of encapsulation provided by your ISP. You can select LLC/SNAP or VC-Mux

Field	Description
Channel Mode	Select the WAN connection type. You can select 1483 Bridged , 1483 MER , PPP over Ethernet (PPPoE) , PPP over ATM (PPPoA) , or 1483 Routed . In this example, 1483 MER is selected
Default Route	You can select Enable or Disable
DNS Settings	<ul style="list-style-type: none"> ● Obtain DNS Automatically: IP address is assigned by the office end automatically. You need not to enter the IP address. ● Use the following DNS server address: If you want to enter the DNS server address manually, select it and enter the IP addresses of primary DNS and secondary DNS

After finishing the configuration, click **NEXT**. The page shown in the following figure appears.

The screenshot shows the 'Step 4: Configuration Saving' page of the Planet ADSL 2/2+ Router configuration wizard. The page has a blue header with the Planet logo and 'ADSL 2/2+ Router'. Below the header is a navigation bar with tabs: Wizard, Status, Network, Service, Advance, Admin, and Diagnostic. The 'Wizard' tab is active, and the 'Wizard' sub-tab is selected. The main content area displays the following information:

Step 4: Configuration Saving

Click "Finish" to save the settings. Click "Back" to make more modifications. Click "Reset" to cancel the settings.

The parameters you set:

- User Name: admin
- Password: admin
- NTP State: Disable
- VPI: 0
- VCI: 35
- Encapsulation: LLC/SNAP
- Channel Mode: 1483 mer
- WAN IP Settings: Obtain an IP address automatically
- DNS Settings: Obtain DNS Automatically

At the bottom right, there are three buttons: Back, Finish, and Reset.

PPPoE/PPPoA

In the **Setup WAN Interface** page, enter the correct PVC, set the channel mode to **PPPoE** or **PPPoA**.

The screenshot shows the 'Step 3: WAN Interface Setup' page of the Planet ADSL 2/2+ Router configuration wizard. The page has a blue header with the Planet logo and 'ADSL 2/2+ Router'. Below the header is a navigation bar with tabs: Wizard, Status, Network, Service, Advance, Admin, and Diagnostic. The 'Wizard' tab is active, and the 'Wizard' sub-tab is selected. The main content area displays the following information:

Step 3: WAN Interface Setup

Set up the channel mode of WAN interface.

PVC Setting: VPI: 0 (0-255) VCI: 35 (32-65535)

Encapsulation: ☒ LLC/SNAP ☐ VC-Mux

Channel Mode: ☐ 1483 Bridged ☐ 1483 MER ☒ PPPoE ☐ PPPoA ☐ 1483 Routed

PPP Settings: User Name: Password:

Default Route: ☒ Enable ☐ Disable

DNS Settings: ☒ Obtain DNS Automatically ☐ Use the following DNS server address:

Primary DNS Server:

Secondary DNS Server:

At the bottom right, there are two buttons: Back and Next.

The following table describes the parameters of this page:

Field	Description
PVC Settings	<ul style="list-style-type: none"> ● VPI: Virtual Path Identifier (VPI) is the virtual path between two points in an ATM network, ranging from 0 to 255 ● VCI: Virtual Channel Identifier (VCI) is the virtual channel between two points in an ATM network, ranging from 32 to 65535 (0 to 31 is reserved for local management of ATM traffic)
Encapsulation	Select the method of encapsulation provided by your ISP. You can select LLC/SNAP or VC-Mux
Channel Mode	Select the WAN connection type. You can select 1483 Bridged , 1483 MER , PPP over Ethernet (PPPoE) , PPP over ATM (PPPoA) , or 1483 Routed . In this example, PPPoE is selected
PPP Settings	Enter the username and password for PPP dial-up, which are provided by your ISP
Default Route	You can select Enable or Disable
DNS Settings	<ul style="list-style-type: none"> ● Obtain DNS Automatically: IP address is assigned by the office end automatically. You need not to enter the IP address. ● Use the following DNS server address: If you want to enter the DNS server address manually, select it and enter the IP addresses of primary DNS and secondary DNS

After finishing the configuration, click **NEXT**. The page shown in the following figure appears.

PLANET
Networking & Communication

ADSL 2/2+ Router

Wizard Wizard Status Network Service Advance Admin Diagnostic

Wizard

Wizard

Step 4: Configuration Saving

Click "Finish" to save the settings. Click "Back" to make more modifications. Click "Reset" to cancel the settings.

The parameters you set:

User Name: admin
 Password: admin
 NTP State: Disable
 VPI: 0
 VCI: 35
 Encapsulation: LLC/SNAP
 Channel Mode: pppoe
 ppp User Name: test@5600.com
 ppp Password: test
 DNS Settings: Obtain DNS Automatically

1483 Routed

In the **Setup WAN Interface** page, enter the correct PVC, set the channel mode to **1483 Routed**.

PLANET
Networking & Communication

ADSL 2/2+ Router

Wizard Wizard Status Network Service Advance Admin Diagnostic

Wizard

Step 3: WAN Interface Setup

Set up the channel mode of WAN interface.

PVC Setting: VPI: 0 (0-255) VCI: 35 (32-65535)

Encapsulation: ☒ LLC/SNAP ☐ VC-Mux

Channel Mode: ☐ 1483 Bridged ☐ 1483 MER ☐ PPPoE ☐ PPPoA ☒ 1483 Routed

WAN IP Settings: ☒ Obtain IP address Automatically ☐ Use the following IP address:
WAN IP Address:
Subnet Mask:
Gateway:

Default Route: ☒ Enable ☐ Disable


DNS Settings: ☒ Obtain DNS Automatically ☐ Use the following DNS server address:
Primary DNS Server:
Secondary DNS Server:

[Back](#) [Next](#)

The following table describes the parameters of this page:

Field	Description
PVC Settings	<ul style="list-style-type: none"> ● VPI: Virtual Path Identifier (VPI) is the virtual path between two points in an ATM network, and its valid value is from 0 to 255 ● VCI: Virtual Channel Identifier (VCI) is the virtual channel between two points in an ATM network, ranging from 32 to 65535 (0 to 31 is reserved for local management of ATM traffic)
Encapsulation	Select the method of encapsulation provided by your ISP. You can select LLC/SNAP or VC-Mux
Channel Mode	Select the WAN connection type. You can select 1483 Bridged , 1483 MER , PPP over Ethernet (PPPoE) , PPP over ATM (PPPoA) , or 1483 Routed . In this example, 1483 Routed is selected
WAN IP Settings	<ul style="list-style-type: none"> ● Obtain an IP address automatically: Obtain the DNS server assigned by the uplink equipment, such as BAS ● Use the following IP address: Enter the static IP address provided by your ISP
Default Route	You can select Enable or Disable .
DNS Settings	<ul style="list-style-type: none"> ● Obtain DNS Automatically: IP address is assigned by the office end automatically. You need not to enter the IP address ● Use the following DNS server address: If you want to enter the DNS server address manually, select it and enter the related data

After finishing the configuration, click **NEXT**. The page shown in the following figure appears.




3.3 Status

In the navigation bar, click **Status**. In the **Status** page that is displayed contains **System**, **LAN**, **WAN**, **Statistics** and **ARP Table**.

3.3.1 System

Choose **Status** > **System**. The page that is displayed shows the current status and some basic settings of the router, such as, uptime, software version, upstream speed, downstream speed, and other information.



3.3.2 LAN

Choose **Status** > **LAN**. The page that is displayed shows some basic LAN settings of the router. In the **LAN Status** page, you can view the LAN IP address, DHCP server status, MAC address and DHCP client table. If you want to configure the LAN network, refer to the chapter 03.4.1 LAN.

PLANET Networking & Communication **ADSL 2/2+ Router**

LAN	Wizard	Status	Network	Service	Advance	Admin	Diagnostic
	System	LAN	WAN	Port Mapping	Statistics	ARP Table	

LAN

LAN Status

This page shows basic LAN settings of the device.

LAN Configuration	
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
DHCP Server	Enable
MAC Address	00:30:4F:90:4C:A3

DHCP Client Table				
Name	IP Address	MAC Address	Expiry(s)	Type
ENM-FRANK	192.168.1.2	00:22:19:06:b9:81	In 0 days 23:38:07	Automatic

3.3.3 WAN

Choose **Status > WAN**. The page that is displayed shows some basic WAN settings of the router. In the **WAN Status** page, you can view basic status of WAN, default gateway, DNS server. If you want to configure the WAN network, refer to the chapter 03.4.2 WAN.

PLANET Networking & Communication **ADSL 2/2+ Router**

WAN	Wizard	Status	Network	Service	Advance	Admin	Diagnostic
	System	LAN	WAN	Port Mapping	Statistics	ARP Table	

WAN

WAN Status

This page shows some basic WAN settings.

Interface	VPI/VCI	Encapsulation	Default Route	Protocol	IP Address	Gateway	Status
DNS Servers							

3.3.4 Port Mapping

Choose **Status > Port Mapping**. The page that is displayed shows the relationship and status of port mapping.

PLANET Networking & Communication **ADSL 2/2+ Router**

Port Mapping	Wizard	Status	Network	Service	Advance	Admin	Diagnostic
	System	LAN	WAN	Port Mapping	Statistics	ARP Table	

Port Mapping

Port Mapping

This page shows the mapping relation and the status of port mapping.

Status: Disabled


Select	Interfaces	Status
Default	LAN1,USB0	Enabled
Group1	--	--
Group2	--	--
Group3	--	--
Group4	--	--

3.3.5 Statistics

Choose **Status > Statistics**. The **Statistics** page that is displayed contains **Traffic Statistic** and **DSL Statistic**.

3.3.5.1 Traffic Statistic

Click **Traffic Statistic** in the left pane, the page shown in the following figure appears. In this page, you can view the statistics of each network interface.



PLANET
Networking & Communication

ADSL 2/2+ Router

Statistics Wizard Status Network Service Advance Admin Diagnostic

System LAN WAN Port Mapping Statistics ARP Table

Traffic Statistics
ADSL Statistics

Traffic Statistics

This page shows the packet statistics for transmission and reception regarding to network interface.

Interface	Rx Packet	Rx Error	Rx Drop	Tx Packet	Tx Error	Tx Drop
e1	812	0	0	819	0	0
a0	0	0	0	0	0	0
a1	0	0	0	0	0	0
a2	0	0	0	0	0	0
a3	0	0	0	0	0	0
a4	0	0	0	0	0	0
a5	0	0	0	0	0	0
a6	0	0	0	0	0	0
a7	0	0	0	0	0	0
e2	0	0	0	0	0	0

Refresh

3.3.5.2 ADSL Statistic

Click **DSL Statistic** in the left pane, the page shown in the following figure appears. In this page, you can view the ADSL line statistics, downstream rate, upstream rate and other information.



PLANET
Networking & Communication

ADSL 2/2+ Router

ADSL Statistics Wizard Status Network Service Advance Admin Diagnostic

System LAN WAN Port Mapping Statistics ARP Table

Traffic Statistics
ADSL Statistics

ADSL Statistics


This page shows the ADSL settings of the device.

ADSL Line Status	ACTIVATING
ADSL Mode	--
Upstream	--
Downstream	--
Attenuation Downstream(db)	--
Attenuation Upstream(db)	--
SNR Margin Downstream(db)	--
SNR Margin Upstream(db)	--
Vendor ID	RETK
DSP Version	2910b224
CRC Errors	--
Upstream BER	--
Downstream BER	--
Up Output Power	--
Down Output Power	--
ES	--
SES	--
UAS	--

ADSL Retrain: Retrain Refresh

3.3.5 ARP Table

Choose **Status > ARP Table**. In the **ARP table's** page, you can view the table that shows a list of learned MAC addresses.



PLANET
Networking & Communication

ADSL 2/2+ Router

ARP Table Wizard Status Network Service Advance Admin Diagnostic

System LAN WAN Port Mapping Statistics ARP Table

ARP Table

ARP Table

This page shows current ARP entries by interrogating the current protocol data.

IP Address	MAC Address
192.168.1.1	00:30:4F:91:30:87
192.168.1.2	00:22:19:06:B9:81

Refresh

3.4 Network

In the navigation bar, click **Network**. The **Network** page that is displayed contains **LAN** and **WAN**.

3.4.1 LAN

Choose **Network** > **LAN**. The **LAN** page that is displayed contains **LAN IP**, **DHCP**, and **DHCP Static IP**.

3.4.1.1 LAN IP

Click **LAN IP** in the left pane, the page shown in the following figure appears. In this page, you can change IP address of the router. The default IP address is 192.168.1.1, which is the private IP address of the router.

The screenshot shows the PLANET ADSL 2/2+ Router web interface. The top navigation bar includes links for Network, Wizard, Status, Network (selected), Service, Advance, Admin, and Diagnostic. The left sidebar shows LAN IP, DHCP, and DHCP Static IP. The main content area is titled 'LAN Interface Setup' and contains the following fields and controls:

- Interface Name: e1
- IP Address: 192.168.1.1
- Subnet Mask: 255.255.255.0
- ☐ Secondary IP
- IGMP Snooping: ☒ Disable ☐ Enable
- Apply Changes button
- LAN Port: [Dropdown menu]
- Link Speed/Duplex Mode: [Dropdown menu]
- Modify button
- ETHERNET Status Table:

Select	Port	Link Mode
<input checked="" type="radio"/>	LAN	Auto Negotiation

- MAC Address Control: ☐ LAN1 ☐ USB
- Apply Changes button
- New MAC Address: [Text input] Add button
- Current Allowed MAC Address Table:

MAC Addr	Action
----------	--------

The following table describes the parameters of this page:

Field	Description
IP Address	Enter the IP address of LAN interface. It is recommended to use an address from a block that is reserved for private use. This address block is 192.168.1.1- 192.168.255.254
Subnet Mask	Enter the subnet mask of LAN interface. The range of subnet mask is from 255.255.0.0-255.255.255.254
Secondary IP	Select it to enable the secondary LAN IP address. The two LAN IP addresses must be in the different network

Field	Description
Link Speed/Duplex Mode	Select the Link Speed/Duplex Mode which you need
ETHERNET Status Table	This table will show the current link mode
MAC Address Control	If you want to use the MAC address control feature, select it and add the MAC address
New MAC Address	Add the MAC address which you want can access the router via the LAN port
Current Allowed MAC Address Table	This table will show the current allowed MAC address

3.4.1.2 DHCP

Dynamic Host Configuration Protocol (DHCP) allows the individual PC to obtain the TCP/IP configuration from the centralized DHCP server. You can configure this router as a DHCP server or disable it. The DHCP server can assign IP address, IP default gateway, and DNS server to DHCP clients. This router can also act as a surrogate DHCP server (DHCP proxy) where it relays IP address assignment from an actual real DHCP server to clients. You can enable or disable DHCP server or DHCP proxy.

Click **DHCP** in the left pane, the page shown in the following figure appears.

PLANET Networking & Communication
ADSL 2/2+ Router

DHCP | Wizard | Status | Network | Service | Advance | Admin | Diagnostic

LAN | WAN

DHCP Mode

This page is used to configure DHCP mode. You can set DHCP mode to None, DHCP Relay or DHCP Server.

(1) Set the DHCP mode to DHCP Server if you are using this device as a DHCP server. This page lists an IP address pool available to hosts on your LAN. The device assigns IP addresses in the pool to hosts on your network when they request Internet access.

(2) Set the DHCP mode to DHCP Relay if you are using another DHCP server to assign IP address to your hosts on the LAN. You can set the IP address of the DHCP server.

(3) If you set the DHCP mode to None, the device does not assign IP addresses to the hosts when they request an IP address.

LAN IP Address: 192.168.1.1 Subnet Mask: 255.255.255.0

DHCP Mode:

Interface: ☒ LAN ☒ USB

IP Pool Range: 192.168.1.2 - 192.168.1.254

Default Gateway: 192.168.1.1

Max Lease Time: 1440 minutes

Domain Name: planet.com

DNS Servers: 192.168.1.1

The following table describes the parameters of this page:

Field	Description
DHCP Mode	If set to DHCP Server , the router can assign IP addresses, IP default gateway and DNS Servers to the host in Windows95, Windows NT and other operation systems that support the DHCP client
IP Pool Range	It specifies the first and the last IP address in the IP address

Field	Description
	pool. The router assigns IP address that is in the IP pool range to the host
Show Client	Click it, the Active DHCP Client Table appears. It shows IP addresses assigned to clients
Default Gateway	Enter the default gateway of the IP address pool
Max Lease Time	The lease time determines the period that the host retains the assigned IP addresses before the IP addresses change
Domain Name	Enter the domain name if you know. If you leave this blank, the domain name obtained by DHCP from the ISP is used. You must enter host name (system name) on each individual PC. The domain name can be assigned from the router through the DHCP server
DNS Server	Enter the DNS Server if you know, the default is router's IP.

Click **Show Client** in the **DHCP Mode** page, the page shown in the following figure appears. You can view the IP address assigned to each DHCP client.



The following table describes the parameters and buttons in this page:

Field	Description
IP Address	It displays the IP address assigned to the DHCP client from the router
MAC Address	It displays the MAC address of the DHCP client. Each Ethernet device has a unique MAC address. The MAC address is assigned at the factory and it consists of six pairs of hexadecimal character, for example, 00-30-4F-00-11-22
Expired (s)	It displays the lease time. The lease time determines the period that the host retains the assigned IP addresses before the IP addresses change
Refresh	Click it to refresh this page
Close	Click it to close this page

Click Set VendorClass IP Range in the DHCP Mode page, the page shown in the following figure appears. You can view the IP address assigned to each DHCP client. The following table describes the parameters and buttons in this page:

Device IP Range Table

This page is used to configure the IP address range based on device type.

Device Name:

Start Address:

End Address:

Router Address:

Option60

Add

Delete

Modify

Close

IP Range Table:

Select	Device Name	Start Address	End Address	Default Gateway	Option60
--------	-------------	---------------	-------------	-----------------	----------

Field	Description
Device Name	You can set the device name on this item
Start Address	The IP address ranges start address
End Address	The IP address range end address
Router Address	Set the router address on this item
Option60	Type the Option60 value

In the **DHCP Mode** field, choose **None**. The page shown in the following figure appears.

PLANET

Networking & Communication

ADSL 2/2+ Router

DHCP

Wizard

Status

Network

Service

Advance

Admin

Diagnostic

LAN

WAN

LAN IP

DHCP

DHCP Static IP

DHCP Mode

This page is used to configure DHCP mode. You can set DHCP mode to None, DHCP Relay or DHCP Server.
(1) Set the DHCP mode to DHCP Server if you are using this device as a DHCP server. This page lists an IP address pool available to hosts on your LAN. The device assigns IP addresses in the pool to hosts on your network when they request Internet access.
(2) Set the DHCP mode to DHCP Relay if you are using another DHCP server to assign IP address to your hosts on the LAN. You can set the IP address of the DHCP server.
(3) If you set the DHCP mode to None, the device does not assign IP addresses to the hosts when they request an IP address.

LAN IP Address: 192.168.1.1 Subnet Mask: 255.255.255.0

DHCP Mode:

None

Apply Changes

Reset

Set VendorClass IP Range

In the **DHCP Mode** field, choose **DHCP Relay**. The page shown in the following figure appears.

The following table describes the parameters and buttons of this page:

Field	Description
DHCP Mode	If set to DHCP Relay , the router acts a surrogate DHCP Server and relays the DHCP requests and responses between the remote server and the client
Relay Server	Enter the DHCP server address provided by your ISP
Apply Changes	Click it to save the settings of this page
Undo	Click it to refresh this page

3.4.1.3 DHCP Static IP

Click **DHCP Static IP** in the left pane, the page shown in the following figure appears. You can assign the IP addresses on the LAN to the specific individual PCs based on their MAC address.

The following table describes the parameters and buttons of this page:

Field	Description
IP Address	Enter the specified IP address in the IP pool range, which is assigned to the host
Mac Address	Enter the MAC address of a host on the LAN
Add	After entering the IP address and MAC address, click it. A row will be added in the DHCP Static IP Table
Delete Selected	Select a row in the DHCP Static IP Table , then click it, this row is deleted

Field	Description
Reset	Click it to reset those parameter
DHCP Static IP Table	It shows the assigned IP address based on the MAC address

3.4.2 WAN

Choose **Network > WAN**. The **WAN** page that is displayed contains **WAN**, **ATM Setting**, and **ADSL Setting**.

3.4.2.1 WAN

Click **WAN** in the left pane, the page shown in the following figure appears. In this page, you can configure WAN interface of your router.

Planet Networking & Communications
ADSL 2/2+ Router

WAN Wizard Status **Network** Service Advance Admin Diagnostic

LAN **WAN**

Channel Configuration

The DSL WAN connection can be separated virtually into multiple channels by assigning different VPI/VCI in each Permanent Virtual Circuit (PVC). In each PVC you can also set the connection protocol to be PPP, Dynamic IP, Static IP or Bridge mode.

Default Route Selection: ☐ Auto ☒ Specified

VPI: 0 VCI: Encapsulation: ☒ LLC ☐ VC-Mux

Channel Mode: 1483 Bridged Enable NAPT: ☐

Enable IGMP: ☐

PPP Settings:

User Name: Password:

Type: Continuous Idle Time (min):

WAN IP Settings:

Type: ☒ Fixed IP ☐ DHCP

Local IP Address: Gateway:

Netmask:

Default Route: ☐ Disable ☒ Enable ☐ Auto

Unnumbered ☐


Add Modify Delete Reset Refresh

Current ATM VC Table:


Select	Inf	Mode	VPI/VCI	Encap	NAPT	IGMP	DRoute	IP Addr	Gateway	NetMask	User Name	Unnumber	Status	Edit	
<input checked="" type="radio"/>	a0	br	1483	0	35	LLC	Off	Off	Off	0.0.0.0	0.0.0.0	0.0.0.0	---	down	

The following table describes the parameters of this page:

Field	Description
Default Route Selection	You can select Auto or Specified
VPI	The virtual path between two points in an ATM network, ranging from 0 to 255
VCI	The virtual channel between two points in an ATM network, ranging from 32 to 65535 (1 to 31 are reserved for known protocols)
Encapsulation	You can choose LLC and VC-Mux .
Channel Mode	You can choose 1483 Bridged , 1483 MER , PPPoE , PPPoA , or 1483 Routed
Enable NAPT	Select it to enable Network Address Port Translation (NAPT) function. If you do not select it and you want to access the Internet normally, you must add a route on the uplink equipment. Otherwise, the access to the Internet fails. Normally, it is enabled
Enable IGMP	You can enable or disable Internet Group Management Protocol (IGMP) function
PPP Settings	
User Name	Enter the correct user name for PPP dial-up, which is provided by your ISP

Field	Description
Password	Enter the correct password for PPP dial-up, which is provided by your ISP
Type	You can choose Continuous , Connect on Demand , or Manual
Idle Time (min)	If set the type to Connect on Demand , you need to enter the idle timeout time. Within the preset minutes, if the router does not detect the flow of the user continuously, the router automatically disconnects the PPPoE connection
WAN IP Settings	
Type	You can choose Fixed IP or DHCP <ul style="list-style-type: none"> ● If select Fixed IP, you should enter the local IP address, remote IP address and subnet mask ● If select DHCP, the router is a DHCP client, the WAN IP address is assigned by the remote DHCP server
Local IP Address	Enter the IP address of WAN interface provided by your ISP
Remote IP Address	Enter the gateway IP address provided by your ISP
Netmask	Enter the subnet mask of the local IP address
Unnumbered	Select this checkbox to enable IP unnumbered function
Add	After configuring the parameters of this page, click it to add a new PVC into the Current ATM VC Table
Modify	Select PVC in the Current ATM VC Table , and then modify the parameters of this PVC. After finishing, click it to apply the settings of this PVC
Current ATM VC Table	This table shows the existed PVCs. It shows the interface name, channel mode, VPI/VCI, encapsulation mode, local IP address, remote IP address and other information. The maximum item of this table is eight
	Click it; the PPP Interface-Modify appears. You can modify the PVCs' parameters

Click  in the **PPPoE** mode, the page shown in the following figure appears. In this page, you can configure parameters of this PPPoE PVC.



The screenshot shows the PLANET ADSL 2/2+ Router web interface. The top navigation bar includes tabs for WAN, Wizard, Status, Network, Service, Advance, Admin, and Diagnostic. The left sidebar has links for WAN, ATM Setting, and ADSL Setting. The main content area is titled "PPP Interface - Modify" and contains the following configuration fields:

- Protocol: PPPoE
- ATM VCC: 0/33
- Login Name: test@5600.com
- Password: ****
- Authentication Method: AUTO
- Connection Type: Continuous
- Idle Time(s): 0
- Bridge:
 - ☐ Bridged Ethernet (Transparent Bridging)
 - ☐ Bridged PPPoE (Implies Bridged Ethernet)
 - ☒ Disable Bridge
- AC-Name:
- Service-Name:
- 802.1q:
 - ☒ Disable
 - ☐ Enable
- VLAN ID(1-4095): 0
- MTU (1-1500): 1492
- Static IP:
- Source Mac address: 00:E9:07:90:36:87 (ex. 00:E0:86:71:05:02)

At the bottom, there are three buttons: "Apply Changes", "Return", and "Reset".

The following table describes the parameters and buttons of this page:

Field	Description
Protocol	It displays the protocol type used for this WAN connection
ATM VCC	The ATM virtual circuit connection assigned for this PPP interface (VPI/VCI)
Login Name	The user name provided by your ISP
Password	The password provided by your ISP
Authentication Method	You can choose AUTO , CHAP , or PAP
Connection Type	You can choose Continuous , Connect on Demand , or Manual
Idle Time (s)	If choose Connect on Demand , you need to enter the idle timeout time. Within the preset minutes, if the router does not detect the flow of the user continuously, the router automatically disconnects the PPPoE connection
Bridge	You can select Bridged Ethernet , Bridged PPPoE , or Disable Bridge
AC-Name	The accessed equipment type
Service-Name	The service name
802.1q	You can select Disable or Enable . After enable it, you need to enter the VLAN ID. The value ranges from 0 to 4095
Apply Changes	Click it to save the settings of this page temporarily
Return	Click it to return to the Channel Configuration page
Undo	Click it to refresh this page

3.4.2.2 ATM Setting

Click **ATM Setting** in the left pane, the page shown in the following figure appears. In this page, you can configure the parameters of the ATM, including QoS, PCR, CDVT, SCR, and MBS.

PLANET Networking & Communication **ADSL 2/2+ Router**

ATM Setting | Wizard | Status | Network | Service | Advance | Admin | Diagnostic

LAN | WAN

WAN
ATM Setting
ADSL Setting

ATM Settings

This page is used to configure the parameters for the ATM of your ADSL Router. Here you may change the setting for QoS, PCR, CDVT, SCR and MBS.

VPI: VCI: QoS:

PCR: CDVT: SCR: MBS:

Current ATM VC Table:

Select	VPI	VCI	QoS	PCR	CDVT	SCR	MBS
<input type="radio"/>	0	35	UBR	6144	0	---	---
<input type="radio"/>	0	33	UBR	6144	0	---	---

The following table describes the parameters of this page:

Field	Description
VPI	The virtual path identifier of the ATM PVC
VCI	The virtual channel identifier of the ATM PVC
QoS	The QoS category of the PVC. You can choose UBR , CBR , rt-VBR , or nrt-VBR
PCR	Peak cell rate (PCR) is the maximum rate at which cells can be

Field	Description
	transmitted along a connection in the ATM network. Its value ranges from 1 to 65535
CDVT	Cell delay variation tolerance (CDVT) is the amount of delay permitted between ATM cells (in microseconds). Its value ranges from 0 to 4294967295
SCR	Sustain cell rate (SCR) is the maximum rate that traffic can pass over PVC without the risk of cell loss. Its value ranges from 0 to 65535
MBS	Maximum burst size (MBS) is the maximum number of cells that can be transmitted at the PCR. Its value ranges from 0 to 65535

3.4.2.3 ADSL Setting

Click **ADSL Setting** in the left pane, the page shown in the following figure appears. In this page, you can select the DSL modulation. Mostly, you need to remain this factory default settings. The router supports these modulations: **G.Lite**, **G.Dmt**, **T1.413**, **ADSL2**, **ADSL2+**, **AnnexL**, and **AnnexM**. The router negotiates the modulation modes with the DSLAM.

The screenshot shows the configuration interface for a Planet ADSL 2/2+ Router. The top navigation bar includes tabs for ADSL Setting, Wizard, Status, Network, Service, Advance, Admin, and Diagnostic. The left sidebar shows a tree view with WAN, ATM Setting, and ADSL Setting. The main content area is titled 'ADSL Settings' and contains the following configuration options:

- ADSL Modulation:**
 - ☐ G.Lite
 - ☒ G.Dmt
 - ☒ T1.413
 - ☒ ADSL2
 - ☒ ADSL2+
- AnnexL Option:**
 - ☒ Enable
- AnnexM Option:**
 - ☐ Enable
- ADSL Capability:**
 - ☒ Bitswap Enable
 - ☒ SRA Enable

An 'Apply Changes' button is located at the bottom of the configuration area.

3.5 Service

In the navigation bar, click **Service**. In the **Service** page that is displayed contains **DNS**, **Firewall**, **UPNP**, **IGMP Proxy**, **TR-069**, and **ACL**.

3.5.1 DNS

Domain Name System (DNS) is an Internet service that translates the domain name into IP address. Because the domain name is alphabetic, it is easier to remember. The Internet, however, is based on IP addresses. Every time you use a domain name, DNS translates the name into the corresponding IP address. For example, the domain name www.example.com might be translated to 198.105.232.4. The DNS has its own network. If one DNS server does not know how to translate a particular domain name, it asks another one, and so on, until the correct IP address is returned.

Choose **Service** > **DNS**. The **DNS** page that is displayed contains **DNS** and **DDNS**.

3.5.1.1 DNS

Click **DNS** in the left pane, the page shown in the following figure appears.

PLANET Networking & Communication **ADSL 2/2+ Router**

DNS Wizard Status Network Service Advance Admin Diagnostic

DNS Firewall UPnP IGMP Proxy TR-069 ACL

DNS
DDNS

DNS Configuration

This page is used to configure the IP addresses of the DNS server in the DNS relay mode.

☒ Obtain DNS Automatically
☐ Set DNS Manually

DNS 1:
DNS 2:
DNS 3:

The following table describes the parameters and buttons of this page:

Field	Description
Attain DNS Automatically	Select it, the router accepts the first received DNS assignment from one of the PPPoA, PPPoE or MER enabled PVC(s) during the connection establishment
Set DNS Manually	Select it; enter the IP addresses of the primary and secondary DNS server
Apply Changes	Click it to save the settings of this page
Reset Selected	Click it to start configuring the parameters in this page

3.5.1.2 DDNS

Click **DDNS** in the left pane, the page shown in the following figure appears. This page is used to configure the dynamic DNS address from DynDNS.org or TZO. You can add or remove to configure dynamic DNS.

PLANET Networking & Communication **ADSL 2/2+ Router**

DDNS Wizard Status Network Service Advance Admin Diagnostic

DNS Firewall UPnP IGMP Proxy TR-069 ACL

DNS
DDNS

Dynamic DNS Configuration

This page is used to configure the Dynamic DNS address from DynDNS.org or TZO. Here you can Add/Remove to configure Dynamic DNS.

DDNS provider:
Host Name:
Interface:
Enable: ☒

DynDns Settings:
User Name:
Password:

TZO Settings:
Email:
Key:

The following table describes the parameters of this page:

Field	Description
DDNS provider	Choose the DDNS provider name
Hostname	The DDNS identifier
Interface	The WAN interface of the router
Enable	Enable or disable DDNS function
Username	The name provided by DDNS provider
Password	The password provided by DDNS provider
Email	The email provided by DDNS provider
Key	The key provided by DDNS provider

3.5.2 Firewall

Choose **Service > Firewall**. The **Firewall** page that is displayed contains **IP Port Filter**, **MAC Filter**, **URL Blocking**, **Virtual Server**, **DMZ Setting**, and **DoS Setting**.

3.5.2.1 IP Port Filter

Click **IP Port Filter** in the left pane, the page shown in the following figure appears. Entries in the table are used to restrict certain types of data packets through the gateway. These filters are helpful in securing or restricting your local network.

PLANET Networking & Communication **ADSL 2/2+ Router**

IP/Port Filter | Wizard | Status | Network | **Service** | Advance | Admin | Diagnostic

DNS | Firewall | UPnP | IGMP Proxy | TR-069 | ACL

IP/Port Filter
MAC Filter
URL Blocking
Virtual Server
IP Address Mapping
DMZ Setting
NAT EXCLUDE IP
Anti-DoS

IP/Port Filter

Entries in this table are used to restrict certain types of data packets from your local network to Internet through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

Outgoing Default Action: ☒ Permit ☐ Deny
Incoming Default Action: ☐ Permit ☒ Deny

Rule Action: ☒ Permit ☐ Deny
Protocol:
Direction:
Source IP Address:
Destination IP Address:
Source Port: -
Enable: ☒

Subnet Mask:
Subnet Mask:
Destination Port: -

Current Filter Table:

Rule	Protocol	Source IP/Mask	SPort	Dest IP/Mask	DPort	State	Direction	Action
------	----------	----------------	-------	--------------	-------	-------	-----------	--------

3.5.2.2 MAC Filter

Click **MAC Filter** in the left pane, the page shown in the following figure appears. Entries in the table are used to restrict certain types of data packets from your local network to Internet through the gateway. These filters are helpful in securing or restricting your local network.

3.5.2.3 URL Blocking

Click **URL Blocking** in the left pane, the page shown in the following figure appears. This page is used to block a fully qualified domain name, such as tw.yahoo.com and filtered keyword. You can add or delete FQDN and filtered keyword.

The following table describes the parameters and buttons of this page:

Field	Description
URL Blocking Capability	You can choose Disable or Enable <ul style="list-style-type: none"> ● Select Disable to disable URL blocking function and keyword filtering function ● Select Enable to block access to the URLs and keywords specified in the URL Blocking Table
Keyword	Enter the keyword to block
AddKeyword	Click it to add a keyword to the URL Blocking Table
Delete Selected Keyword	Select a row in the URL Blocking Table and click it to delete the row
URL Blocking Table	A list of the URL (s) to which access is blocked

3.5.2.4 Virtual Server

Click **Virtual Server** in the left pane, the page shown in the following figure appears.

Virtual Server

The page is used to configure virtual server.
So other users on the Internet can access the server on your LAN through the device.

Service Type:

☒ Usual Service Name: AUTH

☐ User-defined Service Name:

Protocol: TCP

WAN Setting: Interface

WAN Interface: any

WAN Port: 113 (ex. 5001:5010)

LAN Open Port: 113

LAN IP Address:

Apply Changes

Current Virtual Server Forwarding Table:

ServerName	Protocol	Local IP Address	Local Port	WAN IP Address	WAN Port	State	Action
------------	----------	------------------	------------	----------------	----------	-------	--------

The following table describes the parameters of this page:

Field	Description
Service Type	You can select the common service type, for example, AUTH , DNS , or FTP . You can also define a service name. <ul style="list-style-type: none">● If you select Usual Service Name, the corresponding parameter has the default settings● If you select User-defined Service Name, you need to enter the corresponding parameters
Protocol	Choose the transport layer protocol that the service type uses. You can choose TCP or UDP
WAN Setting	You can choose Interface or IP Address
WAN Interface	Choose the router port that uses virtual server
WAN Port	Choose the access port on the WAN
LAN Open Port	Enter the port number of the specified service type
LAN IP Address	Enter the IP address of the virtual server. It is in the same network segment with LAN IP address of the router

3.5.2.5 DMZ Setting

Demilitarized Zone (DMZ) is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains devices accessible to Internet traffic, such as web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.

Click **DMZ Setting** in the left pane, the page shown in the following figure appears.

The following describes how to configure DMZ.

Step 1: Select **Enable DMZ** to enable this function.

Step 2: Enter an IP address of the DMZ host.

Step 3: Click **Apply Changes** to save the settings of this page temporarily.

PLANET Networking & Communication **ADSL 2/2+ Router**

DMZ Setting	Wizard	Status	Network	Service	Advance	Admin	Diagnostic
	DNS	Firewall	UPnP	IGMP Proxy	TR-069	ACL	

DMZ Setting

A Demilitarized Zone is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains devices accessible to Internet traffic, such as Web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.

☐ **Enable DMZ**

DMZ Host IP Address:

3.5.2.6 NAT EXCLUDE IP

In the page, you can config some source IP address which uses the purge route mode when access internet through the specified interface .You can set a range of the ip not via the NAT to the internet.

PLANET Networking & Communication **ADSL 2/2+ Router**

NAT EXCLUDE IP	Wizard	Status	Network	Service	Advance	Admin	Diagnostic
	DNS	Firewall	UPnP	IGMP Proxy	TR-069	ACL	

NAT EXCLUDE IP

In the page ,you can config some source IP address which use the purge route mode when access internet through the specified interface.

Interface:

IP Range: -

Current NAT Exclude IP Table:

WAN Interface	Low IP	High IP	Action

3.5.2.7 DoS Setting

Denial-of-Service Attack (DoS attack) is a type of attack on a network that is designed to bring the network to its knees by flooding it with useless traffic. Click **DoS Setting** in the left pane, the page shown in the following figure appears. In this page, you can prevent DoS attacks.

PLANET Networking & Communication **ADSL 2/2+ Router**

Anti-DoS	Wizard	Status	Network	Service	Advance	Admin	Diagnostic
	DNS	Firewall	UPnP	IGMP Proxy	TR-069	ACL	

Anti-DoS Setting

A "denial-of-service" (DoS) attack is characterized by an explicit attempt by hackers to prevent legitimate users of a service from using that service.

☐ **Enable DoS Prevention**

<input type="checkbox"/> Whole System Flood: SYN	<input type="text" value="100"/>	Packets/Second
<input type="checkbox"/> Whole System Flood: FIN	<input type="text" value="100"/>	Packets/Second
<input type="checkbox"/> Whole System Flood: UDP	<input type="text" value="100"/>	Packets/Second
<input type="checkbox"/> Whole System Flood: ICMP	<input type="text" value="100"/>	Packets/Second
<input type="checkbox"/> Per-Source IP Flood: SYN	<input type="text" value="100"/>	Packets/Second
<input type="checkbox"/> Per-Source IP Flood: FIN	<input type="text" value="100"/>	Packets/Second
<input type="checkbox"/> Per-Source IP Flood: UDP	<input type="text" value="100"/>	Packets/Second
<input type="checkbox"/> Per-Source IP Flood: ICMP	<input type="text" value="100"/>	Packets/Second
<input type="checkbox"/> TCP/UDP PortScan	<input type="text" value="Low"/>	Sensitivity
<input type="checkbox"/> ICMP Smurf		
<input type="checkbox"/> IP Land		
<input type="checkbox"/> IP Spoof		
<input type="checkbox"/> IP TearDrop		
<input type="checkbox"/> PingOfDeath		
<input type="checkbox"/> TCP Scan		
<input type="checkbox"/> TCP SynWithdata		
<input type="checkbox"/> UDP Bomb		
<input type="checkbox"/> UDP EchoChargen		

3.5.3 UPnP

Choose **Service** > **UPnP**, the page shown in the following figure appears. This page is used to configure UPnP. The system acts as a daemon after you enable it.

The screenshot shows the 'UPnP Configuration' page. The top navigation bar includes 'UPnP', 'Wizard', 'Status', 'Network', 'Service', 'Advance', 'Admin', and 'Diagnostic'. The 'Service' tab is active, showing sub-tabs: 'DNS', 'Firewall', 'UPnP', 'IGMP Proxy', 'TR-069', and 'ACL'. The 'UPnP' sub-tab is selected. The main content area is titled 'UPnP Configuration' and contains a description: 'This page is used to configure UPnP. The system acts as a daemon when you enable UPnP.' Below this, there are radio buttons for 'UPnP:' with 'Disable' and 'Enable' options. The 'Enable' option is selected. There is a 'WAN Interface:' dropdown menu and an 'Apply Changes' button at the bottom.

3.5.4 IGMP Proxy

Choose **Service** > **IGMP Proxy**, the page shown in the following figure appears. IGMP proxy enables the system to issue IGMP host messages on behalf of hosts that the system discovered through standard IGMP interfaces. The system acts as a proxy for its hosts after you enable it.

The screenshot shows the 'IGMP Proxy Configuration' page. The top navigation bar is the same as the previous page. The 'Service' tab is active, and the 'IGMP Proxy' sub-tab is selected. The main content area is titled 'IGMP Proxy Configuration' and contains a description: 'IGMP proxy enables the system to issue IGMP host messages on behalf of hosts that the system discovered through standard IGMP interfaces. The system acts as a proxy for its hosts when you enable it by doing the follows: Enable IGMP proxy on WAN interface (upstream), which connects to a router running IGMP. Enable IGMP on LAN interface (downstream), which connects to its hosts.' Below this, there are radio buttons for 'IGMP Proxy:' with 'Disable' and 'Enable' options. The 'Enable' option is selected. There are also radio buttons for 'Multicast Allowed:' with 'Disable' and 'Enable' options. The 'Enable' option is selected. Below these are input fields for 'Robust Count:' (value 2), 'Last Member Query Count:' (value 2), 'Query Interval:' (value 60, seconds), 'Query Response Interval:' (value 100, *100ms), and 'Group Leave Delay:' (value 2000, ms). There are 'Apply Changes' and 'Reset' buttons at the bottom.

3.5.5 TR-069

Choose **Service** > **TR-069**, the page shown in the following page appears. In this page, you can configure the TR-069 CPE.

The screenshot shows the 'TR-069 Configuration' page. The top navigation bar is the same as the previous pages. The 'Service' tab is active, and the 'TR-069' sub-tab is selected. The main content area is titled 'TR-069 Configuration' and contains a description: 'This page is used to configure the TR-069 customer premises equipment (CPE). In this page, you can configure the parameters of auto-configuration server (ACS).' Below this, there are sections for 'ACS:' and 'Connection Request:'. The 'ACS:' section has a checkbox for 'Enable:' which is checked, a 'URL:' field with value 'http://20.20.20.9090/web/tr069', a 'User Name:' field with value 'hgw', a 'Password:' field with value 'hgw', radio buttons for 'Periodic Inform Enable:' with 'Disable' and 'Enable' options, and a 'Periodic Inform Interval:' field with value 300. The 'Connection Request:' section has a 'User Name:' field with value 'itms', a 'Password:' field with value 'itms', a 'Path:' field with value '/tr069', and a 'Port:' field with value 7547. There are 'Apply Changes' and 'Reset' buttons at the bottom.

Debug:

ACS Certificates CPE: ☒ No ☐ Yes

Show Message: ☒ Disable ☐ Enable

CPE Sends GetRPC: ☒ Disable ☐ Enable

Skip MReboot: ☒ Disable ☐ Enable

Delay: ☐ Disable ☒ Enable

Auto-Execution: ☐ Disable ☒ Enable

Certificate Management:

CPE Certificate:

CA Certificate:

The following table describes the parameters of this page:

Field	Description
ACS	
URL	The URL of the auto-configuration server to connect to
User Name	The user name for logging in to the ACS
Password	The password for logging in to the ACS
Periodic Inform Enable	Select Enable to periodically connect to the ACS to check whether the configuration updates
Periodic Inform Interval	Specify the amount of time between connections to ACS
Connection Request	
User Name	The connection username provided by TR-069 service
Password	The connection password provided by TR-069 service
Debug	
Show Message	Select Enable to display ACS SOAP messages on the serial console
CPE sends GetRPC	Select Enable , the router contacts the ACS to obtain configuration updates
Skip MReboot	Specify whether to send an MReboot event code in the inform message
Delay	Specify whether to start the TR-069 program after a short delay
Auto-Execution	Specify whether to automatically start the TR-069 after the router is powered on

3.5.6 ACL

Choose **Service > ACL**, the page shown in the following figure appears. In this page, you can permit the data packets from LAN or WAN to access the router. You can configure the IP address for Access Control List (ACL). If ACL is enabled, only the effective IP address in the ACL can access the router.



Note:

If you select **Enable** in ACL capability, ensure that your host IP address is in ACL list before it takes effect.

PLANET Networking & Communication **ADSL 2/2+ Router**

ACL Wizard Status Network **Service** Advance Admin Diagnostic

DNS Firewall UPnP IGMP Proxy TR-069 **ACL**

ACL Configuration

You can specify which services are accessible from LAN or WAN side. Entries in this ACL table are used to permit certain types of data packets from your local network or Internet network to the Gateway. Using of such access control can be helpful in securing or restricting the Gateway management.

Direction Select: ☒ LAN ☐ WAN

LAN ACL Switch: ☐ Enable ☒ Disable

IP Address: (The IP 0.0.0.0 represent any IP)

Services Allowed:
☒ Any

Current ACL Table:

Select	Direction	IP Address/Interface	Service	Port	Action
--------	-----------	----------------------	---------	------	--------

The following table describes the parameters and buttons of this page:

Field	Description
Direction Select	Select the router interface. You can select LAN or WAN . In this example, LAN is selected
LAN ACL Switch	Select it to enable or disable ACL function
IP Address	Enter the IP address of the specified interface. Only the IP address that is in the same network segment with the IP address of the specified interface can access the router
Services Allowed	You can choose the following services from LAN: web , telnet , ftp , ftpp , snmp , or ping . You can also choose all the services
Add	After setting the parameters, click it to add an entry to the Current ACL Table
Reset	Click it to refresh this page

Set direction of the data packets to **WAN**, the page shown in the following figure appears.

PLANET Networking & Communication **ADSL 2/2+ Router**

ACL Wizard Status Network **Service** Advance Admin Diagnostic

DNS Firewall UPnP IGMP Proxy TR-069 **ACL**

ACL Configuration

You can specify which services are accessible from LAN or WAN side. Entries in this ACL table are used to permit certain types of data packets from your local network or Internet network to the Gateway. Using of such access control can be helpful in securing or restricting the Gateway management.

Direction Select: ☐ LAN ☒ WAN

WAN Setting:

WAN Interface:

Services Allowed:
☐ Web
☐ Telnet
☐ FTP
☐ TFTP
☐ SNMP
☐ PING

Current ACL Table:

Select	Direction	IP Address/Interface	Service	Port	Action
--------	-----------	----------------------	---------	------	--------

The following table describes the parameters and buttons of this page:

Field	Description
Direction Select	Select the router interface. You can select LAN or WAN . In this example, WAN is selected
WAN Setting	You can choose Interface or IP Address
WAN Interface	Choose the interface that permits data packets from WAN to access the router
IP Address	Enter the IP address on the WAN. Only the IP address that is in the same network segment with the IP address on the WAN can access the router
Services Allowed	You can choose the following services from WAN: web , telnet , ftp , tftp , snmp , or ping . You can also choose all the services
Add	After setting the parameters, click it to add an entry to the Current ACL Table
Reset	Click it to refresh this page

3.6 Advance

In the navigation bar, click **Advance**. In the **Advance** page that is displayed contains **Bridge Setting**, **Routing**, **QoS**, **SNMP** and **Others**.

3.6.1 Bridge Setting

Choose **Advance > Bridge Setting**, the page shown in the following figure appears. This page is used to configure the bridge parameters. You can change the settings or view some information on the bridge and its attached ports.

The following table describes the parameters and button of this page:

Field	Description
Aging Time	If the host is idle for 300 seconds (default value), its entry is deleted from the bridge table
802.1d Spanning Tree	You can select Disabled or Enabled . Select Enabled to provide path redundancy while preventing undesirable loops in your network
Show MACs	Click it to show a list of the learned MAC addresses for the bridge

Click **Show MACs**, the page shown in the following figure appears. This table shows a list of learned MAC addresses for this bridge.

Forwarding Table

MAC Address	Port	Type	Aging Time
00:30:4F:00:00:00	0	Static	300
00:30:4F:03:04:05	0	Static	300
00:30:4F:00:00:09	0	Static	300
00:30:4F:0c:f2:ce	1	Dynamic	300
ff:ff:ff:ff:ff:ff	0	Static	300

refresh

close

3.6.2 Routing

Choose **Advance > Routing**, the page shown in the following figure appears. The page that is displayed contains **RIP** and **Static Route**.

3.6.2.1 Static Route

Click **Static Route** in the left pane, the page shown in the following figure appears. This page is used to configure the routing information. You can add or delete IP routes.

PLANET Networking & Communication
ADSL 2/2+ Router

Static Route | Wizard | Status | Network | Service | Advance | Admin | Diagnostic

Bridge Setting | Routing | Port Mapping | QoS | SNMP | Others

Static Route
RIP

Routing Configuration

This page is used to configure the routing information. Here you can add/delete IP routes.

Enable: ☒

Destination:

Subnet Mask:

Next Hop:

Metric:

Interface:

Add Route | Update | Delete Selected | Show Routes

Static Route Table:

Select	State	Destination	Subnet Mask	Next Hop	Metric	Interface
--------	-------	-------------	-------------	----------	--------	-----------

The following table describes the parameters and buttons of this page:

Field	Description
Enable	Select it to use static IP routes
Destination	Enter the IP address of the destination device
Subnet Mask	Enter the subnet mask of the destination device
Next Hop	Enter the IP address of the next hop in the IP route to the destination device
Metric	The metric cost for the destination
Interface	The interface for the specified route
Add Route	Click it to add the new static route to the Static Route Table
Update	Select a row in the Static Route Table and modify the parameters. Then click it to save the settings temporarily
Delete Selected	Select a row in the Static Route Table and click it to delete the row

Field	Description
Show Routes	Click it, the IP Route Table appears. You can view a list of destination routes commonly accessed by your network
Static Route Table	A list of the previously configured static IP routes

Click **Show Routes**, the page shown in the following figure appears. The table shows a list of destination routes commonly accessed by your network.

Destination	Subnet Mask	Next Hop	Interface
192.168.1.254	255.255.255.255	*	e1

3.6.2.2 RIP

Click **RIP** in the left pane, the page shown in the following figure appears. If you are using this device as a RIP-enabled router to communicate with others using Routing Information Protocol (RIP), enable RIP. This page is used to select the interfaces on your devices that use RIP, and the version of the protocol used.

The following table describes the parameters and buttons of this page:

Field	Description
RIP	Select Enable , the router communicates with other RIP-enabled devices
Apply Change	Click it to save the settings of this page
Interface	Choose the router interface that uses RIP
Receive Version	Choose the interface version that receives RIP messages. You can choose RIP1 , RIP2 , or Both <ul style="list-style-type: none"> Choose RIP1 indicates the router receives RIP v1 messages Choose RIP2 indicates the router receives RIP v2 messages Choose Both indicates the router receives RIP v1 and RIP v2 messages
Send Version	The working mode for sending RIP messages. You can choose RIP1 or RIP2 <ul style="list-style-type: none"> Choose RIP1 indicates the router broadcasts RIP1 messages only Choose RIP2 indicates the router multicasts RIP2

Field	Description
	messages only
Add	Click it to add the RIP interface to the Rip Config List
Delete	Select a row in the Rip Config List and click it to delete the row

3.6.3 Port Mapping

Choose **Advance > Port Mapping**, the page shown in the following figure appears.

Port Mapping Configuration

The procedure for operating a mapping group is as follows:

1. Enable port mapping.
2. Select a group from the table.
3. Select interfaces from the available interface list and add it to the grouped interface list by using the arrow buttons to bind the ports.
4. Click "Apply Changes" to save the settings.

Note: The selected interfaces will be removed from their original groups and added to the new group.

☒ Disable ☐ Enable

WAN

Interface Group

Add >

< Del

Select	Interfaces	Status
Default	LAN1.USB0	Enabled
Group1		--
Group2		--
Group3		--
Group4		--

Apply Changes

You can set which WAN will binding with which LAN port, click add or del to change the group member.

3.6.4 QoS

Choose **Advance > QoS**, the page shown in the following figure appears. Entries in the **QoS Rule List** are used to assign the precedence for each incoming packet based on physical LAN port, TCP/UDP port number, source IP address, destination IP address and other information.

IP QoS

Entries in the table are used to assign the precedence for each incoming packet according to the specified policy.

The procedure for configuring quality of service (QoS) is as follows:

1. Enable QoS.
2. Set traffic rule.
3. Assign the precedence or add marker for different stream.

IP QoS: ☒ Disable ☐ Enable

Apply

Step 1: Enable IP QoS and click **Apply** to enable IP QoS function.

Step 2: Click **add rule** to add a new IP QoS rule.

The page shown in the following figure appears.

IP QoS

Entries in the table are used to assign the precedence for each incoming packet according to the specified policy.
The procedure for configuring quality of service (QoS) is as follows:
1. Enable QoS.
2. Set traffic rule.
3. Assign the precedence or add marker for different stream.

IP QoS: ☐ Disable ☒ Enable

QoS Policy:

Schedule Mode:

QoS Rule List:

Stream Rule							Behavior				
Src IP	Src Port	Dest IP	Dest Port	Proto	Phy Port	Prior	IP Preced	IP ToS	802.1p	WAN If	Sel
<input type="button" value="Add Rule"/> <input type="button" value="Delete"/> <input type="button" value="Delete All"/>											

Add QoS Rule

Source IP: Source Mask:

Destination IP: Destination Mask:

Source Port: Destination Port:

Protocol: Physical Port:

Set Priority:

☐ Insert or Modify QoS Mark

The following table describes the parameters and buttons of this page:

Field	Description
IP QoS	Select to enable or disable IP QoS function. You need to enable IP QoS if you want to configure the parameters of this page
QoS Policy	You can choose stream based , 802.1p based , or DSCP based
Schedule Mode	You can choose strict prior or WFQ (4:3:2:1)
Source IP	The IP address of the source data packet
Source Mask	The subnet mask of the source IP address
Destination IP	The IP address of the destination data packet
Destination Mask	The subnet mask of the destination IP address
Source Port	The port of the source data packet
Destination Port	The port of the destination data packet
Protocol	The protocol responds to the IP QoS rules. You can choose TCP , UDP , or ICMP
Physical Port	The LAN interface responds to the IP QoS rules
Set priority	The priority of the IP QoS rules. P0 is the highest priority and P3 is the lowest
IP Precedence	You can choose from 0 to 7 define the priority in the ToS of the IP data packet
IP ToS	The type of IP ToS for classifying the data package You can choose Normal Service , Minimize Cost , Maximize Reliability , Maximize Throughput , or Minimize Delay
802.1p	You can choose from 0 to 7
delete	Select a row in the QoS rule list and click it to delete the row
delete all	Select all the rows in the QoS rule list and click it to delete the rows

3.6.5 SNMP

Choose **Advance > SNMP**, the page shown in the following figure appears. You can configure the SNMP parameters.

PLANET Networking & Communications
ADSL 2/2+ Router

SNMP | Wizard | Status | Network | Service | **Advance** | Admin | Diagnostic

Bridge Setting | Routing | Port Mapping | QoS | **SNMP** | Others

SNMP Protocol Configuration

This page is used to configure the Simple Network Management Protocol (SNMP). In this page, you can modify the settings of system description, trap IP address, and community name and so on.

☒ Enable SNMP

System Description: ADSL 2/2+ Router

System Contact:

System Name: ADE-3410

System Location:

Trap IP Address:

Community Name (Read-only): public

Community Name (Read-Write): public

Apply Changes Reset

The following table describes the parameters of this page:

Field	Description
Enable SNMP	Select it to enable SNMP function. You need to enable SNMP, and then you can configure the parameters of this page
Trap IP Address	Enter the trap IP address. The trap information is sent to the corresponding host
Community name (read-only)	The network administrators must use this password to read the information of this router
Community name (write-only)	The network administrators must use this password to configure the information of the router

3.6.6 Others

Choose **Advance > Others**, the page shown in the following figure appears.

PLANET Networking & Communications
ADSL 2/2+ Router

Others | Wizard | Status | Network | Service | **Advance** | Admin | Diagnostic

Bridge Setting | Routing | Port Mapping | QoS | SNMP | **Others**

Other Advanced Configuration

Here you can set other miscellaneous advanced settings.

Half Bridge: When enable Half Bridge, that PPPoE(PPPoA)'s connection type will set to continuous.

Half Bridge: ☒ Disable ☐ Enable

Interface:

Apply Changes Reset

3.7 Admin

In the navigation bar, click **Admin**. The **Admin** page that is displayed contains **Commit/Reboot**, **Upgrade**, **System Log**, **Password** and **Time Zone**.

3.7.1 Commit/Reboot

Choose **Admin > Commit/Reboot**, the page shown in the following figure appears. You can set the router reset to the default settings or set the router to commit the current settings.

The screenshot shows the PLANET ADSL 2/2+ Router web interface. The top navigation bar includes 'Admin', 'Wizard', 'Status', 'Network', 'Service', 'Advance', 'Admin' (highlighted), and 'Diagnostic'. Below this, a sub-menu shows 'Commit/Reboot', 'Upgrade', 'System Log', 'Password', and 'Time Zone'. The main content area is titled 'Commit/Reboot' and contains the text: 'This page is used to save the current configuration or restore to the factory default configuration.' Below this text is a 'Reboot from:' dropdown menu with 'Save the current configuration' selected. At the bottom are three buttons: 'Commit Changes', 'Reset', and 'Reboot'.

The following table describes the parameters and button of this page:

Field	Description
Reboot from	You can choose Save Current Configuration or Factory Default Configuration . <ul style="list-style-type: none">● Save Current Configuration: Reset to the factory default settings, and then reboot the router● Factory Default Configuration: Save the current settings, and then reboot the router
Reboot	Click it to reboot the router

3.7.2 Upgrade

Choose **Admin > Upgrade**. The **Upgrade** page that is displayed contains **Upgrade Firmware** and **Backup/Restore**.



Caution:

Do not turn off the router or press the Reset button while the procedure is in progress.

3.7.2.1 Upgrade Firmware

Click **Upgrade Firmware** in the left pane, the page shown in the following figure appears. In this page, you can upgrade the firmware of the router.

The screenshot shows the PLANET ADSL 2/2+ Router web interface. The top navigation bar includes 'Upgrade', 'Wizard', 'Status', 'Network', 'Service', 'Advance', 'Admin' (highlighted), and 'Diagnostic'. Below this, a sub-menu shows 'Commit/Reboot', 'Upgrade', 'System Log', 'Password', and 'Time Zone'. The main content area is titled 'Upgrade Firmware' and contains the text: 'This page is used to upgrade the firmware to a new version. System will reboot after the file is uploaded.' Below this text is a red warning message: 'Caution: Do not power off the device during uploading. Otherwise, it may crash the system.' Below the warning is a 'Select File:' label, a text input field, and a 'Browse...' button. At the bottom are two buttons: 'Upload' and 'Reset'.

The following table describes the parameters and button of this page:

Field	Description
Select File	Click Browse to select the firmware file
Upload	After selecting the firmware file, click Upload to starting upgrading the firmware file
Reset	Click it to starting selecting the firmware file

3.7.2.2 Backup/Restore

Click **Backup/Restore** in the left pane, the page shown in the following figure appears. You can backup the current settings to a file and restore the settings from the file that was saved previously.

The following table describes the parameters and button of this page:

Field	Description
Save Settings to File	Click it, and select the path. Then you can save the configuration file of the router
Load Settings from File	Click Browse to select the configuration file
Upload	After selecting the configuration file of the router, click Upload to start uploading the configuration file of the router

3.7.3 System Log

Choose **Admin > System Log**, the page shown in the following figure appears. In this page, you can enable or disable system log function and view the system log.

3.7.4 Password

Choose **Admin > Password**, the page shown in the following figure appears. By default, the user name and password are **admin** and **admin** respectively. The common user name and password are **user** and **user** respectively.

Planet Networking & Communication **ADSL 2/2+ Router**

Password Wizard Status Network Service Advance Admin Diagnostic

Commit/Reboot Upgrade System Log Password Time Zone

Password

User Account Configuration

This page is used to add user account to access the web server of ADSL Router. Empty user name or password is not allowed.

User Name:

Privilege:

Old Password:

New Password:

Confirm Password:

User Account Table:

Select	User Name	Privilege
<input type="radio"/>	admin	root
<input type="radio"/>	user	user

The following table describes the parameters of this page:

Field	Description
User Name	You can create your account at this item
Privilege	Choose the access permission, you can choose User and root
Old Password	If you want to change the password, select the account and enter the old password
New Password	Enter the password to which you want to change the old password
Confirmed Password	Enter the new password again
User Account Table	Select it and you can change the above parameter.

3.7.5 Time Zone

Choose **Admin > Time Zone**, the page shown in the following figure appears. You can configure the system time manually or get the system time from the time server.

Planet Networking & Communication **ADSL 2/2+ Router**

Time Zone Wizard Status Network Service Advance Admin Diagnostic

Commit/Reboot Upgrade System Log Password Time Zone

Time Zone

System Time Configuration

This page is used to configure the system time and Network Time Protocol (NTP) server. In this page, you can modify the settings or view some information of the system time and NTP parameters.

System Time: 1970 year Jan month 5 day 2 hour 35 min 58 sec

DayLight: LocalTIME

NTP Configuration:

State: ☒ Disable ☐ Enable

Primary Server: 220.130.158.52

Secondary Server:

Interval: Every 1 hours

Time Zone: (GMT) Gambia, Liberia, Morocco, England

Local Time: Mon Jan 5 2:35:58 1970

NTP Start:

The following table describes the parameters of this page:

Field	Description
System Time	Set the system time manually
NTP Configuration	
State	Select enable or disable NTP function. You need to enable NTP if you want to configure the parameters of NTP
Server	Set the primary NTP server manually
Server2	Set the secondary NTP server manually
Time Zone	Choose the time zone in which area you are from the drop down list

3.8 Diagnostic

In the navigation bar, click **Diagnostic**. The **Diagnostic** page that is displayed contains **Ping**, **ATM Loopback**, **ADSL** and **Diagnostic Test**.

3.8.1 Ping

Choose **Diagnostic** > **Ping**. The page shown in the following figure appears.

The following table describes the parameter and button of this page:

Field	Description
Host	Enter the valid IP address or domain name
Run Ping	Click it to start to Ping

3.8.2 ATM Loopback

Choose **Diagnostic** > **ATM Loopback**. The page shown in the following figure appears. In this page, you can use VCC loopback function to check the connectivity of the VCC. The ATM loopback test is useful for troubleshooting problems with the DSLAM and ATM network.

Click **Run Lookback** to start testing.

3.8.3 ADSL

Choose **Diagnostic > ADSL**. The page shown in the following figure appears. It is used for ADSL tone diagnostics.

The screenshot shows the PLANET ADSL 2/2+ Router web interface. The top navigation bar includes tabs for ADSL, Wizard, Status, Network, Service, Advance, Admin, and Diagnostic. The left sidebar has a link for ADSL. The main content area is titled "Diagnostic ADSL" and contains a "Start" button. Below the button are two tables for displaying test results.

	Downstream	Upstream
Hlin Scale		
Loop Attenuation(dB)		
Signal Attenuation(dB)		
SNR Margin(dB)		
Attainable Rate(Kbps)		
Output Power(dBm)		

Tone Number	H.Real	H.Image	SNR	OLN	Hlog
0					
1					
2					
3					

Click **Start** to start ADSL tone diagnostics.

3.8.4 Diagnostic Test

Choose **Diagnostic > Diagnostic Test**, the page shown in the following figure appears. In this page, you can test the DSL connection. You can also view the LAN status connection and ADSL connection.

The screenshot shows the PLANET ADSL 2/2+ Router web interface. The top navigation bar includes tabs for Diagnostic Test, Wizard, Status, Network, Service, Advance, Admin, and Diagnostic. The left sidebar has a link for Diagnostic Test. The main content area is titled "Diagnostic Test" and contains a "Run Diagnostic Test" button. Below the button is a dropdown menu to select the interface.

Select the Interface: a0

Run Diagnostic Test

Click **Run Diagnostic Test** to start testing.

Appendix A: Glossary

Address mask

A bit masks select bits from an Internet address for subnet addressing. The mask is 32 bits long and selects the network portion of the Internet address and one or more bits of the local portion. Sometimes it called subnet mask.

AAL5

ATM Adaptation Layer - This layer maps higher layer user data into ATM cells, making the data suitable for transport through the ATM network.

ADSL

Asymmetric digital subscriber line.

ATM

Asynchronous Transfer Mode - A cell-based data transfer technique in which channel demand determines packet allocation. ATM offers fast packet technology, real time, and demand led switching for efficient use of network resources.

AWG

American Wire Gauge - The measurement of thickness of a wire.

Bridge

A device connects two or more physical networks and forward packets between them. Bridges can usually be made to filter packets, that is, to forward only certain traffic. Related devices are repeaters which simply forward electrical signals from one cable to the other and full-fledged routers which make routing decisions based on several criteria.

Broadband

Characteristic of any network multiplexes independent network carriers onto a single cable. Broadband technology allows several networks to coexist on one single cable; traffic from one network does not interfere with traffic from another. Broadcast a packet delivery system where a copy of a given packet is given to all hosts attached to the network. Example: Ethernet.

CO

Central Office. Refers to equipment located at a Telco or service provider's office.

CPE

Customer Premises Equipment located in a user's premises.

DHCP (Dynamic Host Configuration Protocol)

DHCP is software that automatically assigns IP addresses to client stations logging onto a TCP/IP network. DHCP eliminates having to manually assign permanent IP addresses to every device on your network. DHCP software typically runs in servers and is also found in network devices such as Routers.

DMT

Discrete Multi-Tone frequency signal modulation.

Downstream rate

The line rate for return messages or data transfers from the network machine to the user's premises machine.

DSLAM

Digital Subscriber Line Access Multiplex.

Dynamic IP Addresses

A dynamic IP address is an IP address that is automatically assigned to a client station (computer, printer, etc.) in a TCP/IP network. Dynamic IP addresses are typically assigned by a DHCP server, which can be a computer on the network or another piece of hardware, such as the Router. A dynamic IP address may change every time your computer connects to the network.

Encapsulation

The technique layer protocols in which a layer adds header information to the protocol data unit (PDU) from the layer above. As an example, in Internet terminology, a packet would contain a header from the physical layer, followed by a header from the network layer (IP), followed by a header from the transport layer (TCP), and followed by the application protocol data.

Ethernet

One of the most common local area network (LAN) wiring schemes, Ethernet has a transmission rate of 10 Mbps.

FTP

File Transfer Protocol. The Internet protocol (and program) transfer files between hosts.

Hop count

A measure of distance between two points on the Internet. It is equivalent to the number of gateways that separate the source and destination.

HTML

Hypertext Markup Language - The page-coding language for the World Wide Web.

HTML browser

A browser used to traverse the Internet, such as Netscape or Microsoft Internet Explorer.

HTTP

Hypertext Transfer Protocol - The protocol carry world-wide-web (www) traffic between a www browser computer and the www server being accessed.

ICMP

Internet Control Message Protocol - The protocol handles errors and control messages at the IP layer. ICMP is actually part of the IP protocol.

Internet address

An IP address is assigned in blocks of numbers to user organizations accessing the Internet. These addresses are established by the United States Department of Defense's Network Information Center. Duplicate addresses can cause major problems on the network, but the NIC trusts organizations to use individual addresses responsibly. Each address is a 32-bit address in the form of x.x.x.x where x is an eight- bit number from 0 to 255. There are three classes: A, B and C, depending on how many computers on the site are likely to be connected.

Internet Protocol (IP)

The network layer protocol for the Internet protocol suite.

IP address

The 32-bit address assigned to hosts that want to participate in a TCP/IP Internet.

ISP

Internet service provider - A company allows home and corporate users to connect to the Internet.

MAC

Media Access Control Layer - A sub-layer of the Data Link Layer (Layer 2) of the ISO OSI Model responsible for media control.

MIB

Management Information Base - A collection of objects can be accessed via a network management protocol, such as SNMP and CMIP (Common Management Information Protocol).

NAT

Network Address Translation - A proposal for IP address reuse, where the local IP address is mapped to a globally unique address.

NVT

Network Virtual Terminal

PAP

Password Authentication Protocol

PORT

The abstraction used in Internet transport protocols to distinguish among multiple simultaneous connections to a single destination host.

POTS

Plain Old Telephone Service - This is the term describe basic telephone service.

PPP

Point-to-Point-Protocol - The successor to SLIP, PPP provides router-to-router and host-to-network connections over both synchronous and asynchronous circuits.

PPPoE

PPP over Ethernet is a protocol for connecting remote hosts to the Internet over an always-on connection by simulating a dial-up connection.

Remote server

A network computer allows a user to log on to the network from a distant location.

RFC

Request for Comments - Refers to documents published by the Internet Engineering Task Force (IETF) proposing standard protocols and procedures for the Internet. RFC can be found at www.ietf.org.

Route

The path that network traffic takes from its source to its destination. The route a datagram may follow can include many gateways and many physical networks.

In the Internet, each datagram is routed separately.

Router

A system is responsible for making decisions about which of several paths network (or Internet) traffic will follow. To do this, it uses a routing protocol to gain information about the network and algorithms to choose the best route based on several criteria known as "routing metrics".

Routing Table

Information stored within a router that contains network path and status information. It is used to select the most appropriate route to forward information along.

Routing Information Protocol

Routers periodically exchange information with one another so that they can determine minimum distance paths between sources and destinations.

SNMP

Simple Network Management Protocol - The network management protocol of choice for TCP/IP-based Internet.

SOCKET

- (1) The Berkeley UNIX mechanism for creating a virtual connection between processes.
- (2) IBM term for software interfaces that allow two UNIX application programs to talk via TCP/IP protocols.

Spanning-Tree Bridge Protocol (STP)

Spanning-Tree Bridge Protocol (STP) - Part of an IEEE standard. A mechanism for detecting and preventing loops from occurring in a multi-bridged environment. When three or more LAN's segments are connected via bridges, a loop can occur. Because of a bridge forwards all packets that are not recognized as being local, some packets can circulate for long periods of time, eventually degrading system performance. This algorithm ensures only one path connects any pair of stations, selecting one bridge as the 'root' bridge, with the highest priority one as identifier, from which all paths should radiate.

Spoofing

A method of fooling network end stations into believing that keep alive signals have come from and returned to the host. Polls are received and returned locally at either end

Static IP Address

A static IP address is an IP address permanently assigned to computer in a TCP/IP network. Static IP addresses are usually assigned to networked devices that are consistently accessed by multiple users, such as Server PCs, or printers. If you are using your Router to share your cable or DSL Internet connection, contact your ISP to see if they have assigned your home a static IP address. You will need that address during your Router's configuration.

Subnet

For routing purposes, IP networks can be divided into logical subnets by using a subnet mask. Values below those of the mask are valid addresses on the subnet.

TCP

Transmission Control Protocol - The major transport protocol in the Internet suite of

protocols provides reliable, connection-oriented full-duplex streams.

TFTP

Trivial File Transfer Protocol. A simple file transfer protocol (a simplified version of FTP) that is often boot diskless workstations and other network devices such as routers over a network (typically a LAN).

Telnet

The virtual terminal protocol in the Internet suite of protocols - Allows users of one host to log into a remote host and act as normal terminal users of that host.

Transparent bridging

The intelligence necessary to make relaying decisions exists in the bridge itself and is thus transparent to the communicating workstations. It involves frame forwarding, learning workstation addresses, and ensuring no topology loops exist (in conjunction with the Spanning-Tree algorithm).

UDP

User Datagram Protocol - A connectionless transport protocol that runs on top of TCP/IP's IP. UDP, like TCP, uses IP for delivery; however, unlike TCP, UDP provides for exchange of datagram without acknowledgments or guaranteed delivery. Best suited for small, independent requests, such as requesting a MIB value from an SNMP agent, in which first setting up a connection would take more time than sending the data.

UNI signaling

User Network Interface signaling for ATM communications.

Virtual Connection (VC)

A link that seems and behaves like a dedicated point-to-point line or a system that delivers packets in sequence, as happens on an actual point-to-point network. In reality, the data is delivered across a network via the most appropriate route. The sending and receiving devices do not have to be aware of the options and the route is chosen only when a message is sent. There is no pre-arrangement, so each virtual connection exists only for the duration of that one transmission.

WAN

Wide area network - A data communications network that spans any distance and is usually provided by a public carrier (such as a telephone company or service provider).

Important Note

According to Annex3 of the ERC/REC 70-03 publication, the use of Wideband Data Transmission systems has the following National Restrictions:

Frequency range: 2400-2483.5MHz

Country	Restriction	Reason/Remark
France	Outdoor use limited to 10 mW e.i.r.p. within the band 2454-2483.5 MHz	Military Radiolocation use. Refarming of the 2.4 GHz band has been ongoing in recent years to allow current relaxed regulation. Full implementation planned 2012
Italy		If used outside of own premises, general authorization is required
Luxembourg	None	General authorization required for network and service supply(not for spectrum)
Norway	Implemented	This subsection does not apply for the geographical area within a radius of 20km from the centre of Ny-Alesund
Russian Federation		Only for indoor applications