

User's Manual



**Industrial PoE Plus Outdoor
IR IP Camera**

► ICA-2250VT



Copyright

Copyright © 2013 by PLANET Technology Corp. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of PLANET.

PLANET makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not PLANET, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, PLANET reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

All brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio technician for help.

FCC Caution

To assure continued compliance, for example, use only shielded interface cables when connecting to computer or peripheral devices. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Federal Communication Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20 cm (8 inches) during normal operation.

Safety

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacturer must therefore be followed at all times to ensure the safe use of the equipment.

CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

WEEE Regulation



To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste; they should be collected separately.

Revision

User's Manual for PLANET Industrial PoE Plus Outdoor IR IP Camera

Model: ICA-2250VT

Rev: 1.00 (December.2013)

Part No. EM-ICA2250VT

Table of Contents

Chapter 1.	Product Introduction.....	6
1.1.	Package Contents.....	6
1.2	Overview.....	6
1.3	Features.....	8
1.4.	Product Specifications.....	9
Chapter 2.	Hardware Interface.....	11
2.1	Physical Descriptions.....	11
2.2	Hardware Installation	14
2.3	Initial Utility Installation.....	19
2.4	Preparation	21
2.4.1	Search and View by PLANET IP Wizard II.....	21
2.4.2	Configure Network by PLANET IP Wizard II.....	23
2.5	Using UPnP of Windows XP or 7	25
2.5.1	Windows XP	25
2.5.2	Windows 7	29
2.6	Setup ActiveX to use the Internet Camera	30
2.6.1	Internet Explorer 6 for Windows XP	31
2.6.2	Internet Explorer 7 for Windows XP	31
2.6.3	Internet Explorer 7 for Windows Vista.....	32
Chapter 3.	Web-based Management.....	33
3.1.	Introduction	33
3.2.	Connecting to Internet Camera	33
3.3	Live View	35
3.4	ActiveX Control	37
3.4.1	Digital Zoom	38
3.4.2	Snapshot.....	38
3.4.3	Record.....	38
3.4.4	Volume	39
3.4.5	Statistics.....	40
3.4.6	About	40
3.5	Network.....	40
3.5.1	Network	40
3.5.2	IPv6.....	43
3.5.3	HTTPS	43
3.5.4	DDNS server.....	44
3.5.5	PPPoE.....	45
3.5.6	Streaming.....	46
3.5.7	UPnP	47
3.5.8	Bonjour	48
3.5.9	IP Filter.....	49
3.6	Camera	50
3.6.1	Picture	50
3.6.2	Privacy Mask.....	53
3.6.3	PTZ Setting	54
3.6.4	Preset Setting	55
3.6.5	Tour Setting	55
3.7	System.....	56
3.7.1	System	56


3.7.2 Date & Time.....	57
3.7.3 Maintenance.....	58
3.8 Video	60
3.8.1 Common	60
3.8.2 Overlay Image.....	61
3.8.3 Video Profile	62
3.8.4 ONVIF Profile.....	63
3.8.5 ROI	64
3.8.6 AOI.....	65
3.9 Audio	66
3.10 User Privilege Access	66
3.11 Protocol.....	67
3.11.1 ONVIF	67
3.11.2 SNMP	68
3.12 Mail	69
3.13 Event Detection	71
3.13.1 Motion Detection	71
3.13.2 Camera Tampering	72
3.13.3 Audio Detection	72
3.14 Storage	73
3.14.1 SD Card.....	73
3.14.2 SAMBA Server.....	74
3.15 Continuous Recording	75
3.16 Recording List.....	75
3.17 Event Server	76
3.17.1 FTP Server.....	76
3.17.2 TCP Server.....	77
3.17.3 HTTP Server.....	78
3.17.4 SAMBA Server.....	79
3.18 Event Schedule.....	80
3.18.1 Setting	80
3.18.2 Record	84
3.18.3 Port Status.....	84
Appendix A: PING IP Address	85
Appendix B: 3GPP Access	86
Appendix C: Bandwidth and Video Size Estimation	87
Appendix D: DDNS Application.....	88
Appendix E: Configuring Port Forwarding Manually	89
Appendix F: Power Line Frequency.....	91
Appendix G: Troubleshooting & Frequently Asked Questions	92

Chapter 1. Product Introduction

1.1. Package Contents

The package should contain the following items:

- Camera Unit x 1
- User's Manual CD x 1
- Quick Installation Guide x 1
- Wall Mounting Kit x 1
- Wall Mounter x 1



1. If any of the above items are missing, please contact your dealer immediately.
2. Using the power supply that is not the one included in the Internet Camera packet will cause damage and void the warranty for this product.

1.2 Overview

Superb, Outdoor Full HD Professional Surveillance


PLANET ICA-2250VT is a Full HD camera for a wide range of video surveillances over IP networks. It supports H.264, MPEG-4, and M-JPEG compression formats to deliver excellent picture quality in 1080P resolutions at 30 frames per second (fps). Incorporating the new Exmor™ CMOS image sensor from Sony, which is specially designed for surveillance applications, this camera provides high quality images under all lighting conditions. Superb 1080P video quality is provided with progressive scan in multiple individual streams, 16:9 aspect ratio and frame rate. The ICA-2250VT offers high-performing video surveillance in almost any difficult environment. Its IP66 and -40 to 75 degrees C operating temperature features help to protect the camera body against rain and dust, and ensures operation under extreme weather conditions, which make it an ideal solution for outdoor applications, e.g. surveillance of buildings, roads, parking areas, garages, railway stations and airports.

Full HD Resolution



Day & Night Surveillance

The ICA-2250VT features an automatic, removable infrared-cut filter to provide color video when there is sufficient light, and black/white video in dark conditions. The ICA-2250VT is able to maintain clear images 24 hours a day.



Extraordinary Image quality

Together with powerful image processing attributes like Wide Dynamic Range (WDR) and 3-Dimension Noise Reduction (3DNR) technology, the ICA-2250VT is able to filter the intense backlight surrounding a subject and remove noises from video signal. Thus, an extremely clear and exquisite picture quality can be produced even under any challenging lighting conditions.



Advanced Event Management

The ICA-2250VT supports a number of advanced features that enhance the camera flexibility and capabilities. The Auto-Iris function improves the image quality and avoid over exposure. The AV output enables 2-way audio communication. The embedded micro SD/SDHC card slot facilitates the image storage locally. It also provides the RS-485 interface for an optional pan/tilt enclosure connection to effectively perform pan/tilt management. The input/output interface of the ICA-2250VT can connect to external devices such as door sensors and relays to activate light or close doors automatically.

Flexible Installation and Power Functionality

The ICA-2250VT incorporates 802.3at Power over Ethernet standard so it can be powered via the network cable, eliminating the need for power cables and reducing installation costs. The ICA-2250VT is ONVIF compliant and therefore is interoperable with other brands in the market. It also includes the 64 channel central management software for efficient surveillance monitoring. The ICA-2250VT is indisputably the top choice for reliable and high performance surveillance.

Composite Outdoor-ready and Camera

The ICA-2250VT is an out-of-the-box, full HD IP camera that is designed to sustain severe weather conditions. It is a unique and competitive camera in the IP CCTV market, with features such as IP66 housing for rain/dust protection and -40 to 75°C operation. It comes with a built-in heater and blower in the box. It's ideal for cost efficient 24/7 area or perimeter surveillance of all security applications such as roads, tunnels and airports.



1.3 Features

➤ **Camera**

- 1 / 2.9" 2MP Sony Exmor Image Sensor
- 3.1~8 mm Vari-focal, Auto-iris Lens
- 0.5 lux Minimum Illumination at F1.4
- Maximum resolution 1920 x 1080
- Removable IR-cut Filter for Day & Night Function
- CS or C-mount Adjustment Ring for Flexible Lens Installation

➤ **Video / Audio**

- H.264 / MPEG-4 and M-JPEG video compression simultaneously
- Simultaneous multi-stream support
- H.264 high profile, main profile and baseline
- Max. resolution 1080P at 30fps
- 3DNR to improve picture quality at low Lux
- WDR Enhancement to enhance visibility under extremely bright or dark environments
- 2-way audio support with enhanced audio quality

➤ **Network and Configuration**

- Compliant with IEEE 802.3at PoE interface for flexible deployment
- Auto MDI/MDI-X supported
- Supports IPv6 protocol in addition to the standard IP protocol version 4 (IPv4)
- RTSP / UPnP / 3GPP / HTTPS protocols selectable

➤ **Easy Installation & Management**

- ONVIF compliant
- Built-in Samba client for NAS
- SD Card Local Video Recording Supported
- 3GPP for 3G mobile remote applications
- RS-485 interface for P/T scanner control
- Digital Input / Output for integration with sensors and alarms
- Cam Viewer 3 central management software supported
- Fan and heater with fully automatic intelligent control
- Industrial design with -40 to 75 degrees C operating temperature
- IP66 outdoor classifications with cable management bracket for rigorous environment

1.4. Product Specifications


Model	ICA-2250VT
Camera	
Image Device	2 Mega-pixel Sony Exmor image sensor
Lens	Vari-focal 3.1~8mm, F1.4 DC Auto-iris, CS mount Mechanical IR Cut Filter Angle of view (horizontal field): 79.3 x 29.8 degrees
Min Illumination	0.5 lux @ F1.4
Effective Pixels	1920 x 1080 pixels
IR LED	24 pcs / distance up to 35 meters
Image	
Video Compression	H.264 / MPEG-4 / M-JPEG
Video Resolution	1080P mode H.264: 1080P / 1280 x 720 / 640 x 360 / 320 x 180 M-JPEG: 1080P / 1280 x 720 / 640 x 360 / 320 x 180 MPEG4: 1280 x 720 / 640 x 360 / 320 x 180 720P mode H.264: 1280 x 720 / 640 x 360 / 320 x 180 / 160 x 80 M-JPEG: 1280 x 720 / 640 x 360 / 320 x 180 / 160 x 80 MPEG4: 640 x 360 / 320 x 180 / 160 x 80
Frame Rate	Up to 30fps for all resolutions
Image Setting	AE, AWB 3D Noise reduction Digital WDR WDR Color, brightness, sharpness, contrast Mirror / Flip 7 Privacy Masks Text, time and date overlay Overlay image on video
Streaming	Simultaneously multi-profile streaming Streaming over UDP, TCP, or HTTP M-JPEG streaming over HTTP (server push) Supports 3GPP mobile surveillance (MPEG4) Controllable frame rate and bandwidth Constant and variable bit rate (MPEG4 / H.264) ROI
Audio	
Audio Streaming	2-way Audio
Audio Compression	RTSP: G.711 64kbps, G.726 32kbps 3GPP: AMR
Microphone	External microphone input
Audio Output	Adjustable audio output gain
Network and Configuration	
Standard	IEEE802.3 10Base-T IEEE802.3u 100Base-TX IEEE802.3ab 1000Base-T IEEE802.3at Power over Ethernet
Protocol	IPv4, IPv6, TCP/IP, UDP, HTTP, HTTPS, SMTP, FTP, NTP, DNS, DDNS, DHCP, ARP, Bonjour, UPnP, RTSP, RTP, RTCP, IGMP, PPPoE, 3GPP, ICMP, Samba
Security	Password protection, IP address filtering, HTTPS encrypted data transmission, user access log
Users	20 clients on-line monitoring at the same time

System Integration	
Application Programming Interface	Open API for software integration ONVIF Compliant
Alarm Triggers	Intelligent video motion detection and external input
Alarm Events	File upload via FTP, Samba to NAS, SD card or email Notification via email, HTTP, and TCP External output activation Audio alerting output Pre and post-alarm buffering
General	
Power Requirements	IEEE 802.3at Class 4
Fan / Heater Control Temperature	Heater: On: 15 / Off: 25 degrees C Fan: On: 35 / Off: 25 degrees C
Power Consumption	19.8W max.
Protection Class	IP-66 classification with weatherproof feature
Operating Temperature	-40 ~ 75 degrees C
Operating Humidity	20 ~ 80% (non-condensing)
Weight (include LENS)	2.89kg
Dimensions (W x D x H)	145 x 406 x 109 mm
Emission	CE, FCC
Connectors	10/100/1000Mbps Ethernet, RJ-45 DC power jack Terminal block for 1 alarm input and 1 output RS-485 interface for pan/tilt scanners control External Mic input Audio output BNC video output Micro SD/SDHC card (Max 32GB, Class 6) Factory default reset


Chapter 2. Hardware Interface

2.1 Physical Descriptions

Inside View of ICA-2250VT



Rear View



Interface	Description
DC Power (Power Jack)	<p>The input power is DC 12V, 1A.</p> <p> The power supply from 802.3at PoE module.</p>
LAN (RJ-45 socket)	<p>Connect to PC or Switch.(For connection to 10Base-T / 100Base-TX and 1000 Base-T Ethernet cabling)</p> <p>This Ethernet port built auto-negotiation protocol can detect or negotiate the transmission speed of the network automatically. Please use CAT-5 cable to connect the Network Camera to a 100Mbps Fast Ethernet network switch or hub.</p> <p>Power LED (orange color)</p> <p>This LED is used to indicate whether DC power is on or not.</p> <p>LAN LED (green color)</p> <p>This LED will be flashing while network accessing via Ethernet</p>
Audio Out (Audio Output)	Connect a loud speaker to the IP Camera. This is for voice alerting and two-way audio.
Mic In (Microphone Input)	Connect a microphone to the IP Camera.
Micro SD (Micro SD Card Slot)	User can insert a micro SD card into this slot for recording.
BNC Connector (Video Output)	The Network Camera also provides composite video output. The video output function is only for easy installation to check view angle and focus. Furthermore, only "720p Mode" supports this function.


RST (Factory Default)	This button is used to restore all the factory default settings.
DI/DO, RS-485	The 6-pin terminal block includes 1 input ports and 1 output ports, and RS-485 D+ and D-.

The Camera provides a terminal block with 6 pins of connectors for DI, DO, and RS485. Please refer below for more information.


Name	Number	Function
12VDC	1	DC 12V (50mA maximum)
DI	2	Digital signal input
GND	3	GND
DO	4	Digital signal output
485+	5	RS485 data +
485-	6	RS485 data -

2.2 Hardware Installation


2.2.1 Use the wrench from the wall mounting kit to counterclockwise release the screw and protective cap.



2.2.2 Slide an RJ-45 cable without its plug through the stand and the protective cap. Then fix the RJ-45 plug and connect it to the connector of the PoE module. Please note that the whole RJ-45 cable (with the plug) cannot go through the protective cap. When the setup is completed, user can use PoE tester to test PoE module to check whether the LED works or not.




2.2.3 Use the wrench from the wall mounting kit to clockwise tighten the screw and protective cap.




Note Two screws of shield will effects camera's waterproof. Please notice it.

2.2.4 Use the wrench to tighten the four screws.




2.2.5 After the above steps have been done, place the ICA-2250VT on the wall with the four screws tightened.



2.2.6. Network Installation

1. Connect an Ethernet cable


Connect the LAN cable on the camera to the network device (hub or switch).



If there is an IEEE802.3at PoE switch in your network, you can connect the camera LAN cable to this PoE switch to obtain power. The power adapter is unnecessary when Internet camera is connected to a PoE switch.

2. Attach the power supply

Plug in power adapter and connect to power source. After power on, the camera will start to operate.



1. Only use the power adapter supplied with Internet camera; otherwise, the product may be damaged.
2. The power adapter is unnecessary when Internet camera is connected to a PoE switch. Otherwise, the product may be damaged when Internet camera is connected to a POE switch and power adapter simultaneously.

3. Attach BNC connector


Connect the video BNC connector to a monitor set, if necessary, to check camera viewing angle and focus.

4. Attach Speaker to camera (optional)

If user needs both video stream and audio stream, then the speaker should be attached to camera.

5. PoE (Power over Ethernet)



Power over Ethernet (PoE) is a technology that integrates power into a standard LAN infrastructure. It enables power to be provided to the network device, such as an IP phone or a network camera, using the same cable as that used for network connection. It eliminates the need for power outlets at the camera locations and enables easier application of uninterruptible power supplies (UPS) to ensure 24 hours a day, 7 days a week operation. The IP Camera requires a connectivity to IEEE802.3at Power over Ethernet Switch (PSE) or 802.3at Injector for the system includes camera itself, infrared LEDs, internal blower, and heater.



2.3 Initial Utility Installation

This chapter shows how to quickly set up your H.264 camera. The camera is with the default settings. However to help you find the networked camera quickly the windows utility PLANET IP Wizard II can search the cameras in the network that can help you to configure some basic setting before you start advanced management and monitoring.


1. Insert the bundled CD into the CD-ROM drive to launch the auto-run program. Once completed, a welcome menu screen will appear.
2. Click the “IP Wizard II” hyperlink; you will see the dialog box as below.




3. The “Welcome to the Install Shield Wizard for PLANET IP Wizard II” prompt will display on the screen and click “Next” to continue.



4. Please click “**Next**” to install with original settings, or you may click “**Change...**” button to modify the install folder and then press “Next” to continue.



5. Please click “**Install**” to start the installation.



-
6. Please click “**Finish**” to complete the installation and launch program immediately.




2.4 Preparation

When you install the Internet Camera on a LAN environment, you may execute PLANET IP Wizard II to discover camera's IP address and set up related parameters in the camera.


2.4.1 Search and View by PLANET IP Wizard II

When you install the Internet Camera on a LAN environment, you have two easy ways to search your cameras by PLANET IP Wizard II or UPnP discovery. Here is the way to execute PLANET IP Wizard II to discover camera's IP address and set up related parameter in a camera.

Search




When launching the Planet IP Wizard II, a search window will pop up. Planet IP Wizard II is starting to search Internet Cameras on the LAN. The existing devices will be listed below.




View

If Planet IP Wizard II finds Internet Camera, View button will be available. Please select the camera you want to view and click the View button. Then you can see the Video from camera directly. Furthermore, you can double-click the left button of mouse to link to the Internet Camera by browser.




2.4.2 Configuring Network by PLANET IP Wizard II

In case you want to change the IP related parameters of wired interface, please select the Internet Camera you want to configure and click the LAN button. Relative settings will be carried out as shown below.



In case, you do not want to change user name and/or password, then just click "**Submit**" button to perform your setting accordingly. Click "**<<**" button will go back to the previous page.
 If you like to change user name and/or password of the device, just click the check button. Then, the related fields will show up as follows.




After keying in the new user name and password, click “**Submit**” button to perform your setting accordingly. Click “<<” button to go back to the previous page.

2.5 Using UPnP of Windows XP or 7

2.5.1 Windows XP


UPnP™ is short for Universal Plug and Play, which is a networking architecture that provides compatibility among networking equipment, software, and peripherals. This device is an UPnP enabled device. If the operating system, Windows XP, of your PC is UPnP enabled, the device will be very easy to configure. Use the following steps to enable UPnP settings only if your operating system of PC is running Windows XP.




Go to **Start > Settings**, and Click **Control Panel**.




The “**Control Panel**” will display on the screen and double click “**Add or Remove Programs**” to continue.




The “Add or Remove Programs” will display on the screen and click **Add/Remove Widows Components** to continue.




In case, you do not want to change user name and/or password, then just click “**Submit**” button to perform your setting accordingly. Click “<<” button will go back to the previous page. If you like to change user name and/or password of the device, just click the check button. Then, the related fields will show up as follows.




When “Networking Services” displays on the screen, select “**Universal Plug and Play**” and click “**OK**” to continue.



Please click “**Next**” to continue.




The program will start installing the UPnP automatically. You will see the below pop-up screen. Please wait while Setup configures the components.



Please click "**Finish**" to complete the UPnP installation




Double-click "**My Network Places**" on the desktop. When "My Network Places" displays on the screen, double-click the UPnP icon with Internet Camera to view your device in an Internet browser.





2.5.2 Windows 7

Go to **Start > Control Panel > Network and Internet > Network and Sharing Center**, if network discovery is off; click the arrow button  to expand the section.

Click Turn on network discovery, and then click Apply.  If you are prompted for an administrator password or confirmation, type the password or provide confirmation.





2.6 Setting Up ActiveX to Use the Internet Camera

The Internet Camera web pages communicate with the Internet Camera using an ActiveX control. The ActiveX control must be downloaded from the Internet Camera and installed on your PC. Your Internet Explorer security settings must allow for the web page to work correctly. To use the Internet Camera, user must set up his IE browser as follows:

2.6.1 Internet Explorer 6 for Windows XP

From your IE browse → "Tools" → "Internet Options..." → "Security" → "Custom Level...", please set up your "Settings" as follows:

Set the first 3 items

- *Download the signed ActiveX controls*
- *Download the unsigned ActiveX controls*
- *Initialize and script the ActiveX controls not marked as safe and set to Prompt*


By now, you have finished your entire PC configuration for Internet Camera.

2.6.2 Internet Explorer 7 for Windows XP

From your IE browse → "Tools" → "Internet Options..." → "Security" → "Custom Level...", please set up your "Settings" as follows:

Set the first 3 items

- *Allow previously unused ActiveX control to run...*
- *Allows Scriptlets*
- *Automatic prompting for ActiveX controls*




By now, you have finished your entire PC configuration for Internet Camera.

2.6.3 Internet Explorer 7 for Windows Vista


From your IE browse → "Tools" → "Internet Options..." → "Security" → "Internet" → "Custom Level...", please set up your "Settings" as follows:

- Enable "Automatic prompting for ActiveX controls"
- Prompt "Initialize and script active controls not marked...."



From your IE browse → "Tools" → "Internet Options..." → "Security" → "Trusted Sites" → "Custom Level...", please set up your "Settings" as follows:

- Enable "Automatic prompting for ActiveX controls"
- Prompt "Initialize and script active controls not marked...."



By now, you have finished your entire PC configuration for Internet Camera.

Chapter 3. Web-based Management

This chapter provides setup details of the Internet Camera's Web-based Interface.

3.1. Introduction

The Internet Camera can be configured with your Web Browser. Before configuring, please make sure your PC is under the same IP segment with Internet Camera.

3.2. Connecting to Internet Camera

- A. Use the following procedures to establish a connection from your PC to the Internet Camera.
- B. Once connected, you can add the camera to your Browser's Favorites or Bookmarks.



Start the web browser on the computer and type the IP address of the camera.

The Default IP: "<http://192.168.0.20>"



The login window of Internet Camera will appear,

Default login **user name** and **password** are: **admin** and **admin**



If the User Name and Password have been changed with PLANET IP Wizard II, please enter the new User Name and Password here.

After logging on, you should see the following messages at the top of Internet Explorer:



Click on the message, and click **Run Add-on**




When you see this message, click **Run** to install required ActiveX control



After the ActiveX control is installed and run, the first image will be displayed.


You should be able to see the images captured from the Internet Camera on the web page now. For advanced functions, please refer to instructions given in the following chapters.



If you log in the camera as an ordinary user, setting function will be not available. If you log in the camera as the administrator, you can perform all the settings provided within the device.

3.3 Live View

Start-up screen will be as follows whether you are an ordinary user or an administrator.




Function	Description
Monitor Image Section	The image shot by the device is shown here. The date and time are displayed at the top of the window if Text Overlay is enabled.
Video Profile	The camera supports multi-profile for three compressions such as, H264, MPEG-4 and M-JPEG, simultaneously. User can choose the proper and/or preferred profile here.
Full Screen	Click this button to display the image in full-screen mode (using every available space to display the image captured by this camera).
2-way Audio	The Internet Camera supports 2-way audio function. User can choose to enable or disable this function by toggling the icon below.
	 : Disable audio uploading function.  : Enable audio uploading function.

ActiveX Control	The plug-in ActiveX control supports a lot of functions by clicking the left mouse button.																														
	 This feature only supports the ActiveX control within Microsoft® Internet Explorer. Note																														
Setting Menu	<p>This function is a detailed setting of the camera that is only available for administrator to enable to log-in camera.</p> <table border="1"> <thead> <tr> <th style="text-align: center;">Item</th><th style="text-align: center;">Action</th></tr> </thead> <tbody> <tr> <td>Network</td><td>Configure Network settings such as IPv6, ONVIF, DHCP, DDNS, 3GPP, PPPoE and UPnP.</td></tr> <tr> <td>Camera</td><td>Adjust camera parameters.</td></tr> <tr> <td>System</td><td>Configure system information, date & time, maintenance, and view system log file.</td></tr> <tr> <td>Video</td><td>Configure bit rate and frame rate of video profiles.</td></tr> <tr> <td>Audio</td><td>Configure audio parameters.</td></tr> <tr> <td>User</td><td>Set up user name, password and login privilege.</td></tr> <tr> <td>Protocol</td><td>Set up ONVIF and SNMP configuration.</td></tr> <tr> <td>E-Mail</td><td>Set up E-mail configuration.</td></tr> <tr> <td>Object Detection</td><td>Set up Object detection.</td></tr> <tr> <td>Storage</td><td>Status and configuration of SD card and Samba server.</td></tr> <tr> <td>Continuous Recording</td><td>Files list inside the SD Card and Samba server.</td></tr> <tr> <td>Recording List</td><td>Files list inside the SD Card.</td></tr> <tr> <td>Event Server</td><td>Set up FTP/TCP/HTTP/Samba server for event</td></tr> <tr> <td>Event Schedule</td><td>Configure the schedule while event triggered.</td></tr> </tbody> </table>	Item	Action	Network	Configure Network settings such as IPv6, ONVIF, DHCP, DDNS, 3GPP, PPPoE and UPnP.	Camera	Adjust camera parameters.	System	Configure system information, date & time, maintenance, and view system log file.	Video	Configure bit rate and frame rate of video profiles.	Audio	Configure audio parameters.	User	Set up user name, password and login privilege.	Protocol	Set up ONVIF and SNMP configuration.	E-Mail	Set up E-mail configuration.	Object Detection	Set up Object detection.	Storage	Status and configuration of SD card and Samba server.	Continuous Recording	Files list inside the SD Card and Samba server.	Recording List	Files list inside the SD Card.	Event Server	Set up FTP/TCP/HTTP/Samba server for event	Event Schedule	Configure the schedule while event triggered.
Item	Action																														
Network	Configure Network settings such as IPv6, ONVIF, DHCP, DDNS, 3GPP, PPPoE and UPnP.																														
Camera	Adjust camera parameters.																														
System	Configure system information, date & time, maintenance, and view system log file.																														
Video	Configure bit rate and frame rate of video profiles.																														
Audio	Configure audio parameters.																														
User	Set up user name, password and login privilege.																														
Protocol	Set up ONVIF and SNMP configuration.																														
E-Mail	Set up E-mail configuration.																														
Object Detection	Set up Object detection.																														
Storage	Status and configuration of SD card and Samba server.																														
Continuous Recording	Files list inside the SD Card and Samba server.																														
Recording List	Files list inside the SD Card.																														
Event Server	Set up FTP/TCP/HTTP/Samba server for event																														
Event Schedule	Configure the schedule while event triggered.																														
Streaming Protocol	User can select proper streaming protocol according to networking environment.																														
Language	The device could provide multiple languages to meet customer's requirements.																														

Client Setting	Click this button to display the client extra control panel for 2-way Audio and Full Screen.
Video Information	Display video information including video format, resolution, frame rate and bit rate.

3.4 ActiveX Control

The plug-in ActiveX control supports a lot of functions by clicking the left mouse button.



This feature only supports the ActiveX control within Microsoft® Internet Explorer.


On the ActiveX control icon, click the Left Mouse Button, and then a menu pops up. This menu provides features that are unique to the ActiveX control. These features include:

- Digital Zoom
- Snapshot
- Record
- Volume
- Statistics
- About



3.4.1 Digital Zoom

Click **Digital Zoom** to activate this function as above. User can drag or scale the box over the video to adjust zoom ratio and position.



3.4.2 Snapshot

Click **Snapshot** to activate this function. Press **Snapshot** button to take a picture. The image file is saved as JPEG format into your local PC. Select **Browser**, the pop-up window to select the save path and file name prefix, select **OK** to continue.

If you like to retrieve the saved image, select the file to display the saved image by using any one of graph editing tools.



3.4.3 Record

Click **Record** to activate this function. Press **Record** button to start recording. The video file is saved as ASF format into your local PC. While you want to stop it, press **Stop** to stop recording. Select **Browser**, the pop-up window to select the save path and file name

prefix, select **OK** to continue.


After stopping recording, list the file. This file is named as Video_yyyymmddhhmmss.asf

The ASF files can be displayed by the standard Windows Media Player, but it needs the DirectX 9.0 or later version to be installed.




3.4.4 Volume

Click Volume to activate this function. These have two control bars for speaker and microphone volume. Scroll this control bar to adjust the audio attribute. Check the volume mute and it will mute the speaker output.



3.4.5 Statistics

Click Statistics to show information with select profile.



3.4.6 About

Click **About** to show the ActiveX information



3.5 Network

Use this menu to configure the network to connect the device and the clients.


3.5.1 Network

This section provides the menu of connecting the device through Ethernet cable.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter															
<p>MAC Address 00:30:4F:A2:BF:E1</p> <p><input checked="" type="checkbox"/> Obtain IP address automatically (DHCP)</p> <table> <tr> <td>IP Address</td> <td>192.168.1.169</td> <td>Test</td> </tr> <tr> <td>Subnet Mask</td> <td>255.255.255.0</td> <td></td> </tr> <tr> <td>Gateway</td> <td>192.168.1.254</td> <td></td> </tr> </table> <p><input type="checkbox"/> Obtain DNS from DHCP</p> <table> <tr> <td>Primary DNS</td> <td>192.168.1.1</td> <td></td> </tr> <tr> <td>Secondary DNS</td> <td>168.95.192.1</td> <td></td> </tr> </table> <p>HTTP Port 80 (1 ~ 65535) Test</p>									IP Address	192.168.1.169	Test	Subnet Mask	255.255.255.0		Gateway	192.168.1.254		Primary DNS	192.168.1.1		Secondary DNS	168.95.192.1	
IP Address	192.168.1.169	Test																					
Subnet Mask	255.255.255.0																						
Gateway	192.168.1.254																						
Primary DNS	192.168.1.1																						
Secondary DNS	168.95.192.1																						

Function	Description
MAC address	Display the Ethernet MAC address of the device. Note that user cannot change it.
Obtain an IP address automatically (DHCP)	Enable this checked box when a DHCP server is installed on the network to issue IP address assignment. With this setting, the IP address is assigned automatically. If this device cannot get an IP address within limited tries, the device will assign a default IP address for 192.168.0.20. If you do not select "Obtain an IP address automatically", then you need to enter these network parameters by yourself.
IP Address	This address is a unique number that identifies a computer or device on the WAN or LAN. These numbers are usually shown in groups separated by periods, for example: 192.168.0.200
Subnet Mask	Subnets allow network traffic between hosts to be separated based on the network's configuration. In IP networking, traffic takes the form of packets. IP subnets advance network security and performance to some level by organizing hosts into logical groups. Subnet masks contain four bytes and usually appear in the same "dotted decimal" data. For example, a very common subnet mask in its binary demonstration 11111111 11111111 11111111 00000000 will usually be

	shown in the corresponding, more readable form as 255.255.255.0.
Gateway	A gateway is a piece of software or hardware that passes information between networks. You'll see this term most often when you either log in to an Internet site or when you're transient email between different servers.
Obtain DNS from DHCP	Enable this checked box when a DHCP server is installed on the network and provide DNS service.
Primary DNS	When you send email or position a browser to an Internet domain such as xxxx.com, the domain name system translates the names into IP addresses. The term refers to two things: the conventions for naming hosts and the way the names are control across the Internet.
Secondary DNS	The same function as DNS1. It is option not necessary
HTTP Port	<p>The device supports two HTTP ports. The first one is default port 80 and this port is fixed. This port is very useful for Intranet usage. The second HTTP port is changeable. Users could assign the second port number of http protocol, and the WAN users should follow the port number to login. If the http port is not assigned as 80, users have to add the port number in back of IP address. For example:</p> <p style="color: blue;">http://192.168.0.20:8080.</p> <p>Therefore, the user can access the device by either http://xx.xx.xx.xx/, or http://xx.xx.xx.xx:xxxx to access the device.</p> <p>If multiple devices are installed on the LAN and also required to be accessed from the WAN, then the HTTP Port can be assigned as the virtual server port mapping to support multiple devices.</p>




If you log in the camera as an ordinary user, setting function will be not available. If you log in the camera as an administrator, you can perform all the settings provided within the device.

When the configuration is finished, please click “OK” to save and enable the setting.

3.5.2 IPv6

Internet Protocol version 6 (IPv6) is called the “IP Next Generation” (IPng), which is designed to fix the shortcomings of IPv4, such as data security and maximum number of user addresses. It is backward compatible and thus expected to slowly replace IPv4, with the two existing side by side for many years.



Function	Description
IPv6	To enable or disable the IPv6 function here.

3.5.3 HTTPS

HTTPS: Stands for Hypertext Transfer Protocol Secure

HTTPS is a combination of the Hypertext Transfer Protocol with the SSL/TLS protocol to provide encrypted communication and secure identification of a network web server. HTTPS connections are often used for sensitive transactions in corporate information systems. The main idea of HTTPS is to create a secure channel over an insecure network. This ensures reasonable protection from eavesdroppers and man-in-the-middle attacks, provided that adequate cipher suites are used and that the server certificate is verified and trusted.



Function	Description
HTTPS	To enable or disable the HTTPS service here. Note that the HTTPS function of this device is not only encrypted the web content but also audio/video data.

Port	Choose the HTTPS port. The default value is 443.
------	--

3.5.4 DDNS server

Stands for Dynamic Domain Name Server

The device supports DDNS. If your device is connected to xDSL directly, you might need this feature. However, if your device is behind a NAT router, you will not need to enable this feature. Because DDNS allows the device to use an easier way to remember naming format rather than an IP address. The name of the domain is like the name of a person, and the IP address is like his phone number. On the Internet we have IP numbers for each host (computer, server, router, and so on), and we replace these IP numbers to easy remember names, which are organized into the domain name. As to xDSL environment, most of the users will use dynamic IP addresses. If users want to set up a web or a FTP server, then the Dynamic Domain Name Server is necessary. For more DDNS configuration, please consult your dealer.

Your Internet Service Provider (ISP) provides you at least one IP address which you use to connect to the Internet. The address you get may be static, meaning it never changes, or dynamic, meaning it's likely to change periodically. Just how often it changes, depends on your ISP. A dynamic IP address complicates remote access since you may not know what your current WAN IP address is when you want to access your network over the Internet. The solution to the dynamic IP address problem comes in the form of a dynamic DNS service.

The Internet uses DNS servers to lookup domain names and translates them into IP addresses. Domain names are just easy to remember aliases for IP addresses. A dynamic DNS service is unique because it provides a means of updating your IP address so that your listing will remain current when your IP address changes. There are several excellent DDNS services available on the Internet and best of all they're free to use. One such service you can use is www.DynDNS.org. You'll need to register with the service and set up the domain name of your choice to begin using it. Please refer to the home page of the service for detailed instructions or refer to Appendix E for more information.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter								
DDNS <div style="display: flex; justify-content: space-around; align-items: center;"> <input type="radio"/> Disable <input checked="" type="radio"/> Enable </div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">Server Name</td> <td style="width: 70%;"> <input style="width: 100%; height: 25px; border: 1px solid #ccc; padding: 2px; margin-bottom: 5px;" type="text" value="dyndns.org"/> <div style="display: flex; justify-content: space-between; font-size: small;"> (1 ~ 30 Digits) </div> </td> </tr> <tr> <td>User Name</td> <td> <input style="width: 100%; height: 25px; border: 1px solid #ccc; padding: 2px; margin-bottom: 5px;" type="text"/> <div style="display: flex; justify-content: space-between; font-size: small;"> < 22 Digits </div> </td> </tr> <tr> <td>Password</td> <td> <input style="width: 100%; height: 25px; border: 1px solid #ccc; padding: 2px; margin-bottom: 5px;" type="text"/> <div style="display: flex; justify-content: space-between; font-size: small;"> < 22 Digits </div> </td> </tr> <tr> <td>Internet Status</td> <td style="text-align: right;">Connected (210.61.134.92)</td> </tr> </table>									Server Name	<input style="width: 100%; height: 25px; border: 1px solid #ccc; padding: 2px; margin-bottom: 5px;" type="text" value="dyndns.org"/> <div style="display: flex; justify-content: space-between; font-size: small;"> (1 ~ 30 Digits) </div>	User Name	<input style="width: 100%; height: 25px; border: 1px solid #ccc; padding: 2px; margin-bottom: 5px;" type="text"/> <div style="display: flex; justify-content: space-between; font-size: small;"> < 22 Digits </div>	Password	<input style="width: 100%; height: 25px; border: 1px solid #ccc; padding: 2px; margin-bottom: 5px;" type="text"/> <div style="display: flex; justify-content: space-between; font-size: small;"> < 22 Digits </div>	Internet Status	Connected (210.61.134.92)
Server Name	<input style="width: 100%; height: 25px; border: 1px solid #ccc; padding: 2px; margin-bottom: 5px;" type="text" value="dyndns.org"/> <div style="display: flex; justify-content: space-between; font-size: small;"> (1 ~ 30 Digits) </div>															
User Name	<input style="width: 100%; height: 25px; border: 1px solid #ccc; padding: 2px; margin-bottom: 5px;" type="text"/> <div style="display: flex; justify-content: space-between; font-size: small;"> < 22 Digits </div>															
Password	<input style="width: 100%; height: 25px; border: 1px solid #ccc; padding: 2px; margin-bottom: 5px;" type="text"/> <div style="display: flex; justify-content: space-between; font-size: small;"> < 22 Digits </div>															
Internet Status	Connected (210.61.134.92)															

Function	Description
DDNS	To enable or disable the DDNS service here.

Server name	Choose the built-in DDNS server.
DDNS Host	The domain name is applied to this device.
User Name	The user name is used to log into DDNS.
Password	The password is used to log into DDNS.

This model comes with PLANET easy DDNS. When this function is enabled, the host name with PLANET DDNS and the MAC address of the last six entries will be established automatically. User does not need to go to the web of www.planetddns.com to apply for a new account.



3.5.5 PPPoE

PPPoE: Stands for Point to Point Protocol over Ethernet

A standard builds on Ethernet and Point-to-Point network protocol. It allows Internet Camera connect to Internet with xDSL or cable connection; it can dial up your ISP and get a dynamic IP address. For more PPPoE and Internet configuration, please consult your ISP.

It can directly connect to the xDSL, however, it should be setup on a LAN environment to program the PPPoE information first, and then connect to the xDSL modem. Power on again, then the device will dial on to the ISP connect to the WAN through the xDSL modem.

The procedures are

- Connect to a LAN by DHCP or Fixed IP
- Access the device, enter **Setting** → **Network** → **PPPoE** as below

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter
PPPoE <input checked="" type="radio"/> Disable <input type="radio"/> Enable User Name <input type="text" value=""/> (< 65 Digits) Password <input type="text" value=""/> (< 65 Digits) IP Address <input type="text" value=""/> (readonly) Subnet Mask <input type="text" value=""/> (readonly) Gateway <input type="text" value=""/> (readonly) Status <input type="text" value="Try to connect"/> (readonly)								

Function	Description
PPPoE	To enable or disable the PPPoE service here.
User Name	Type the user name for the PPPoE service which is provided by ISP.
Password	Type the password for the PPPoE service which is provided by ISP.
IP Address / Subnet Mask / Gateway	Shows the IP information got from PPPoE server site.
Status	Shows the Status of PPPoE connection.

3.5.6 Streaming

RTSP is a streaming control protocol, and a starting point for negotiating transports such as RTP, multicast and Unicast, and for negotiating codes. RTSP can be considered a "remote control" for controlling the media stream delivered by a media server. RTSP servers typically use RTP as the protocol for the actual transport of audio/video data.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter
RTSP Port <input type="text" value="554"/> (554 ~ 65535) <input type="button" value="Test"/> RTP Port <input type="text" value="50000"/> ~ <input type="text" value="50999"/> (1024 ~ 65535)								

Function	Description
RTSP Port	Choose the RTSP port. The RTSP protocol allows a connecting client to start a video stream. Enter the RTSP port number to use. The default value is 554.
RTP Port	Specify the range of transmission port numbers of video stream. The default range is 50000 to 50999. User can specify a number between 1024 and 65535.

 Note	<ul style="list-style-type: none"> • Dialing procedure <ol style="list-style-type: none"> a. Choose a verified player (PacketVideo, QuickTime or Real player currently) b. Use the following URL to access: rtsp://host/mpeg4/media.3gp where host is the host name or IP address of the camera. • Compatible 3G mobile phone Please contact your dealer to get the approved list of compatible 3G phones.
--	---

 Note	<ol style="list-style-type: none"> 1. To use the 3GPP function, in addition to the previous section, you might need more information or configuration to make this function works. 2. The camera must be set as multi-profile mode, not mega-pixel mode. Otherwise, this device cannot serve 3GPP streaming. 3. To use the 3GPP function, it is strongly recommended to install the Networked Device with a public and fixed IP address without any firewall protection. 4. Port 554 is the default for RTSP service. However, sometimes, some service providers change this port number for some reason. If so, user needs to change this port accordingly.
--	--

3.5.7 UPnP

UPnP is short for Universal Plug and Play, which is a networking architecture that provides compatibility among networking equipment, software, and peripherals. This device is an UPnP enabled Internet Camera. If your operating system is UPnP enabled, the device will automatically be detected and a new icon will be added to "My Network Places." If you do not want to use the UPnP functionality, it can be disabled

In addition, this device also provides UPnP IGD function for NAT traversal easily. Use NAT traversal when your device is located on an intranet (LAN) and you wish to make it available from the other (WAN) side of a NAT router. With NAT traversal properly configured, all HTTP traffic to an external HTTP port in the NAT router will be forwarded to the device.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter
UPnP <input checked="" type="radio"/> Disable <input type="radio"/> Enable Friendly Name ICA-2250VT - 00304FA2BFE1 (readonly)								
UPnP NAT Traversal <input checked="" type="radio"/> Disable <input type="radio"/> Enable Port Range 32768 ~ 65535 (1 ~ 65535) External IP Address http://210.66.155.70:32777 (readonly)								

Function	Description
UPnP	To enable or disable the UPnP service here.
Friendly Name	Shows the friendly name of this device here.
UPnP NAT Traversal	When enabled, the device will attempt to configure port mapping in a NAT router on your network, using UPnP™. Note that UPnP™ must be enabled in the NAT router first.
Port Range	The port range will open in NAT router.
External IP address	Shows the IP address and port for WAN access through Internet. If NAT traversal is configured successfully, user can use this IP address and port to access this device.

3.5.8 Bonjour


The Bonjour service allows IP camera to be discovered with Apple Safari browser applied, once enabled, the IP camera will show the Friendly Name in the Bonjour bookmark menu of Safari browser.

Network	IPv6	HTTPS	DDNS	PPPoE	Streaming	UPnP	Bonjour	IP Filter
Bonjour <input checked="" type="radio"/> Disable <input type="radio"/> Enable Friendly Name ICA-2250VT - 00304FA2BFE1 (readonly)								

Function	Description
Bonjour	To enable or disable the Bonjour service here.
Friendly Name	Shows the friendly name of this device here.

3.5.9 IP Filter

You can enter different user IP addresses which are allowed to enter or deny by the device.



Filter IP	Add	Delete	DeleteAll

Function	Description
IP Filter	To enable or disable the IP filter function here.
IP Filter Policy	Choose the filter policy where deny or allow is.

3.6 Camera

Use this menu to set the function of the Internet Camera

3.6.1 Picture

Picture	Privacy Mask	PTZ Setting	Preset Setting	Tour Setting
---------	--------------	-------------	----------------	--------------

Rotation: Normal

White Balance: Auto

Iris/Exposure Control: Outdoor

Maximum Exposure Time: 1/30 S

Power Frequency: 50Hz 60Hz

Exposure Value: 50 (0 ~ 100)

Color Level: 50 (0 ~ 100)

Hue: 50 (0 ~ 100)

Brightness: 50 (0 ~ 100)

Contrast: 50 (0 ~ 100)

Sharpness: 50 (0 ~ 100)

Local video output: Disable Enable

ICR: Auto




Function	Description
Rotation	<p>Turn the “Mirror” and “Vertical Flip” On or OFF. The image will be overturned as shown below.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Normal</p>  </div> <div style="text-align: center;"> <p>Mirror</p>  </div> </div> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Vertical Flip</p>  </div> <div style="text-align: center;"> <p>Mirror + Vertical Flip</p>  </div> </div>

White Balance	Auto: will adjust the white balance automatically. Hold: will hold the white balance.
	Auto Exposure: will adjust the internal gain automatically. Hold Exposure: will hold the internal gain. Auto Iris: This Camera has a built-in DC-Iris lens. User can choose the Iris control mode from "Auto" or "Off". In case, the "Auto" mode is selected, the Camera will control DC Iris automatically. On the hand, if the "Off" mode is selected, the Camera will open the lens Iris to maximize.
Iris / Exposure Control	Sometimes, the Auto Iris may work abnormally under some environments. In this case, user can click "Calibrate" button to adjust Auto Iris function again. Manual Exposure: Allow user to adjust exposure from 1/2 to 1/47000 manually. Outdoors: If the camera is installed outdoors, it will enable this option. Otherwise, disable it. The feature is used to improve auto-exposure performance under strong sunlight.
Maximum Exposure Time	User can limit the maximum exposure time of the image sensor. The larger value means longer exposure time possibly.
Power Frequency	Frequency of power line: 50 or 60Hz
Exposure Value	Exposure value is AE target value. This value is to adjust the integration, analog gain and digital gain to achieve the target brightness value (Exposure Value). This value is dependent to "Auto Exposure" only
Color Level	Large value will be colorful.
Hue	Changing the value will result in color tuning.
Brightness	Large value will brighten camera.
Contrast	Large value will contrast camera heavily.
Sharpness	Large value will sharpen camera.

Local Video Output	<p>Enable or disable video signal of BNC to a TV monitor. It's very useful to check view angle or focus during camera installation. However, disabling this function will save power a lot. Suggest to disable it after camera is installed</p>
ICR	<p>Use built-in photo sensor or manual to control ICR.</p> <p>In case user selects manual mode, there are 4 modes: Night (On), Day (Off), Auto or Schedule to control built-in IR LEDs. This function is very useful under low illumination environment even 0 Lux.</p> <p>In case the Auto mode is selected, user needs to specify 3 parameters in advance:</p> <p>Night Mode Threshold (0~10000): This value set the threshold to turn on IR LED. It should be lower or equal to Day Mode Threshold.</p> <p>Day Mode Threshold (0~10000): This value set the threshold to turn off IR LED. It should be higher or equal to Night Mode Threshold.</p> <p>Auto: Automatic changes to day mode or night mode depending on camera's sensor.</p> <p>Schedule: The default is day mode. This function needs coordination with event schedule's schedule trigger. When enabling time and ICR time of action, the camera will change a specified time to night mode.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  Note The Current Value is the current luminance from the captured video. It's a useful reference to set LED On/Off threshold. </div>
BLC	<p>BLC means Back Light Compensation, allowing the camera to adjust the exposure of the entire image to properly expose the subject in the foreground</p>
3D De-Noise	<p>3D De-Noise can remove or lower unwanted noise and preserve fine details and edges.</p>
WDR	<p>This function is to provide clear images even under back light circumstances. The higher "Strength" level will adjust contrast compensation stronger.</p>
Default Settings	<p>Restore to factory image settings.</p>

3.6.2 Privacy Mask

Use this page to specify privacy mask window 1 to window 8 and set the name and gray level for selected window.



Function	Description
Add and Delete	To add or delete the privacy mask windows, user can specify up to 7 windows to mask the video captured by this device. By dragging mouse on the image, you can change the position and size of the selected window accordingly.
Name	Name of the specified privacy window
Level	To define the gray level of mask block, the smaller value will be darker.

3.6.3 PTZ Setting

This page allows user to modify the RS-485 interface according to the P/T scanner.

Picture	Privacy Mask	PTZ Setting	Preset Setting	Tour Setting
<div style="background-color: #00008B; color: white; padding: 10px;"> Camera Protocol <input style="width: 100px; height: 20px; border: none; background-color: #00008B; color: white; font-size: 10px; margin-right: 10px;" type="button" value="none"/> Camera Address <input style="width: 100px; height: 20px; border: 1px solid #00008B; margin-bottom: 10px;" type="text" value="1"/> Baud rate <input style="width: 100px; height: 20px; border: none; background-color: #00008B; color: white; font-size: 10px; margin-right: 10px;" type="button" value="9600"/> </div>				

Function	Description
Camera Protocol	This device can connect to a PTZ camera or speed dome camera and controls them through RS-485 interface.
Camera Address	This is the camera ID set in PTZ camera or speed dome camera. <div style="border: 1px solid #00008B; padding: 5px; margin-top: 10px;">  Note Please DO NOT change the default value if unnecessary. If so, user needs to check and set value properly for both sides. </div>
Baud Rate	This is the communication speed between network module and P/T scanner.

 Note	If these parameters need to be changed, user needs to check and set value properly for both the network module and P/T scanner.
---	---

3.6.4 Preset Setting

This page provides the edit tool to modify or delete the “Preset Setting” item by item.


Picture	Privacy Mask	PTZ Setting	Preset Setting	Tour Setting
Preset Number Preset Name Home Position				Preset List
				Preset Number
				Preset Name
				Home Position <input checked="" type="radio"/> Enable <input type="radio"/> Disable
				<input type="button" value="Modify"/> <input type="button" value="Delete"/>

3.6.5 Tour Setting

Up to 64 positions can be preset, and the camera can be programmed to move to the preset position sequentially.

Picture	Privacy Mask	PTZ Setting	Preset Setting	Tour Setting												
<table border="1"><thead><tr><th>Tour Number</th><th>Tour Name</th><th>Running</th></tr></thead><tbody><tr><td></td><td></td><td></td></tr></tbody></table>	Tour Number	Tour Name	Running				<table border="1"><thead><tr><th>Sequence</th><th>Preset Name</th><th>Wait Time</th></tr></thead><tbody><tr><td></td><td></td><td></td></tr></tbody></table>	Sequence	Preset Name	Wait Time						
Tour Number	Tour Name	Running														
Sequence	Preset Name	Wait Time														

Function	Description
Tour Name	The group name of the sequence of camera tour. The maximum number of camera tour is 16.
Running	Enable or disable this camera tour.
Preset	Set the sequence of the tour. Maximum 16 points can be assigned. The selected preset position is added in the Sequence list from 1 to 16.
Wait Time	Type a period of time during which the camera is to stay at each preset point, between 0 to 36000 seconds.



To use the camera tour function, user must preset some camera positions first. The maximum number of preset points is 64.

3.7 System

Use this menu to perform the principal settings of Internet Camera.

3.7.1 System


System	Date & Time	Maintenance
Device Title	ICA-2250VT (0 ~ 30 Digits)	
Software Version	6.M.2.12645	
Network LED	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	
Power LED	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	
Log	<input type="button" value="Reload"/>	

Function	Description
Device Title	You can enter the name of this unit here. It's very useful to identify the specific device from multiple units.
Software Version	This information shows the software version in the device.
Network LED	Switch the LED light of this Internet Camera on or off. The Network LEDs will stop working; in case you don't want other people to know the camera is transferring data.

Power LED	Switch the LED light of this Internet Camera on or off.
Log	User can check the system log information of the device, including the Main Info, Appended Info, Operator IP, and so on.
Reload	Click this button; user can refresh the log information of the device.

3.7.2 Date & Time

User can set up the time setting of Internet Camera, making it synchronized with PC or remote NTP server. Also, you may select the correct time zone of your country.



Function	Description	
Server Date & Time	Displays the date and time of the device	
PC Time	Displays the date and time of the connected PC	
Adjust	Synchronize with PC	Click this option to enable time synchronization with PC time
	Manual setting	Click this option to set time and date manually
	Synchronize with NTP	Click this option if you want to synchronize the device's date and time with those of time server called NTP server (Network Time Protocol)
NTP Server Name	Type the host name or IP address or domain name of the NTP server.	


NTP Sync. Interval	Select an interval between 1 and 23 hours at which you want to adjust the device's time referring to NTP server
Time Zone	Set the time difference from Greenwich Mean Time in the area where the device is installed.
Daylight Saving	Check this item to enable daylight saving adjustment.
Daylight Saving Start Time	Sets up the date and time of daylight saving start time.
Daylight Saving Stop Time	Sets up the date and time of daylight saving stop time.
Daylight Saving Offset	Sets up the date of daylight saving offset.

3.7.3 Maintenance

System	Date & Time	Maintenance
Default Settings (Including Network Setting)		Factory Default Settings
Default Settings (Excluding Network Setting)		Default Settings
Backup Setting		Backup Setting
Restore Setting		Browse... Restore Setting Reset
Firmware Upgrade		Browse... Firmware Upgrade Reset
System Restart		Restart

Function	Description
Default Settings (Including the network setting)	Recall the device hard factory default settings. Note that by clicking this button, it will reset all device's parameters to the factory settings (including the IP address).
Default Settings (Except the network setting)	The unit is restarted and most current settings are reset to factory default values. This action will not reset the network setting.

Backup Setting	To take a backup of all of the parameters, click this button. If necessary, it will then be possible to return to the previous settings, if settings are changed and there is unexpected behavior.
Restore Setting	Click the “Browse” button to locate the saved backup file and then click the “Restore Setting” button. The settings will be restored to the previous configuration.
Firmware Upgrade	The device supports new firmware upgrade.
	<ol style="list-style-type: none"> 1. Close all other application programs which are not necessary for firmware update. 2. Make sure that only you access this device at this moment 3. Disable Motion Detection function. 4. Select “Firmware name” 5. Select the Firmware binary file.



Make sure that the Firmware only applies to this device. Once updated, it will be burned into FLASH ROM of system.

	<ol style="list-style-type: none"> 6. Once the firmware file is selected, select “Upgrade”. 7. The upgrade progress information will be displayed on the screen. 8. A message will be shown while the firmware is upgraded. Once the upgrading process completed, the device will reboot the system automatically. 9. Please wait for 80 seconds, and then you can use PLANET IPWizard II to search the device again.
--	---

Warning!!!

The download firmware procedure cannot be interrupted. If the power and/or network connection are broken during the download procedure, it might possibly cause serious damage to the device.


Please be aware that you should not turn off the power during updating the firmware and wait for “finish” message. Furthermore, do not try to upgrade new firmware if it's not necessary.

System Restart	The device is restarted without changing any of the settings.
-----------------------	---

3.8 Video

This device provides 2 modes of video profile. The first one is 2MEGA mode which supports video resolution up to 2 mega-pixels. The second one is 720p mode which supports video resolution up to 720p pixel. User only can select either 720p or 2 mega mode to operate the camera. Switching to 720p and 2 mega mode, the device will take time to reboot system.


3.8.1 Common



Function	Description
Video Profile	User can only choose either 2 MEGA or 720p mode. 2MEGA mode can serve maximum streams of up to 1920X1080 resolutions on one hand. On the other hand, 720p mode can stream a maximum of up to 1280 x 720 resolutions.
Text Overlay Setting	There are some important information that can be embedded into image, including date, time, and/or text.

3.8.2 Overlay Image

User can upload “**bmp**” format picture to IP camera



Function	Description
Upload Own Image	Select your picture to upload
Coordinates	Select the location of the picture

3.8.3 Video Profile

User can modify the detailed parameter for each video profile on this page.

Common	Overlay Image	Video Profile	ONVIF Profile	ROI	AOI	
Profile3	mpeg	1080p	VBR	75	-	13
Profile4	h264/Baseline	1280x720	EVBR	70	-	30
Profile5	mpeg4	1280x720	EVBR	80	-	30
Profile6	mpeg	1280x720	VBR	90	-	10
Profile7	h264/Baseline	640x360	EVBR	70	-	30
Profile8	mpeg4	640x360	EVBR	90	-	30
Profile9	mpeg	640x360	VBR	90	-	10
Profile10	h264/Baseline	320x180	EVBR	70	-	30

Name	Profile1
Video Type	h264 Baseline
Resolution	1080p
ROI	<input checked="" type="radio"/> Yes <input type="radio"/> No
Rate Control	VBR Quality 100
Max Frame Rate	30
GOP Control	30
Multicast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Multicast Video	IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)
Multicast Audio	IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)
Time to live	1 (1 ~ 255)
Always Enable Multicast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable

Function	Description
Name	To assign a name to the selected profile.
Video Type	Video codec of the selected profile.
Resolution	Resolution of the selected profile.
ROI	Assign the selected profile as a ROI stream or not (Only available for the profiles with max resolution).
Rate Control	<p>Defines the rate control method of this profile. There are four options: Constant Bit Rate (CBR), Variable Bit Rate (VBR), and Enhanced Variable Bit Rate (EVBR).</p> <p>For CBR, the video bit rate is between low to high bandwidth based on different resolutions. User can set the desired bit rate to match the limitation of bandwidth.</p> <p>For VBR, user should choose the quality level to set the video quality rather than bit rate. The quality level is between 1 and 100. The higher value can reach the better quality but of course will consume more bandwidth.</p>

	higher bandwidth. For EVBR, the video bitrates is based on normal VBR mode. However, the target bitrates can be increased to max target bitrates while lots of motion in video. The max target bitrates will keep a pre-defined time period and then back to normal VBR mode.
Max Frame Rate	Defines the targeted frame rate of this profile. For example, set the frame rate to 15 fps, then the image will be updated for 15 frames per second. User can set the desired max frame rate versus video quality under the limited bandwidth.
GOP Control	Defines the Intra/Inter-frame (I/P) ratio of this profile. For example, set the GOP to 30, then the video stream will have one Intra-frame every 30 frames.
Multicast	Enable or disable the multicast function.
Multicast Video	IP address and port for multicast video streaming of the selected profile.
Multicast Audio	IP address and port for multicast audio streaming of the selected profile
Time to Live	Time to live (TTL) is a mechanism that limits the lifespan of data in a computer or network. Once the prescribed event count or time span has elapsed, data is discarded. TTL prevents a data packet from circulating indefinitely.
Always Enable Multicast	Multicast streaming is always enabled or by request

Warning!!!

To enable the multicast streaming, make sure your Intranet does support multicast function. Otherwise, your Intranet may fall into network storm seriously.


3.8.4 ONVIF Profile

ONVIF protocol defines profile of video streams. In case, the NVR, CMS and/or VMS connect to this device via ONVIF protocol. Use this page to define parameters of video streams.

Common	Overlay Image	Video Profile	ONVIF Profile	ROI	AOI
Name					
OnvifProfile1	h264/Baseline	1080p	75	10000	30
OnvifProfile2	h264/Baseline	1280x720	70	5000	30
Name					
OnvifProfile1					
Video Type					
h264 <input type="button" value="▼"/>					
Baseline <input type="button" value="▼"/>					
Resolution					
1080p <input type="button" value="▼"/>					
Rate Control					
Quality 75 <input type="button" value="▼"/>					
Max Bitrate 10000 K bps 1024 ~ 15000					
Max Frame Rate					
30 <input type="button" value="▼"/>					
GOP Control					
30 <input type="button" value="▼"/>					
Audio					
<input checked="" type="radio"/> Enable <input type="radio"/> Disable					
Multicast Video					
IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)					
Multicast Audio					
IP Address 239.198.97.181 Port 0 (0 means auto, 1024 ~ 65534)					
Time to live					
1 (1 ~ 255)					

3.8.5 ROI

ROI means Region of Interest. Use this page to specify location of ROI windows. Only the maximum resolution profiles can be defined as ROI. In this model, the default ROI windows are profile 4 and 5.




3.8.6 AOI

AOI means Area of Interest. Use this page to specify location and size of AOI windows. Only the profiles with H.264 codec and VBR rate control can support AOI function. It enables a non-uniform distribution of the image quality between a selected region (the AOI) and the rest of the image (background).



Function	Description
Add and Del	To add or delete the AOI windows, user can specify up to 2 AOI windows to change the video quality in specified areas. By dragging mouse on the image, you can change the position and size of the selected AOI window accordingly
Name	Name of the specified AOI window.
Level	Adjust the video quality of specified AOI window. The higher value will be better video quality.

3.9 Audio



Function	Description
Audio	To enable or disable audio function.
Audio Type	To select G711 or G726 for audio coding.
Audio Mode	To select Simplex or Full duplex (2-way audio) mode.
Input Gain	To adjust gain of input audio.
Output Gain	To adjust gain of output audio.
Speaker Out	To enable or disable speaker function.

3.10 User Privilege Access

Use this menu to set the user name and password of the administrator and up to 10 users, and access right of each user.

Setting

Viewer Login Anonymous Only users in database

User Name	Access Right	PTZ Control
admin	administrator	yes

User List	
User Name	(1 ~ 20 Digits)
Password	(0 ~ 20 Digits)
Verify Password	(0 ~ 20 Digits)
Access Right	<input checked="" type="radio"/> Administrator <input type="radio"/> Viewer
PTZ Control	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
<input type="button" value="Add"/> <input type="button" value="Modify"/> <input type="button" value="Delete"/>	

Function	Description
Viewer Login	Select “Anonymous” to allow any one viewing the video once connected. Otherwise, only users in database can view the video after login.
Access Right	Administrator can access every function in this device. However, Viewers only can view the video and access limited function.
PTZ Control	Authorize this user to control PTZ function or not.
Add, Modify, and Delete of Users account	Manage the account of viewer's use.

3.11 Protocol

Use this menu to select enable or disable ONVIF and set up SNMP configuration.

3.11.1 ONVIF

ONVIF is a global and open industry forum with the goal to facilitate the development and use of a global open standard for the interface of physical IP-based security products. Or in other words, to create a standard for how IP products within video surveillance and other physical security areas can communicate with each other.

ONVIF	SNMP
ONVIF <input type="radio"/> Disable <input checked="" type="radio"/> Enable <input type="radio"/> V1.0 <input checked="" type="radio"/> V1.01/V1.02/V2.0/V2.1.1/V2.2/V2.3	

Function	Description
ONVIF	To enable or disable the ONVIF interface here.
Version	Currently, the V1.0 or V1.01/V1.02/V2.0/V2.1.1/V2.2/V2.3 is available.

3.11.2 SNMP

SNMP provides a simple framework for administering networked hardware. To manage the IP camera, you have to prepare an MIB browser or similar tools first. SNMPv1 and SNMPv2c can be enabled simultaneously.

ONVIF	SNMP
SNMP v1 <input type="radio"/> Disable <input checked="" type="radio"/> Enable SNMP v2c <input checked="" type="radio"/> Disable <input type="radio"/> Enable Read community public (< 33 Digits) Write community write (< 33 Digits) Traps <input type="radio"/> Disable <input checked="" type="radio"/> Enable Trap address 192.168.1.41 (< 257 Digits) Trap community 1234 (< 33 Digits) Available traps <input checked="" type="checkbox"/> Cold start <input type="checkbox"/> Warm start <input type="checkbox"/> Link up <input type="checkbox"/> Authentication failed	

Function	Description
SNMP v1	To enable or disable the SNMP v1 function here.
SNMP v2c	To enable or disable the SNMP v2c function here.
Read Community	The term "Community name" in SNMPv1 and SNMPv2c can be

Write Community	roughly regarded as key. The person who has the community name has the authority to read or edit the information of IP camera via SNMP.
Traps	Trap is a mechanism that allows the managed device to send messages to manager instead of waiting passively for polling from the manager.
Trap Address	The IP address of SNMP traps station.
Trap Community	Trap Community means the community that can receive the trap message.
Available Traps	
Cold Start	The camera reboots.
Available Traps	
Warm Start	The camera starts up
Available Traps	
Link Up	The camera connected network.
Available Traps	
Authentication Failed	When content of read community is wrong, MIB browser connecting to camera will appear trap message.

3.12 Mail

You may set up SMTP mail parameters for further operation of Event Schedule. That is, if users want to send the alarm message out, it will need to configure parameters here and also add at least one event schedule to enable event triggering.

Setting

SMTP Server	mail.planet.com.tw (< 129 Digits)	<input type="button" value="Test"/>
SMTP Port	25 (1 ~ 65535)	
SSL	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	
SMTP Authentication	<input checked="" type="radio"/> Disable <input type="radio"/> Enable	
Authentication User Name	admin (< 65 Digits)	
Authentication Password	***** (< 22 Digits)	
E-mail From	admin@planet.com,.tw (< 129 Digits)	
E-mail To	support@planet.com,.tw (< 129 Digits)	
E-mail Subject	message (< 65 Digits)	


Function	Description
SMTP Server	Type the SMTP server name or the IP address of the SMTP server.
Test	Send a test mail to mail server to check whether this account is available or not.
SMTP Port	Set port number of SMTP service.
SSL	Enable SSL function or not.
SMTP Authentication	Select the authentication required when you send an e-mail. Disable: If no authentication is required when an e-mail is sent. Enable: If authentication is required when an e-mail is sent.
Authentication User Name	Type the user name for the SMTP server if Authentication is Enabling.
Authentication Password	Type the password for the SMTP server if Authentication is Enabling.
E-mail From	Type the sender's E-mail address. This address is used for replying e-mails.
E-mail To	Type the receiver's e-mail address.
E-mail Subject	Type the subject/title of the e-mail.

3.13 Event Detection

Use this menu to specify motion detection window 1 to window 4 and set the conditions for detection while observing a captured image.

3.13.1 Motion Detection

Use this menu to specify motion detection window 1 to window 10 and set the conditions for detection while observing a captured image.



Function	Description
Add and Delete	To add or delete the motion windows, user can specify up to 4 Included and /or Excluded windows to monitor the video captured by this device. By dragging mouse on the image, you can change the position and size of the selected motion window accordingly.
Included or Excluded Window	These windows can be specified as Included or Excluded type. Included: Windows target specific areas within the whole video image Excluded: Windows define areas within an Include window that should be ignored (areas outside Include windows are automatically ignored)
Name	Name of the specified motion window.
Object Size	Defines the object size of motion detection. For the higher level, only the larger objects will trigger motion detection. And for the lower

level, even the small objects will trigger motion detection, too. Generally speaking, the smaller size will be easier to trigger event.

3.13.2 Camera Tampering


Camera tampering detection is a new intelligent functionality that further strengthens the benefit of Network Camera. When the camera is moved, partially obscured, severely defocused, covered or sprayed, an event can be triggered to send notifications, upload images / files to remote server or email.



Function	Description
Camera Tampering	Enable camera tampering function or not.
Minimum Duration	Define the minimum triggered duration by camera tampering detection. The triggered duration less than target value will be ignored to filter false alarms.

3.13.3 Audio Detection

Audio detection alarm can be used as a complement to motion detection. Since audio detection can react to events in areas too dark for the video motion detection functionality to work properly. In addition, it can be used to detect activity in areas outside of the camera's view.



Function	Description
Audio Detection	Enable audio detection function or not.
Audio Alarm Level	Define the threshold value of audio detection.

3.14 Storage

This page shows the status of attached SD card and Samba server. You may set up related parameters to manage the attached SD card or Samba server also.

3.14.1 SD Card

SD Card	SAMBA Server																												
<table border="1"> <thead> <tr> <th>Disk ID</th> <th>SD_DISK</th> <th>Mount</th> <th>Unmount</th> </tr> </thead> <tbody> <tr> <td>Status</td> <td>Free space 57% - 1126844KB</td> <td>Reload</td> <td>Format</td> </tr> <tr> <td>Total size</td> <td>1966080 KB</td> <td></td> <td></td> </tr> <tr> <td>Status</td> <td>OK</td> <td></td> <td></td> </tr> <tr> <td>Full</td> <td>No</td> <td></td> <td></td> </tr> <tr> <td> Readonly</td> <td>No</td> <td></td> <td></td> </tr> <tr> <td colspan="4"> <input type="checkbox"/> Enable automatic disk cleanup Remove recordings older than: 7 day(s) Remove oldest recordings when disk is: 95 % full <input type="checkbox"/> Lock disk </td> </tr> </tbody> </table>	Disk ID	SD_DISK	Mount	Unmount	Status	Free space 57% - 1126844KB	Reload	Format	Total size	1966080 KB			Status	OK			Full	No			Readonly	No			<input type="checkbox"/> Enable automatic disk cleanup Remove recordings older than: 7 day(s) Remove oldest recordings when disk is: 95 % full <input type="checkbox"/> Lock disk				
Disk ID	SD_DISK	Mount	Unmount																										
Status	Free space 57% - 1126844KB	Reload	Format																										
Total size	1966080 KB																												
Status	OK																												
Full	No																												
Readonly	No																												
<input type="checkbox"/> Enable automatic disk cleanup Remove recordings older than: 7 day(s) Remove oldest recordings when disk is: 95 % full <input type="checkbox"/> Lock disk																													

Function	Description
Disk ID	This name of SD card.
Status	This information of SD card.
Enable automatic disk cleanup	Delete old recorded files while the conditions are reached as shown below.
Remove recordings older than	Delete old files by days.
Remove oldest recordings when disk is	Delete old files by remaining capacity.
Lock Disk	Avoid writing data and delete from SD card


3.14.2 SAMBA Server

SD Card	SAMBA Server
Host	192.168.0.201 (1 ~ 63 Digits)
Share	share (1 ~ 63 Digits)
User Name	test (< 63 Digits)
Password	***** (< 63 Digits)
Status	Online
Total size	13.34 GB
Free space	59% - 7.88 GB
SAMBA Server	Unmount

Function	Description
Host	Type the server name or the IP address of the SAMBA server.
Share	Set working directory path of SAMBA server.
User Name	Type the user name for the SAMBA server
Password	Type the password for the SAMBA server.

3.15 Continuous Recording

You may enable or disable continuous recording function here. Select SD card or Samba server for storage destination.



Continuous Recording

Continuous Recording <input checked="" type="radio"/> Disable <input type="radio"/> Enable Record File Type Disk Path	<input checked="" type="radio"/> SD Card <input type="radio"/> SAMBA Server PLANET-00304FA2BFE1 (For example: Folder1/Folder2/Folder3) (1 ~ 63 Digits)
<input type="button" value="Restart"/> (Restarting will delete the current recording.) Oldest recordings will be removed if the disk is 90% full and free space is smaller than 1GB.	

3.16 Recording List

This page shows the files where information is listed inside the SD Card. User may reload file from SD card that plays or removes the selected file.

Recording List **Continuous Recording List**

Date	File	Trigger by	Size
20120329	20120326_113301.avi	motion0Occur	2004 KB
20120330	20120326_115716.avi	motion0Occur	2068 KB
20120326	20120326_115732.avi	motion0Occur	2081 KB
	20120326_115740.avi	motion0Occur	2067 KB
	20120326_115749.avi	motion0Occur	2093 KB
	20120326_115755.avi	motion0Occur	2059 KB
	20120326_115932.avi	motion0Occur	2057 KB
	20120326_115943.avi	motion0Occur	2056 KB
	20120326_115951.avi	motion0Occur	2090 KB
	20120326_121234.avi	motion0Occur	2074 KB
	20120326_121329.avi	motion0Occur	2067 KB
	20120326_121411.avi	motion0Occur	2056 KB

This page shows the files where information is listed inside the SD Card or Samba server. User may reload file from SD card or Samba server that plays or removes the selected file.

Recording List Continuous Recording List

Disk: SD Card
Path: PLANET-00304FA22E92

Date	File	Trigger by	Size
20120326	20120326_113156.avi	continuous	15506 KB
	20120326_113656.avi	continuous	17931 KB
	20120326_114156.avi	continuous	19834 KB
	20120326_114657.avi	continuous	19608 KB
	20120326_115157.avi	continuous	19150 KB
	20120326_115659.avi	continuous	50094 KB
	20120326_120200.avi	continuous	20253 KB
	20120326_120701.avi	continuous	19704 KB
	20120326_121201.avi	continuous	27162 KB

Reload Play Remove

3.17 Event Server

3.17.1 FTP Server

You may set up FTP parameters for further operation of Event Schedule. That is, if users want to send the alarm message to an FTP server, it will need to configure parameters here and also add at least one event schedule to enable event triggering as SMTP.

FTP Server TCP Server HTTP Server SAMBA Server

Name	FTP Server	FTP Port	FTP Path
FTP	192.168.0.174	21	/anthony/test

Name	FTP (< 22 Digits)
FTP Server	192.168.0.174 (< 65 Digits) <input type="button" value="Test"/>
FTP Login Name	admin (< 22 Digits)
FTP Login Password	***** (< 22 Digits)
FTP Port	21 (1 ~ 65535)
FTP Path	/admin/test (< 65 Digits)
FTP Passive Mode	<input checked="" type="radio"/> Disable <input type="radio"/> Enable

Function	Description
Name	User can specify multiple FTP paths as wished. Therefore, user needs to specify a name for each FTP setting.
FTP Server	Type the server name or the IP address of the FTP server.
Test	Check the FTP server whether this account is available or not.
FTP Login Name	Type the user name for the FTP server.
FTP Login Password	Type the password for the FTP server.
FTP Port	Set port number of FTP service.
FTP Path	Set working directory path of FTP server.
FTP Passive Mode	Select passive or active mode connecting to FTP server.

3.17.2 TCP Server

In addition to sending video file to FTP server, the device can also send event message to specified TCP server.

FTP Server	TCP Server	HTTP Server	SAMBA Server																				
<table border="1"> <thead> <tr> <th>Name</th> <th>TCP Server</th> <th>TCP Port</th> <th></th> </tr> </thead> <tbody> <tr> <td colspan="4"> </td> </tr> <tr> <td>Name</td> <td colspan="3">< 22 Digits)</td> </tr> <tr> <td>TCP Server</td> <td colspan="3">< 65 Digits) <input type="button" value="Test"/></td> </tr> <tr> <td>TCP Port</td> <td colspan="3">(1 ~ 65535)</td> </tr> </tbody> </table>				Name	TCP Server	TCP Port						Name	< 22 Digits)			TCP Server	< 65 Digits) <input type="button" value="Test"/>			TCP Port	(1 ~ 65535)		
Name	TCP Server	TCP Port																					
Name	< 22 Digits)																						
TCP Server	< 65 Digits) <input type="button" value="Test"/>																						
TCP Port	(1 ~ 65535)																						

Function	Description
Name	User can specify multiple TCP servers as wished. Therefore, user needs to specify a name for each TCP server setting.
TCP Server	Type the server name or the IP address of the TCP server.
TCP Port	Set port number of TCP server.

3.17.3 HTTP Server

The device can also send event message to specified HTTP server.

FTP Server	TCP Server	HTTP Server	SAMBA Server																																								
<table border="1"> <thead> <tr> <th>Name</th> <th>HTTP Server</th> <th colspan="2">Proxy Address</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Name</td> <td></td> <td colspan="2">< 22 Digits)</td> </tr> <tr> <td>URL</td> <td>http://</td> <td>< 129 Digits)</td> <td>Test</td> </tr> <tr> <td>HTTP Login Name</td> <td></td> <td colspan="2">< 22 Digits)</td> </tr> <tr> <td>HTTP Login Password</td> <td></td> <td colspan="2">< 22 Digits)</td> </tr> <tr> <td>Proxy Address</td> <td></td> <td colspan="2">< 129 Digits)</td> </tr> <tr> <td>Proxy Login Name</td> <td></td> <td colspan="2">< 22 Digits)</td> </tr> <tr> <td>Proxy Login Password</td> <td></td> <td colspan="2">< 22 Digits)</td> </tr> <tr> <td>Proxy Port</td> <td></td> <td colspan="2">(1 ~ 65535)</td> </tr> </tbody> </table>				Name	HTTP Server	Proxy Address						Name		< 22 Digits)		URL	http://	< 129 Digits)	Test	HTTP Login Name		< 22 Digits)		HTTP Login Password		< 22 Digits)		Proxy Address		< 129 Digits)		Proxy Login Name		< 22 Digits)		Proxy Login Password		< 22 Digits)		Proxy Port		(1 ~ 65535)	
Name	HTTP Server	Proxy Address																																									
Name		< 22 Digits)																																									
URL	http://	< 129 Digits)	Test																																								
HTTP Login Name		< 22 Digits)																																									
HTTP Login Password		< 22 Digits)																																									
Proxy Address		< 129 Digits)																																									
Proxy Login Name		< 22 Digits)																																									
Proxy Login Password		< 22 Digits)																																									
Proxy Port		(1 ~ 65535)																																									

Function	Description
Name	User can specify multiple HTTP servers as wished. Therefore, user needs to specify a name for each HTTP server setting.
URL	Type the server name or the IP address of the HTTP server.
Test	Check the HTTP server whether it is available or not.
HTTP Login Name	Type the user name for the HTTP server.
HTTP Login Password	Type the password for the HTTP server.
Proxy Address	Type the server name or the IP address of the HTTP Proxy.
Proxy Login Name	Type the user name for the HTTP Proxy.
Proxy Login Password	Type the password for the HTTP Proxy.
Proxy Port	Set port number of Proxy.

3.17.4 SAMBA Server

The device can also send video stream to specified SAMBA server. Most of the time, the SAMBA server will be another PC or NAS server.

FTP Server	TCP Server	HTTP Server	SAMBA Server															
<table border="1"> <thead> <tr> <th>Name</th> <th>SAMBA Server</th> <th>SAMBA Path</th> </tr> </thead> <tbody> <tr> <td>samba</td> <td>192.168.0.201</td> <td>share</td> </tr> </tbody> </table>				Name	SAMBA Server	SAMBA Path	samba	192.168.0.201	share									
Name	SAMBA Server	SAMBA Path																
samba	192.168.0.201	share																
<table border="1"> <tbody> <tr> <td>Name</td> <td>samba</td> <td>(< 22 Digits)</td> </tr> <tr> <td>SAMBA Server</td> <td>192.168.0.201</td> <td>(< 65 Digits) <input type="button" value="Test"/></td> </tr> <tr> <td>SAMBA Login Name</td> <td>test</td> <td>(< 22 Digits)</td> </tr> <tr> <td>SAMBA Login Password</td> <td>*****</td> <td>(< 22 Digits)</td> </tr> <tr> <td>SAMBA Path</td> <td>share</td> <td>(< 65 Digits)</td> </tr> </tbody> </table>				Name	samba	(< 22 Digits)	SAMBA Server	192.168.0.201	(< 65 Digits) <input type="button" value="Test"/>	SAMBA Login Name	test	(< 22 Digits)	SAMBA Login Password	*****	(< 22 Digits)	SAMBA Path	share	(< 65 Digits)
Name	samba	(< 22 Digits)																
SAMBA Server	192.168.0.201	(< 65 Digits) <input type="button" value="Test"/>																
SAMBA Login Name	test	(< 22 Digits)																
SAMBA Login Password	*****	(< 22 Digits)																
SAMBA Path	share	(< 65 Digits)																

Function	Description
Name	User can specify multiple HTTP servers as wished. Therefore, user needs to specify a name for each HTTP server setting.
SAMBA Server	Type the server name or the IP address of the SAMBA server.
Test	Check the SAMBA server whether this account is available or not.
SAMBA Login Name	Type the user name for the SAMBA server.
SAMBA Login Password	Type the password for the SAMBA server.
SAMBA Path	Set working directory path of SAMBA server.

3.18 Event Schedule

This menu is used to specify the schedule of Events and activate some of the actions provided by this device.

3.18.1 Setting

Setting	Record	Port Status																		
<table border="1"> <thead> <tr> <th>Name</th> <th>Enable</th> <th>Type</th> <th>Weekday</th> <th>Start</th> <th>Duration</th> <th>Trigger by</th> <th>Prefix</th> <th>Action</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>			Name	Enable	Type	Weekday	Start	Duration	Trigger by	Prefix	Action									
Name	Enable	Type	Weekday	Start	Duration	Trigger by	Prefix	Action												
Name																				
Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No																			
Type	<input checked="" type="radio"/> Event Trigger <input type="radio"/> Schedule Trigger, Interval 60	{ Seconds}																		
Enable Time	<input checked="" type="checkbox"/> Sun <input checked="" type="checkbox"/> Mon <input checked="" type="checkbox"/> Tue <input checked="" type="checkbox"/> Wed <input checked="" type="checkbox"/> Thu <input checked="" type="checkbox"/> Fri <input checked="" type="checkbox"/> Sat Start from 0 0 , Duration 24 0 0 ((max 168:00 hours))																			
Trigger by	<input type="checkbox"/> Sensor Change to active <input type="checkbox"/> Motion Area <input type="checkbox"/> Camera Tampering <input type="checkbox"/> Audio Detection Over Alarm Level																			
Record File Prefix	(0 ~ 48 Digits)																			
	<input type="checkbox"/> Go <input checked="" type="radio"/> Preset <input type="checkbox"/> Tour <input type="checkbox"/> Voice Alert, Duration 5 { 0~86400 Seconds } <input type="checkbox"/> Alarm Out, Duration 5 { 0~86400 Seconds }																			

Function	Description
Name	Name of the Event or Schedule.
Enable	Enable or disable this Event or Schedule.
Type	Schedule start with Event trigger or Schedule trigger.
Enable Time	Define the feasible time slot.
Trigger by	Select the triggered sources with event trigger.
Record File Prefix	Define the prefix of recorded filename
Action	Define the actions once event triggered.

Example1.

Setting	Record	Port Status
Name	Send to FTP	
Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No	
Type	<input checked="" type="radio"/> Event Trigger <input type="radio"/> Schedule Trigger, Interval 60 (Seconds)	
Enable Time	<input checked="" type="checkbox"/> Sun <input checked="" type="checkbox"/> Mon <input checked="" type="checkbox"/> Tue <input checked="" type="checkbox"/> Wed <input checked="" type="checkbox"/> Thu <input checked="" type="checkbox"/> Fri <input checked="" type="checkbox"/> Sat Start from 0 0 , Duration 24 0 ((max 168:00 hours))	
Trigger by	<input type="checkbox"/> Sensor Change to active <input checked="" type="checkbox"/> Motion Area DefaultWindow <input checked="" type="checkbox"/> Camera Tampering <input type="checkbox"/> Audio Detection Over Alarm Level	
Record File Prefix	(0 ~ 48 Digits)	
Action	<input type="checkbox"/> Go <input checked="" type="radio"/> Preset <input type="radio"/> Tour <input type="checkbox"/> Voice Alert, Duration 5 (0~86400 Seconds) <input type="checkbox"/> Alarm Out, Duration 5 (0~86400 Seconds) <input checked="" type="checkbox"/> Send FTP FTP <input type="checkbox"/> Send TCP <input type="checkbox"/> Send HTTP <input type="checkbox"/> Send E-Mail <input type="checkbox"/> Send SD <input type="checkbox"/> Send Samba <input type="checkbox"/> ICR 0 (0~86400 Seconds)	

Send file to FTP server by motion triggered always by::

1. Select event trigger
2. Enable time: start from 00:00 to 24:00 every day
3. Trigger by: Motion Area (Added in Object Detection page)
4. Action : Send FTP (Add in Event Server -> FTP Server page)

Example 2.

Setting	Record	Port Status
Name	Send to E-mail	
Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No	
Type	<input checked="" type="radio"/> Event Trigger <input type="radio"/> Schedule Trigger, Interval 60 (Seconds)	
Enable Time	<input type="checkbox"/> Sun <input type="checkbox"/> Mon <input type="checkbox"/> Tue <input type="checkbox"/> Wed <input type="checkbox"/> Thu <input checked="" type="checkbox"/> Fri <input type="checkbox"/> Sat Start from 18 0, Duration 12 0 ((max 168:00 hours))	
Trigger by	<input type="checkbox"/> Sensor Change to active <input checked="" type="checkbox"/> Motion Area DefaultWindow <input checked="" type="checkbox"/> Camera Tampering <input type="checkbox"/> Audio Detection Over Alarm Level	
Record File Prefix	(0 ~ 48 Digits)	
Action	<input type="checkbox"/> Go <input checked="" type="radio"/> Preset <input type="radio"/> Tour <input type="checkbox"/> Voice Alert, Duration 5 (0~86400 Seconds) <input type="checkbox"/> Alarm Out, Duration 5 (0~86400 Seconds) <input type="checkbox"/> Send FTP FTP <input type="checkbox"/> Send TCP <input type="checkbox"/> Send HTTP <input checked="" type="checkbox"/> Send E-Mail To email address support@planet.com.tw Subject Motion Detected! Message Motion Detected!	

Send file to E-Mail server by motion triggered from Friday 18:00 to Saturday 06:00

1. Select event trigger.
2. Enable time: start from Friday 18:00 and keep work in 12 hours, so it will stop on Saturday 06:00.
3. Trigger by : Motion Area (Added in Object Detection page)
4. Action : Send e-mail (Add in E-Mail page)
 - i. To email address: You need to input the receiver email address.
 - ii. Subject: You could specify the email subject.
 - iii. Message: You could specify the email content.

Example 3.

Setting		Record	Port Status																												
<table border="1"> <tr> <td>Name</td> <td colspan="3">Trigger_capture_picture</td> </tr> <tr> <td>Enable</td> <td colspan="3"> <input checked="" type="radio"/> Yes <input type="radio"/> No </td> </tr> <tr> <td>Type</td> <td colspan="3"> <input checked="" type="radio"/> Event Trigger <input type="radio"/> Schedule Trigger, Interval 600 (Seconds) </td> </tr> <tr> <td>Enable Time</td> <td colspan="3"> <input type="checkbox"/> Sun <input checked="" type="checkbox"/> Mon <input checked="" type="checkbox"/> Tue <input checked="" type="checkbox"/> Wed <input checked="" type="checkbox"/> Thu <input checked="" type="checkbox"/> Fri <input type="checkbox"/> Sat Start from 18 0 , Duration 6 0 ((max 168:00 hours)) </td> </tr> <tr> <td>Trigger by</td> <td colspan="3"> <input type="checkbox"/> Sensor Change to active <input type="checkbox"/> Motion Area DefaultWindow <input type="checkbox"/> Camera Tampering <input type="checkbox"/> Audio Detection Over Alarm Level </td> </tr> <tr> <td>Record File Prefix</td> <td colspan="3">(0 ~ 48 Digits)</td> </tr> <tr> <td>Action</td> <td colspan="3"> <input type="checkbox"/> Go <input checked="" type="radio"/> Preset <input type="radio"/> Tour <input type="checkbox"/> Voice Alert, Duration 5 (0~86400 Seconds) <input type="checkbox"/> Alarm Out, Duration 5 (0~86400 Seconds) <input checked="" type="checkbox"/> Send FTP FTP <input type="checkbox"/> Send TCP <input type="checkbox"/> Send HTTP <input type="checkbox"/> Send E-Mail </td> </tr> </table>				Name	Trigger_capture_picture			Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No			Type	<input checked="" type="radio"/> Event Trigger <input type="radio"/> Schedule Trigger, Interval 600 (Seconds)			Enable Time	<input type="checkbox"/> Sun <input checked="" type="checkbox"/> Mon <input checked="" type="checkbox"/> Tue <input checked="" type="checkbox"/> Wed <input checked="" type="checkbox"/> Thu <input checked="" type="checkbox"/> Fri <input type="checkbox"/> Sat Start from 18 0 , Duration 6 0 ((max 168:00 hours))			Trigger by	<input type="checkbox"/> Sensor Change to active <input type="checkbox"/> Motion Area DefaultWindow <input type="checkbox"/> Camera Tampering <input type="checkbox"/> Audio Detection Over Alarm Level			Record File Prefix	(0 ~ 48 Digits)			Action	<input type="checkbox"/> Go <input checked="" type="radio"/> Preset <input type="radio"/> Tour <input type="checkbox"/> Voice Alert, Duration 5 (0~86400 Seconds) <input type="checkbox"/> Alarm Out, Duration 5 (0~86400 Seconds) <input checked="" type="checkbox"/> Send FTP FTP <input type="checkbox"/> Send TCP <input type="checkbox"/> Send HTTP <input type="checkbox"/> Send E-Mail		
Name	Trigger_capture_picture																														
Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No																														
Type	<input checked="" type="radio"/> Event Trigger <input type="radio"/> Schedule Trigger, Interval 600 (Seconds)																														
Enable Time	<input type="checkbox"/> Sun <input checked="" type="checkbox"/> Mon <input checked="" type="checkbox"/> Tue <input checked="" type="checkbox"/> Wed <input checked="" type="checkbox"/> Thu <input checked="" type="checkbox"/> Fri <input type="checkbox"/> Sat Start from 18 0 , Duration 6 0 ((max 168:00 hours))																														
Trigger by	<input type="checkbox"/> Sensor Change to active <input type="checkbox"/> Motion Area DefaultWindow <input type="checkbox"/> Camera Tampering <input type="checkbox"/> Audio Detection Over Alarm Level																														
Record File Prefix	(0 ~ 48 Digits)																														
Action	<input type="checkbox"/> Go <input checked="" type="radio"/> Preset <input type="radio"/> Tour <input type="checkbox"/> Voice Alert, Duration 5 (0~86400 Seconds) <input type="checkbox"/> Alarm Out, Duration 5 (0~86400 Seconds) <input checked="" type="checkbox"/> Send FTP FTP <input type="checkbox"/> Send TCP <input type="checkbox"/> Send HTTP <input type="checkbox"/> Send E-Mail																														

Enable send picture to FTP server every 10 minutes during 18:00 to 24:00 from Monday to Friday.

1. Type: Select schedule trigger and interval is 10 minutes.
2. Enable Time: Select Monday to Friday, and set start time from 18:00 and keep work in 6 hours.
3. Trigger by: You do not need to choose it because this will be triggered every 10 minutes.
4. Action: Send one picture to FTP server. (Need to go to event schedule->record setup mjpeg profile).

Setting		Record	Port Status						
<table border="1"> <tr> <td>Record File Type</td> <td>Profile6 mjpeg / 1280x720</td> </tr> <tr> <td>JPEG Picture Numbers</td> <td> <input type="radio"/> Auto <input checked="" type="radio"/> One </td> </tr> <tr> <td>Record File Prefix</td> <td>(0 ~ 20 Digits)</td> </tr> </table>				Record File Type	Profile6 mjpeg / 1280x720	JPEG Picture Numbers	<input type="radio"/> Auto <input checked="" type="radio"/> One	Record File Prefix	(0 ~ 20 Digits)
Record File Type	Profile6 mjpeg / 1280x720								
JPEG Picture Numbers	<input type="radio"/> Auto <input checked="" type="radio"/> One								
Record File Prefix	(0 ~ 20 Digits)								

3.18.2 Record

User can choose the type of record file for event or schedule application.

Setting	Record	Port Status
Record File Type	Profile1 h264 / 1080p	<input type="button" value="▼"/>
Record File Prefix		(0 ~ 20 Digits)
Pre Trigger Duration	5	(0 ~ 20 Seconds)
Best Effort Duration	30	(1 ~ 60 Seconds)
Max File Size	3072	(256 ~ 3072 KB)

Function	Description
Record File Type	Choose AVI or JPEG file format for record file.
Record File Prefix	Define the prefix of recorded filename.
Pre-Trigger Duration	Define the maximum duration of pre-alarm.
Best Effort Duration	Define the best effort duration of post-alarm.
Max. File Size	Define the maximum buffer size of record file.

3.18.3 Port Status

User can check the status of digital input and output (DIDO).

Setting	Record	Port Status
Input Status		Input 0: Inactive
Output Status		Output 0: Inactive

Appendix A: PING IP Address

The PING (stands for Packet Internet Groper) command is used to detect whether a specific IP address is accessible by sending a packet to the specific address and waiting for a reply. It's also a very useful tool to confirm the installation of Internet Camera, or if the IP address conflicts with any other device over the network.

If you want to make sure the IP address of Internet Camera, utilize the PING command as follows:

- Start a DOS window.
- Type ping x.x.x.x, where x.x.x.x is the IP address of the Internet Camera.

The replies, as illustrated below, will provide an explanation to the problem.



```
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

D:\Documents and Settings\Administrator>PING 192.168.0.20

Pinging 192.168.0.20 with 32 bytes of data:
Reply from 192.168.0.20: bytes=32 time=1ms TTL=64
Reply from 192.168.0.20: bytes=32 time<1ms TTL=64
Reply from 192.168.0.20: bytes=32 time<1ms TTL=64
Reply from 192.168.0.20: bytes=32 time<1ms TTL=64

Ping statistics for 192.168.0.20:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms

D:\Documents and Settings\Administrator>
```

If you want to detect any other device that conflicts with the IP address of Internet Camera, you also can utilize the PING command but you must disconnect the Internet Camera from the network first.

Appendix B: 3GPP Access

To use the 3GPP function, in addition to previous section, you might need more information or configuration to make this function works.



Note
To use the 3GPP function, it is strongly recommended to install the Networked Device with a public and fixed IP address without any firewall protection.

RTSP Port:

Port 554 is the default for RTSP service. However, sometimes, some service providers change this port number for some reason. If so, user needs to change this port accordingly.

Dialing procedure:

1. Choose a verified player (PacketVideo or Realplayer currently)
2. Use the following URL to access:

rtsp://host/mpeg4/media.3gp

Where *host* is the host name or IP address of the camera.

Compatible 3G mobile phone:

Please contact your dealer to get the approved list of compatible 3G phone.




Note
Besides IP camera and 3G mobile phone, you will also need to make sure the ISP and telephone company has provided the 3GPP service to you.

Appendix C: Bandwidth and Video Size Estimation

The frame rate of video transmitted from the Internet Camera depends on connection bandwidth between client and server, video resolution, codec type, and quality setting of server. Here is a guideline to help you roughly estimate the bandwidth requirements for your Internet Camera.

The required bandwidth depends on content of video source. The slow motion video will produce smaller bit rate generally and fast motion will produce higher bit rate vice versa. Actual results generated by the Internet Camera may be varying.

Image Resolution	Average range of data sizes for JPEG mode	Average bit rate for MPEG4 mode	Average bit rate for H.264 mode
320 x 240	8 ~ 20k byte per frame	256kbps~768kbps @ 30fps	192kbps~512kbps @ 30fps
640 x 480	20 ~ 50K byte per frame	512kbps~3072kbps @ 30fps	384kbps~1536kbps @ 30fps
1920 x 1080	200 ~ 500k byte per frame	-	1536kbps~10000kbps @ 30fps



Note Audio streaming also takes bandwidth around 32kbps. Some xDSL/Cable modem upload speeds could not even reach up to 128 kbps. Thus, you may not be able to receive good quality video while also streaming audio on a 128 kbps or lower connection. Even though the upload speed is more than 128kbps for optimal video performance, disabling audio streaming will get better video performance.


Appendix D: DDNS Application

1. Configuring PLANET DDNS steps:

Step 1: Enable DDNS option through accessing web page of NAS

Step 2. Select on DDNS server provided, and register an account if you have not used yet.

Let's take dyndns.org as an example. Register an account in <http://planetddns.com>



The screenshot shows the PLANET DDNS website. At the top left is the PLANET logo with the text "PLANET DDNS". At the top right are links for "PLANET Website", "FAQ", and "Support". A large background image of a modern living room with a sofa and a window is visible. On the left, there is a "Sign in" form with fields for "ID / Email" and "Password", and a "Sign in" button. Below the form are links for "Forgotten Password / Create A New Account". In the center, there are three product highlights: "XRT-401F Internet Broadband Router" with a "More Info" button, "ICA-HM132 2 Mega-Pixel 20M IR Vari-Focal Dome IP Camera" with a "More Info" button, and "ICA-HM316 2 Mega-Pixel 11n Outdoor IR IP Camera" with a "More Info" button. At the bottom, there are two sections: "Access anytime & anywhere" which says "Sign-in PLANET DDNS to register a simple domain name to access home device anytime and anywhere." and "Support & Download" which says "You can find drivers, firmware updates, other software and documentation for your PLANET products." There is also a "Go!" button with a download icon. At the very bottom, there are links for "About DDNS | Term of Usage" and "PLANET Technology Corp. Copyright ©2012 All Rights Reserved."

Appendix E: Configuring Port Forwarding Manually

The device can be used with a router. If the device wants to be accessed from the WAN, its IP address needs to be set up as fixed IP address, also the port forwarding or Virtual Server function of router needs to be set up. This device supports UPnP traversal function. Therefore, user could use this feature to configure port forwarding of NAT router first. However, if user needs to configure port forwarding manually, please follow the steps as below:

Manually installing the device with a router on your network is an easy 3-step procedure as shown below::

1. Assign a local/fixed IP address to your device
2. Access the Router with Your Web browser
3. Open/Configure Virtual Server Ports of Your Router


1. Assign a local/fixed IP address to your device

The device must be assigned a local and fixed IP Address that allows it to be recognized by the router. Manually set up the device with a fixed IP address, for example, 192.168.0.100.

2. Access the Router with Your Web browser

The following steps generally apply to any router that you have on your network. The PLANET WNRT-620 is used as an example to clarify the configuration process. Configure the initial settings of the router by following the steps outlined in the router's **Quick Installation Guide**.

If you have cable or DSL service, you will most likely have a dynamically assigned WAN IP Address. 'Dynamic' means that your router's WAN IP address can change from time to time depending on your ISP. A dynamic WAN IP Address identifies your router on the public network and allows it to access the Internet. To find out what your router's WAN IP Address is, go to the **Status** screen on your router and locate the WAN information for your router. As shown on the following page the WAN IP Address will be listed. This will be the address that you will need to type in your web browser to view your camera over the Internet. Be sure to uncheck the **Reset IP address at next boot** button at the top of the screen after modifying the IP address. Failure to do so will reset the IP address when you restart your computer.



The screenshot shows the 'Internet Connection' status page. On the left sidebar, under 'Status', 'Internet Connection' is selected. The main area displays the current internet connection status with the following information:

Actual IP Protocol :	Dynamic IP disconnect
IP Address :	
Subnet Mask :	
Default Gateway :	0.0.0.0
MAC Address :	00:11:22:33:44:56
Primary DNS :	
Secondary DNS :	

Current Time: 14/0000 201-15

Your WAN IP Address will be listed here.


3. Open/set Virtual Server Ports to enable remote image viewing

The firewall security features built into the router and most routers prevent users from accessing the video from the device over the Internet. The router connects to the Internet over a series of numbered ports. The ports normally used by the device are blocked from access over the Internet. Therefore, these ports need to be made accessible over the Internet. This is accomplished using the **Virtual Server** function on the router. The Virtual Server ports used by the camera must be opened through the router for remote access to your camera.


Follow these steps to configure your router's Virtual Server settings

- Click **Enabled**.
- Enter a unique name for each entry.
- Select **Both** under **Protocol Type (TCP and UDP)**
- Enter your camera's local IP Address (e.g., **192.168.0.100**, for example) in the **Private IP** field.
- If you are using the default camera port settings, enter **80** into the **Public** and **Private Port** section, click **Add**.

A check mark appearing before the entry name will indicate that the ports are enabled.



Some ISPs block access to port 80. Be sure to check with your ISP so that you can open the appropriate ports accordingly. If your ISP does not pass traffic on port 80, you will need to change the port the camera uses from 80 to something else, such as 8080. Not all routers are the same, so refer to your user manual for specific instructions on how to open ports.



Virtual Server

You can configure the Broadband router as a Virtual Server so that remote users accessing services such as the Web or FTP at your local site via Public IP Addresses can be automatically redirected to local servers configured with Private IP Addresses. In other words, depending on the requested service (TCP/UDP) port number, the Broadband router redirects the external service request to the appropriate internal server (located at one of your LAN's Private IP Address).

Enable Virtual Server				
Private IP	Private Port	Type	Public Port	Comment
<input type="text"/>	<input type="text"/>	Both	<input type="text"/>	<input type="text"/>
<input type="button" value="Add"/>	<input type="button" value="Reset"/>			

Current Virtual Server Table

NO.	Private IP	Private Port	Type	Public Port	Comment	Select
						<input type="button" value="Delete Selected"/>
						<input type="button" value="Delete All"/>
						<input type="button" value="Reset"/>

Enter valid ports in the **Virtual Server** section of your router. Please make sure to check the box on this line to enable settings. Then the device can be accessed from WAN by the router's WAN IP Address.

By now, you have finished your entire PC configuration for this device.

Appendix F: Power Line Frequency

COUNTRY	VOLTAGE	FREQUENCY	COMMENTS
Argentina	220V	50 Hz	*Neutral and line wires are reversed from that used in Australia and elsewhere.
Australia	230V*	50 Hz	*Outlets typically controlled by adjacent switch. Though <i>nominal</i> voltage has been officially changed to 230V, 240V is within tolerances and commonly found.
Austria	230V	50 Hz	
Brazil	110/220V*	60 Hz	*127V found in states of Bahia, Paran (including Curitiba), Rio de Janeiro, Paulo and Minas Gerais (though 220V may be found in some hotels). Other areas are 220V only, with the exception of Fortaleza (240V).
Canada	120V	60 Hz	
China	220V	50 Hz	
Finland	230V	50 Hz	
France	230V	50 Hz	
Germany	230V	50 Hz	
Hong Kong	220V*	50 Hz	
India	230V	50 Hz	
Italy	230V	50 Hz	
Japan	100V	50/60 Hz*	*Eastern Japan 50 Hz (Tokyo, Kawasaki, Sapporo, Yokohoma, and Sendai); Western Japan 60 Hz (Osaka, Kyoto, Nagoya, Hiroshima)
Malaysia	240V	50 Hz	
Netherlands	230V 220V	50 Hz	
Portugal		50 Hz	
Spain	230V	50 Hz	
Sweden	230V	50 Hz	
Switzerland	230V	50 Hz	
Taiwan	110V	60 Hz	
Thailand	220V	50 Hz	
United Kingdom	230V*	50 Hz	*Outlets typically controlled by adjacent switch. Though nominal voltage has been officially changed to 230V. 240V is within tolerances and commonly found.
United States of America	120V	60 Hz	

Appendix G: Troubleshooting & Frequently Asked Questions

Features	
The video and audio codec is adopted in the device.	<p>The device utilizes H.264, MPEG-4 and M-JPEG triple compression to providing high quality images. Where H.264 and MPEG-4 are standards for video compression, M-JPEG is a standard for image compression.</p> <p>The audio codec is defined as AMR for 3GPP and G.711/G.726 for RTSP streaming.</p>
The maximum number of user accesses the device simultaneously.	<p>The maximum number of users is limited to 20. However, it also depends on the total bandwidth accessed to this device from clients. The maximum data throughput of the device is around 100~200Mbps for UDP mode and 50Mbps for HTTP mode. Therefore, the actual number of connected clients is varying by streaming mode, settings of resolution, codec type, frame rate and bandwidth. Obviously, the performance of the each connected client will slow down when many users are logged on.</p>
Cannot work in cold place when camera is installed outdoors	<p>Please confirm whether 802.3at PoE switch is in use or not. ICA-2250VT needs enough power to enable heater.</p>
Install this device	
Status LED does not light up.	Check and confirm that the DC power adaptor, included in packaged, is used. Secure the power connector and power it on again.
The network cabling is required for the device.	The device uses Category 5 UTP cable allowing 10 and/or 100 Base-TX networking.
The device will be installed and work if a firewall exists on the network.	If a firewall exists on the network, port 80 is open for ordinary data communication. The HTTP port and RTSP port need to be opened on the firewall or NAT router.
The user name and password for the first time or after factory default reset	<p>User name = admin and password = admin. Note that it's all case sensitivity.</p>
Forgot the username and password	<p>Follow the steps below:</p> <ol style="list-style-type: none"> 1. Restore the factory default setting by pressing and holding down for more than 5 seconds on the device. 2. Reconfigure the device.
Forgot the IP address of the device.	Check IP address of device by using the PLANET IP Wizard II program or by UPnP discovery or set the device to default by Reset button.

PLANET IP Wizard II program cannot find the device.	<ul style="list-style-type: none"> ● Re-power the device if cannot find the unit within 1 minutes. ● Do not connect device over a router. PLANET IP Wizard II program cannot detect device over a router. ● If IP address is not assigned to the PC which runs PLANET IP Wizard II program, then PLANET IP Wizard II program cannot find the device. Make sure that IP address is assigned to the PC properly. ● Antivirus software on the PC might interfere with the setup program. Disable the firewall of the antivirus software during setting up this device. ● Check the firewall setting of your PC or Notebook.
Internet Explorer does not seem to work well with the device	<p>Make sure that your Internet Explorer is version 8.0 or later. If you are experiencing problems, try upgrading to the latest version of Microsoft's Internet Explorer from the Microsoft webpage.</p>
PLANET IP Wizard II program fails to save the network parameters.	<p>Network may have trouble. Confirm the parameters and connections of the device.</p>
UPnP NAT Traversal	
Cannot work with NAT router	<p>Maybe NAT router does not support UPnP function. Please check user's manual of router and turn on UPnP function.</p>
Some IP cameras are working but others failed	<p>Maybe too many IP cameras have been installed on the LAN, and then NAT router is out of resource to support more cameras. You could turn off and on NAT router to clear out of date information inside router.</p>
Access this device	
Cannot access the login page and other web pages of the Internet Camera from Internet Explorer	<ul style="list-style-type: none"> ● Maybe the IP Address of the Internet Camera is already being used by another device or computer. To confirm this possible problem, disconnect the Internet Camera from the network first, and then run the PING utility to check it out. ● Maybe due to the network cable, try correcting your network cable and configuration. Test the network interface by connecting a local computer to the Internet Camera via a crossover cable. ● Make sure the Internet connection and setting is ok. ● Make sure the IP address of Internet Explorer is correct. If the Internet Camera has a dynamic address, it may have changed since you last checked it. ● Network congestion may prevent the web page from appearing quickly. Wait for a while. <p>The IP address and Subnet Mask of the PC and Internet Camera must be in the same class of the private IP address on the LAN.</p> <ul style="list-style-type: none"> ● Make sure the http port used by the Internet Camera, default=80,

	<p>is forward to the Internet Camera's private IP address.</p> <ul style="list-style-type: none"> ● The port number assigned in your Internet Camera might not be available via Internet. Check your ISP for available port. ● The proxy server may prevent you from connecting directly to the Internet Camera, set up not to use the proxy server. ● Confirm that Default Gateway address is correct. ● The router needs Port Forwarding feature. Refer to your router's manual for details. ● Packet Filtering of the router may prohibit access from an external network. Refer to your router's manual for details. ● Access the Internet Camera from the Internet with the global IP address of the router and port number of Internet Camera. ● Some routers reject the global IP address to access the Internet Camera on the same LAN. Access with the private IP address and correct port number of Internet Camera. ● When you use DDNS, you need to set Default Gateway and DNS server address. ● If it's not working after the above procedure, reset Internet Camera to default setting and installed it again.
Image or video does not appear on the main page.	<ul style="list-style-type: none"> ● When the PC is connected to Internet Camera for the first time, a pop-up Security Warning window will appear to download ActiveX Controls. When using Windows XP, or Vista, log on with an appropriate account that is authorized to install applications. ● Network congestion may prevent the Image screen from appearing quickly. You may choose lower resolution to reduce the required bandwidth.
How to check the device's ActiveX that is installed on your computer.	Go to C:\Windows\Downloaded Program Files and check to see if there is an entry for the file " IPCamera Control ". The status column should show "Installed". If the file is not listed, make sure your Security Settings in Internet Explorer are configured properly and then try reloading the device's home page. Most likely, the ActiveX control did not download and install correctly. Check your Internet Explorer security settings and then close and restart Internet Explorer. Try to browse and log in again.
Internet Explorer displays the following message: "Your current security settings prohibit downloading ActiveX controls".	Set up the IE security settings or configure the individual settings to allow downloading and scripting of ActiveX controls.
The device works locally but not externally.	<ul style="list-style-type: none"> ● Might be caused from the firewall protection. Check the Internet firewall with your system or network administrator. The firewall may need to have some settings changed in order for the device to be accessible outside your LAN. ● Make sure that the device isn't conflicting with any other web

	<p>server running on your LAN.</p> <ul style="list-style-type: none"> • Checking the configuration of the router settings allows the device to be accessed outside your local LAN. • Check the bandwidth of Internet connection. If the Internet bandwidth is lower than target bit rate, the video streaming will not work correctly.
The unreadable characters are displayed.	<p>Use the operating system of the selected language. Set the Encoding or the Character Set of the selected language on the Internet Explorer.</p>
Frame rate is slower than the setting.	<ul style="list-style-type: none"> • The traffic of the network and the object of the image affect the frame rate. The network congestion causes frame rate slower than the setting. • Check the bandwidth of Internet connection. If the Internet bandwidth is lower than target bit rate, the video streaming will not work correctly. • Ethernet switching hub can smooth the frame rate.
Blank screen or very slow video when audio is enabled.	<ul style="list-style-type: none"> • Your connection to the device does not have enough bandwidth to support a higher frame rate for the streamed image size. Try reducing the video streaming size to 160x120 or 320x240 and/or disabling audio. • Audio will consume 32 kbps. Disable audio to improve video. Your Internet connection may not have enough bandwidth to support streaming audio from the device.
Image Transfer on e-mail or FTP does not work.	<ul style="list-style-type: none"> • Default Gateway and DNS server address should be set up correctly. • If FTP does not work properly, ask your ISP or network administrator about the transferring mode of FTP server.
Pan/Tilt does not work. (including Click to Center and Preset Positioning)	<ul style="list-style-type: none"> • Click “Refresh” on the Internet Explorer when the communication stops with the device. The image will refresh. • Other clients may be operating Pan/Tilt. • Pan/Tilt operation has reached the end of corner.
Pan/Tilt does not work smoothly.	<p>There may be a slight delay when you are using the Pan/Tilt feature in conjunction with streaming audio and video. If you find that there is a significant delay while panning or tilting the camera, try disabling the audio streaming and/or reducing the video streaming size.</p>
Video quality of the device	
The focus on the Camera is bad.	<p>The lens is dirty or dust is attached. Fingerprints, dust, stain, etc. on the lens can degrade the image quality.</p>
The color of the image is poor or	<ul style="list-style-type: none"> • Adjust White Balance.

strange.	<ul style="list-style-type: none"> To insure the images you are viewing are the best they can be, set the Display property setting (color quality) to 16bit at least and 24 bit or higher if possible within your computer. The configuration on the device image display is incorrect. You need to adjust the image related parameters such as brightness, contrast, hue and sharpness properly.
Image flickers.	<ul style="list-style-type: none"> Wrong power line frequency makes images flicker. Make sure the 50 or 60Hz format of your device. If the object is dark, the image will flicker. Make the condition around the Camera brighter.
Noisy images occur.	The video images might be noisy if the device is located in a very low light environment. Make the condition around the camera brighter or turn the IR LED on.
Miscellaneous	
Cannot play the recorded ASF file	Please install Microsoft®'s DirectX 9.0 or later and uses the Windows Media Player 11.0 or later to play the AVI file recorded by the Device.
Cannot unmount SD card immediately after stopping continuous recording	Because the ICA-2250VT needs about two minutes to stop recording procedure. Please wait for two minutes later and then run unmount SD card.